

## SierraNet M408

## **User Manual**



**Software Version 1.70** 

#### Teledyne LeCroy Protocol Solutions Group

Trademarks and Servicemarks

Teledyne LeCroy, CATC Trace, and SierraNet Protocol Suite are trademarks of Teledyne LeCroy.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Intel and Pentium are registered trademarks of Intel Corporation.

All other trademarks and registered trademarks are property of their respective owners.


THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL INFORMATION, EXAMPLES AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE REPRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS ARE FULLY RESPONSIBLE FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN INFORMATION THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT Teledyne LeCroy FOR A COPY.

© 2012 Teledyne LeCroy, Inc. All rights reserved.

This document may be printed and reproduced without additional permission, but all copies should contain this copyright notice.

## WEEE Program



This electronic product is subject to disposal and recycling regulations that vary by country and region. Many countries prohibit the disposal of waste electronic equipment in standard waste receptacles. For more information about proper disposal and recycling of your Teledyne LeCroy product, please visit teledynelecroy.com/recycle.

Teledyne LeCroy 3385 Scott Blvd. Santa Clara, CA 95054

TEL: 800-909-7112 (USA and Canada) TEL: 408-653-1260 (worldwide)

# **Contents**

Chapter 1: Introduction	1
1.1 Analyzer Overview	1
1.1.1 Receiving Your Analyzer	2 3
1.1.6 LCD Display and Button Functions for Configuring the Analyzer	
1.2.1 Software Installation	7
1.3.1 Connecting in General	8
1.4.1 Removing Expansion Cards	9 12
1.5.1 Using the Software	14 15 16 21
1.6 Protocol Analyzer	
1.6.1 Easy and Advanced Modes	30 30
1.7 InFusion	31
1.8 CrossSync Control Panel	31

1.8.1 Launching the CrossSync Control Panel	31
Chapter 2: Protocol Analysis	33
2.1 Starting a New Project	34
2.2 Opening an Existing Project	35
2.3 Closing an Existing Project	
2.4 Software Menus and Toolbar	
2.5 Application Menu Options	
2.5.1 File	
2.5.2 Setup	
2.5.3 Analysis	
2.5.4 Navigation	
2.5.5 View	
2.5.6 Window	
2.5.7 Help	
2.6 Analyzer Settings	49
2.6.1 Device Pane	49
2.6.2 Probe Calibration	51
2.6.3 Port Status Pane	58
2.6.4 Session Control Pane	59
2.6.5 Recording Settings Pane	59
2.6.6 Trigger/Filter Settings Pane	62
2.7 Trigger Filter Settings in Easy Mode	64
2.7.1 Trigger Tab	64
2.7.2 Filter Tab	65
2.7.3 Patterns and Data Capture Setup	71
2.7.4 Pre- and Post Trigger Data Capture	71
2.7.5 Triggering/Filtering Patterns (Easy Mode)	71
2.7.6 Timers/External	72
2.7.7 Pattern Editing Conventions	73
2.7.8 Ethernet Patterns	74
2.7.9 FC Patterns (Easy Mode)	94
2.7.10 Trigger Setup	101
2.8 Advanced Mode (User-Defined)	104
2.8.1 Working in Advanced Mode	104
Chapter 3: Display Manipulation	113
3.1 Viewer Display	
3.2 Quick View	
3.3 Switching Views	117
3 3 SWITTING VIEWS	11/

3.3.1 Decoding Assignments	117
3.3.2 Spreadsheet View	118
3.3.3 Frame Inspector View	128
3.3.4 Traffic Summary View	131
3.3.5 Reassembly of Frames	132
3.3.6 Source and Destination Columns in Traffic Summary View	133
3.3.7 Data View	134
3.3.8 Customize Display	135
3.3.9 Toolbars	136
3.3.10 Status Bar	138
3.3.11 Search Status	138
3.4 Filtering	138
3.4.1 Filter Setup	139
3.5 Using Cursors	142
3.5.1 Cursors	142
3.6 Find	144
3.6.1 Save Find Setup	145
3.6.2 Search From	146
3.6.3 Find Direction	146
3.6.4 Find Logic	146
3.6.5 Finding LUNs and LBAs	146
3.6.6 Data Pattern Search	147
3.7 Preferences	149
3.7.1 Software Settings	150
3.7.2 Port Alias	153
3.7.3 Address Alias	154
3.7.4 Display Settings	155
3.8 Help Menu	160
3.8.1 Tell Teledyne LeCroy	160
3.8.2 Help Topics	160
3.8.3 License Information	160
3.8.4 Check for Updates	161
3.8.5 Shortcut List	161
3.8.6 About	162
Chapter 4: InFusion	163
4.1 InFusion Overview	
4.2 Key Features	
-	
4.3 Infusion Control Interface	
4.4 InFusion Scenario Manager Interface	166

4.5	Port Configuration for InFusion	166
4.6	InFusion Scenarios	167
	4.6.1 Scenario Overview	167
	4.6.2 Jam Details	170
	4.6.3 Scenario Events	170
	4.6.4 Scenario Actions	181
	4.6.5 Available Resources	191
	4.6.6 Using Counters in Events and Actions	192
	4.6.7 Capturing a Data Dword	193
	4.6.8 Using Captured Data Dwords	193
	4.6.9 Dword Matcher	195
	4.6.10 Reusing "Captured DWORDS" in Events	195
	4.6.11 Global Rules	197
	4.6.12 Sequences	198
	4.6.13 Scenario Libraries	199
	4.6.14 Traffic Direction	199
	4.6.15 Copy and Paste Scenarios	200
	4.6.16 Copy and Paste Library	201
	4.6.17 Copy/Cut and Paste States	203
	4.6.18 Copy/Cut and Paste Conditions	203
	4.6.19 Copy/Cut and Paste Events	203
	4.6.20 Marker Trigger	203
	4.6.21 Synch Jammer Scenarios with Jammer Internal Triggers	206
4.7	Scenario Example	209
	4.7.1 Example: Insert DWORD Matcher	209
	4.7.2 Sequence Creation	213
	4.7.3 Summary of Scenario Creation	214
4.8	Running Scenarios	214
Ch	vantor E. Patah Saanaria	247
GII	apter 5: Batch Scenario	
5.1	Using the Batch Scenario Feature	217
	5.1.1 Interface	219
5.2	Batch Scenario Overview	219
	5.2.1 Adding Commands	220
	5.2.2 Adding Events	224
	5.2.3 State Transition	227
	5 2 4 Global Variables	228

Contents Teledyne LeCroy

Appendix A: China Restriction of Hazardous Substances Table	.233
Appendix B: How to Contact Teledyne LeCroy	. 235
Index:	237

Teledyne LeCroy Contents

# **Chapter 1**

## Introduction

This manual describes installation and operation of the Teledyne LeCroy SierraNet M408™ Fibre Channel over Ethernet (FCoE) Protocol Analyzer and includes examples of typical applications.



Figure 1.1 Teledyne LeCroy SierraNet M408 Protocol Analyzer

## 1.1 Analyzer Overview

The SierraNet M408 analyzer is Teledyne LeCroy's 10 Gigabit Ethernet, 40 Gigabit Ethernet and 16 Gigabit Fibre Channel Analyzer and Jammer platform. The M408 has eight SFP+ 10GigE / 16G FC and two QSFP 40GigE ports. The M408 is very portable and can also be rack mounted (1U form-factor). Up to 64 GB of capture memory allow extensive line-speed capturing. The analyzer supports "Super Jumbo" packets up to 64K.

The M408 ports allow signals to pass through without re-timing, ensuring that the test platform is as transparent as possible.

The analyzer can be controlled either via an 1GbE connection to the local network or via a USB connection. The SierraNet M408 provides the user with an easy to understand control panel and LED indicators.

Major features of the M408 include triggering on back-to-back events, use of counters within trigger conditions, and multi-state (up to 24) triggering and filtering state machines with four transitions per state.

Teledyne LeCroy Analyzer Overview

## 1.1.1 Receiving Your Analyzer

The analyzer package includes the following components:

- ☐ SierraNet M408 Analyzer identified in the packing list
- ☐ SierraNet M408 Quick Start
- □ USB A-B 3.0 cable, 1 meter
- □ USB A-B 2.0 cable, 1.8 meter
- Ethernet cable, 10 feet
- ☐ Three-Prong AC power cord
- □ C13-C14 10A power cord, 2 meter
- ☐ Installation CD ROM with software and documentation

## 1.1.2 Unpacking the Analyzer

Inspect the received shipping container for any damage. Unpack the container and account for each of the system components listed on the accompanying packing list. Visually inspect each component for absence of damage. In the event of damage, notify the shipper and Teledyne LeCroy. Retain all shipping materials for shipper's inspection.

## 1.1.3 Analyzer Features

The Analyzer has the following features:

- Power Switch
- □ Speed, Link and Status LEDs (see next page)
- □ Ports 1 and 2 connector pair
- □ Ports 3 and 4 connector pair
- □ Ports 5 and 6 connector pair
- □ Ports 7 and 8 connector pair
- □ Ports 9 and 10 connector pair
- Status and Configuration LCD Display
- □ Front Panel Configuration Buttons
- □ External Trigger Input and Output
- USB port for host connectivity
- □ Ethernet port for network connectivity
- CrossSync Control Panel




Figure 1.2: Front Panel

Analyzer Overview Teledyne LeCroy

On the back, the Analyzer has:

□ Power In




Figure 1.3: Back Panel

## 1.1.4 LEDs

LEDs indicators support each port link pair (P1 - P2; P3 - P4; P5 - P6; P7 - P8 and P9 -10) with the following functionality (see Figure 1.4):

## **Speed LEDs**

The LEDs for SPEED illuminate as follows:

	GBE	Fibre Channel			
Yellow	<ul><li>Reserved</li></ul>	4G/2G/1G FC			
Green	<ul><li>10 GigE</li></ul>	8G FC			
Blue	40 GigE	16G FC			
Link Activity LEDs					
Green	<ul><li>Network activity Detected</li></ul>				
Yellow	<ul><li>Link up, no activity</li></ul>				
No Color	No link				
Status LEDs					
Yellow Blinking	<b>'ellow Blinking</b> Waiting for trigger				
Yellow Solid	<ul><li>Triggered</li></ul>				
Red	Error detected				
No Color	<ul><li>No Activity</li></ul>				

Teledyne LeCroy Analyzer Overview




Figure 1.4: LEDs on the Front Panel

Analyzer Overview Teledyne LeCroy

## 1.1.5 Status and Configuration Display

The Analyzer front LCD display indicates the configuration and status of the device. For example, during initialization, the LCD panel displays boot status messages.

## 1.1.6 LCD Display and Button Functions for Configuring the Analyzer

The basic settings of the SierraNet M408 can be configured from the unit itself. Five buttons are provided to enable you to configure the Analyzer. When you first turn on the Analyzer, after initialization, the LCD displays **SierraNet M408 Available** with two arrows pointing up and down as shown in the illustration below.




Figure 1.5: LCD Display and Button on the Front Panel

When connected via ethernet or USB, the  $\mathbf{Up} \ \widehat{\mathbf{Down}} \ \mathbf{V}$  buttons display the following:

- ☐ Displays current Static or Dynamic IP Address
- ☐ SierraNet M408 SN (serial number)
- □ Connection
- Unit Name
- Set IP Configuration
- □ IP Mode Dynamic, or
- □ IP Mode Static

The **Left**  $\leftarrow$  and **Right**  $\Rightarrow$  buttons are used to change the configuration properties.

The LCD will display **Button Inactive In This MenuItem** if the button does not serve any purpose for that selection.

Perform the following steps to set IP Configuration, Static on Dynamic IP using the buttons and the LCD display on the Analyzer:

## **Set IP Configuration**

To set IP Configuration:

- 1. Press the **Up Button** once to get into the **Set IP Configuration** mode.
- 2. Press the **Center Button** once to select Set IP Configuration.

Teledyne LeCroy Analyzer Overview

**Set IP Mode Static** is displayed in the LCD display. If you do not want to set IP Mode Static, press the **Up Button** to set the IP Mode Dynamic, see "IPMode Dynamic" on page 6).

3. Press the Center Button once to select Set IP Mode Static.

The **Static IP** address (for example: 188.168.040.036) is displayed in the LCD display.

- 4. Press the **Center Button** once to set the Static IP address.
  - The first numeral of the IP address will start blinking.
- 5. Use the **Up Button** or **Down Button** to change the IP Address.
- 6. Press the **Right Button** or **Left Button** to move to the right or left to change each component of the static or dynamic IP address and change it using step 5.
- 7. Once the IP Address is set, press the center button to select it.
- 8. Press the **Up Button** once to **Accept and Reboot**.
- 9. Press the **Up Button** once to **Cancel** the Changes.
- 10. Press the **Up Button** once to set the **Gateway** address. Repeat steps 4 through 9 to set the Gateway address.
- 11. Press the **Up Button** once to set the **Subnet Mask** address. Repeat steps 4 through 9 to set the Subnet Mask address.
- 12. Press the **Up Button** once to set the **Static IP** address. Repeat steps 4 through 9 to set the Static IP address.
- 13. Press the **Center Button** once to confirm reboot. The LCD display will read **Center Button to Confirm Reboot.**
- 14. The Analyzer will reboot. The LCD display will display the new IP Configuration.

## **IPMode Dynamic**

Perform the following steps to set IP Mode Dynamic on the Analyzer:

- 1. Press the **Up Button** once to get into the **Set IP Configuration** mode.
- 2. Press the **Center Button** once to select Set IP Configuration.
  - **Set IP Mode Dynamic** is displayed in the LCD display.
- Press the Center Button once to select Set IP Mode Dynamic.
   The Dynamic IP address (for example: 188.168.040.036) is displayed in the LCD display.
- 4. Press the **Center Button** to select it.
- 5. Press the **Up Button** once to **Accept and Reboot**.
- 6. Press the **Up Button** once to **Cancel the Changes**.

**Note:** In case the device is often moved from one subnet to the other, it is recommended to configure the DHCP server so that the device always receives the same (known) IP address. Many DHCP server allow this type of static allocation based on the devices MAC address.

Installing Your Analyzer Teledyne LeCroy

## 1.2 Installing Your Analyzer

## 1.2.1 Software Installation

The software works on systems using the Windows XP, Windows Server 2003, Windows Server 2008 R2, Windows Server 2012, Windows 7 and Windows 8/8.1 operating systems.

- 1. Insert the Installation CD-ROM into the CD drive on the host machine.
- 2. The installation automatically starts setup, unless Auto Run is off. In that case, select the CD-ROM from "My Computer" and click **Setup**.
- 3. After the warning to close all other programs and before starting the installation, the Install component selection opens.
- 4. Select components for installation.
- 5. Click **Next** to complete the installation.

## **System restart**

You must restart your computer before you can use your Analyzer software.

## **Error Message**

If you get an error message during installation of the drivers for Windows, consult your system administrator. Your system may allow only administrator-level users to copy such driver files.

## 1.3 Hardware Setup

The hardware setup is described below.

## 1.3.1 Connecting in General

**Note:** You must install the software before connecting the analyzer to the host machine for the first time.

To set up the analyzer:

- 1. Connect the analyzer to a 100V–240V, 50Hz–60Hz, power outlet and turn on the Power switch.
  - At power on, the analyzer will go through initialization as shown on the LCD display.
- Connect the USB cable between the SierraNet M408 USB port and a USB port on the Host PC. The host PC operating system detects the analyzer and configures the drivers automatically.
  - (See "Connecting via Ethernet" on page 21 for Ethernet connectivity.)
- 3. Connect the analyzer as shown in the following figure. The following figure shows connections between Port-pairs P1-P2 to Device 1 and Device 2; P3-P4 to Device 3 and Device 4; and so on.

Teledyne LeCroy Expandability




Figure 1.6: Analyzer Connections

## 1.3.2 Cables to Use

Connect to and from devices using SFP+/QSFP and a cable suitable for your setup.




Figure 1.7: Analyzer Connections

## 1.4 Expandability

You can expand the functionality of the tester by daisy-chaining multiple SierraNet M408 analyzers with CATC SYNC Expansion Cards (ACC-EXP-002-X).

You can remove expansion cards with two simple tools.

Expandability Teledyne LeCroy

## 1.4.1 Removing Expansion Cards

You can remove expansion cards using two tools:

- □ Standard (flat blade) 3/16" screwdriver
- ☐ Teledyne LeCroy Extraction Tool (part number 230-0160-00)




Figure 1.8: Tools needed to Remove the Expansion Cards

**Note:** The SierraNet M408 Protocol Analyzer does not support the power expansion card shown below. However, the method of inserting and removing any expansion card is the same.

To remove an expansion card, follow these steps:

1. Unplug the system from AC power and turn the system so the expansion port is facing you. Note the two retaining screws and the holes for the extraction tool that are located on the panel of the expansion card.




Figure 1.9: Holes in the Expansion Card Panel

2. Insert the extraction-tool prongs into the holes in the expansion card panel.

Teledyne LeCroy Expandability

**Note:** If the prongs do not slip easily into the holes, use a small nail file or similar device to remove paint from the prongs




Figure 1.10: Insertion of Handle/Tool into Expansion Card Panel

3. Rotate the extraction tool to a horizontal position to lock the prongs into place and make a handle




Figure 1.11: Rotate Handle/Tool from Vertical to Horizontal

4. Using the screwdriver, loosen both retaining screws by rotating them counterclockwise approximately two full turns, until feeling slight resistance. **Do not force the retaining screws** after two turns.

Expandability Teledyne LeCroy




Figure 1.12: Loosen Screws with Flat Bladed Screw Driver

5. Using the extraction tool as a handle, gently wriggle the expansion card forward about 1/8".




Figure 1.13: Pulling on the Expansion Card

6. Repeat steps 4 and 5 approximately three times, until the card is free from the retaining screws and you can remove the card from the system.




Figure 1.14: Remove Expansion Card from Chassis

Teledyne LeCroy Expandability

## 1.4.2 Daisy-Chaining with CATC SYNC Expansion Cards

You can daisy-chain analyzer units for higher port count, by connecting the units through the optional CATC SYNC Expansion Card on the analyzer back.

## Connecting Two SierraNet M408 Analyzers via the CATC Sync Expansion Card (ACC-EXP-002-X)

Multiple SierraNet M408 Analyzers can be connected using their CATC Sync ports which require an optional expansion card (ACC-EXP-002-X).

**Note:** Refer to relevant protocol analyzer user manual for instructions on how to install the expansion card.

To do so perform the following steps:

1. Make sure to stop any recordings in progress.

**Note:** You may plug/unplug the sync cable while the analyzer unit is powered on.

- 2. Connect the female end of the sync cable to the SYNC OUT port of one SierraNet M408.
- 3. Connect the male end of the sync cable to the SYNC IN port of the other SierraNet M408 (see Figure 1.15 on page 12.)




Figure 1.15: An Example of Connecting two SierraNet M408 Analyzers

Expandability Teledyne LeCroy

## Connecting to Sierra FC M8-4 and Sierra FC M164 Analyzers via the CATC Sync Expansion Card

You can connect and control any of the following analyzers:

- SierraNet M408
- SierraNet M168
- ☐ Sierra FC M8-4
- □ Sierra FC M164

Select **File > New Project** to display the Add Device to Project dialog (see Figure 1.16 on page 13). Select the desired analyzer and click **OK**.



Figure 1.16: Add Device to Project Dialog

You can also create hybrid Ethernet/FC traces when the SierraNet M408 is daisy-chained with other compatible analyzers.

This is similar to the CrossSync functionality, but is done internal to the application, automatically.

You can connect to any of the off-line devices to create a dummy project and use the project when you are connected to a device.

You can select a function from Analyzer, Jammer or both, as well as the protocols you want to work with from 10 GigE, 40 GigE, FC or 10 GigE and FC by selecting the port pair combinations. Select the Device you want to connect to and click **More** to display the Port Configuration columns.

The software checks SFP speed for functional ports. If the software finds any mismatch between the given port configuration and SFPs, it displays a warning message describing the issues, but does not stop the Analyzer and/or Jammer.




Figure 1.17: Port Configuration Dialog.

## 1.5 Launching Your Analyzer

To launch the software, double-click the Net Protocol Suite Icon in the Program Manager Window.

## 1.5.1 Using the Software

The SierraNet M408 application has protocol analysis software to capture data, trigger on Events, and save. Easy Mode allows standard Trigger and Data capture. Advanced Mode (see Figure 1.18 on page 15) allows you to program custom triggering, capturing, multistate sequencing, and timers. (See "Protocol Analysis" on page 33.)




Figure 1.18: Easy/Advanced Mode Toggle Button.

## 1.5.2 Add Device to Project

After you start the software, select **File > New Project** to open Add Device to Project dialog. The following Add Device to Project dialog displays (see Figure 1.19 on page 16). The colors in the 'Location' column mean the following:

- □ Red: Device is not updated (firmware or one of bus engines is not updated).
- ☐ Light Blue: Ready to connect.
- ☐ Yellow: Device manually added and it is not connected OR device is locked.
- □ Green: Connected

Select a device with "Ready to connect" status.

If the device supports more than one protocol, select the desired protocols from the drop-down list in the Port column.

Select the port configuration from the Link Assignment column.

Click OK to connect to the device.



Figure 1.19: Add Device to Project Dialog

**Note:** Click **Refresh Device List** to display all the devices on the on the local Ethernet subnet and also devices connected via USB cable.

## 1.5.3 Device Management

Click on **Setup a**nd select **Device Management** to open the Device Management dialog (see Figure 1.21 on page 17).




Figure 1.20: Connecting to Device(s).




Figure 1.21: Device Management Dialog.

## **Set Alias Name**

Address Alias allows you to assign a meaningful name to each address to assist in interpreting the results displayed in the trace view. To assign address names in an open trace view, select **Setup > Device Management > Set Device Alias Name** (see Figure 1.22 on page 17.)



Figure 1.22: Assign Alias Name.

Assign a meaningful name to each address in use and click **OK**. The assigned names replace the address in the trace view, Search, filter, and Statistical Report.

If you elect to save the captured trace file, the assigned address names are saved together with the result, so that when you open the trace file later, the assigned names are retained.

#### Set As Default

If you want to set these address aliases for trace files that will be captured later, you can set them as default, and new traces will be opened by these default address aliases.

## Connect/Disconnect

Click **Connect** to connect or click **Disconnect** to disconnect a device.

#### Add Device...

Click Add Device to add a device with a static IP address.



Figure 1.23: Add device.

**Note:** When entering addresses, you must include the leading zeros. Use 003.010.195.006 as entering 3.10.195.6 will not work. This is also applicable for Figure 1.33 on page 25.

#### Find

Click the **Find** button to test if the device at the specified IP address can be located.

## **Force Add/Connect Attempt**

Use this option if the **Find** function fails, but you're sure the address is correct and you still want to attempt the connection. This setting is stored in the device list database and is applied when attempting to connect to the device.

#### **Remove Device**

Click **Remove Device** to remove a previously added device.

## **IP Settings**

Click **IP Setting** to reset a device's IP settings. The following IP Setting dialog displays (see Figure 1.24).




Figure 1.24: IP Setting Dialog.

## **Update Device**

Click **Update** to update a device (see "Update Device" on page 28).

## **Subnets**

Refer to section below (see "Ethernet Connectivity Through a Different Subnet" on page 22).

## **Adapters**

Click **Adapters** to select the network adapter to use for connecting to Ethernet-connected devices. Some PCs have multiple adapters for connecting to different networks, so be sure to choose the one to which your desired device is connected. The following dialog displays.




Figure 1.25: Select Adapter Dialog.

#### **Reset Device**

Click **Reset Device** to open the Reset Device dialog. To Reset a Device, select a **Device** from the list below or enter an IP address. Then click the **Reset** button to reset the device.




Figure 1.26: Device Reset Menu

#### **Refresh Device List**

Click Refresh Device List to refresh the device list.

To connect to a device, select a device which is Ready to Connect and click the **Connect** button on the right. The Connection Properties dialog is displayed (see the following screen capture).




Figure 1.27: Connection Properties Dialog.

Specify one of the actions from the following:

- Automatically connect to the device
- □ Ask if I want to connect to the device

#### □ Take no action

If 'Automatically connect to the device' is selected, the next time the application opens the device will be automatically connected.

In the **Device Management** dialog daisy-chained units are displayed in the **Device** column with a [ (square bracket) icon. The sequence of the units is displayed in the **Order** column. See Figure 1.28.




Figure 1.28: Device Management Dialog Displaying Unit 1 and Unit 2 Daisy-Chained together.

**Note:** When using the CATC Sync cards the order is automatically detected.

**IMPORTANT!** Power up all units before starting the software.

## 1.5.4 Connecting via Ethernet

The Ethernet connection can have any of these configurations:

- 1. Analyzer connected to the host computer (machine running the application software), using a switch, Gigabit Ethernet interface, or similar device.
- 2. Analyzer connected directly to the host computer using an Ethernet crossover cable.

To connect via USB refer to "Connecting Via USB" on page 27.

## **Connecting to a Network**

When connected to a network, the analyzer can communicate with the DHCP server in order to obtain it's IP address configuration. The client needs to send a request to the DHCP server to obtain an IP. The server sends only one reply. The server does not necessarily send the available IP address

The SierraNet M408 product uses the following ports:

TCP Ports: 4000 - 4003

UDP Ports: 4033-4035

## Connecting using a Switch, or Similar Device

The SierraNet M408 analyzer is automatically detected by the application if the analyzer and the host PC on which the application is running are on the same Ethernet subnet. If the analyzer and the host PC are located on different subnets then the IP address of the analyzer needs to be configured manually in the application. To add the IP address to the Select Device dialog, use the **Add Device** button (refer to "Add Device..." on page 18 and see Figure 1.24 on page 19). See Figure 1.24 on page 19 to set the IP address.

## Analyzer Connected Directly to the Host Machine Using a Crossover Ethernet Cable

SierraNet M408 Systems are designed to connect to host PCs using a network connection, which allows the user to control the SierraNet M408 System from a local or remote host system. When connected to the host machine using a crossover ethernet cable, the Analyzer must be given a static IP address such that it will reside on the same subnet as the Ethernet interface of the host computer. See Figure 1.24 on page 19 to set the IP address.

## **Ethernet Connectivity Through a Different Subnet**

The default discovery mechanism relies on broadcast messaging, which typically does not traverse between different subnets. Thus, alternate mechanisms are required to discover devices on different subnets. This section describes two methods: automatic subnet scanning and manual device adding.

## **Automatic Subnet Scanning**

The software can be configured to automatically discover devices on other subnets. To do this, you must specify which subnets you would like the software to scan. This section describes how to add subnets so that the software will scan them for available devices.




Figure 1.29: Device List with Subnets Button

Clicking on the "Subnets..." button invokes the "Manage Additional Subnets" dialog, which shows the existing subnets and allows the user to add/remove them.




Figure 1.30: Manage Additional Subnets Dialog

Subnets in this list will be saved (e.g. to the Windows registry). Clicking on the "Add..." button invokes a dialog for adding another subnet.




Figure 1.31: Adding a Subnet with Host's Mask

A subnet is identified by a network IP address and a subnet mask, so both parameters must be specified. By default, we'll use the Host's subnet mask since it's most likely in enterprise environments that different subnets will still have the same mask. However, the option to provide some other subnet mask is provided.




Figure 1.32: Adding a Subnet With a Different Mask

The software will validate the subnet to make sure it is not the same as the host's subnet.

## **Connecting Manually**

If the device cannot be discovered through the automatic discovery mechanisms, you can discover it directly if you know its IP address. The SierraNet M408 IP address must be added manually. Perform the following steps:

- 1. Launch the application and click the Ethernet radio button.
- 2. Click OK.
- 3. Click **Add Device** in the Select Device dialog.
- 4. The Add Device with Static IP displays. Enter the IP address to add the device.




Figure 1.33: Add New Device with Static IP Address

Once the IP address is added, the application will then send a connection request to that IP address to connect to the SierraNet M408 System.

#### Setup IP

This section describes the connectivity procedure for the SierraNet M408 System (see "IP Settings" on page 18).

## **Configuring the Ethernet Connection**

There are two ways of configuring a SierraNet M408 for network connectivity:

- □ **DHCP** automatically assigns an IP address. DHCP is the default.
- □ **Static IP** prompts you to enter a specific IP address.

The SierraNet M408 can be configured from the unit itself using the five buttons and the LCD display on the front panel of the analyzer. For additional information, see "LCD Display and Button Functions for Configuring the Analyzer" on page 5.

## **Dynamic Configurations**

Dynamic configuration uses DHCP (Dynamic Host Configuration Protocol).

Under DHCP, SierraNet M408 will issue a broadcast to any DHCP Server requesting configuration. If a DHCP server is present on the network, it will assign an IP address, Subnet Mask and a default GATEWAY (a router port IP address) to the SierraNet M408. The Gateway port will be used by SierraNet M408 to forward packets to IP addresses that do not reside within the same subnet.

When using the dynamic configuration, the front panel display will only update the IP address.

The subnet mask and gateway address will remain at the last values programmed

(000.000.000 by default, or whatever was last programmed in the static configuration). While in dynamic mode, these parameters will have actually been programmed within the IP STACK inside the SierraNet M408, but are not displayed in the LCD display.

To change from DHCP to Static IP, you must be connected to a device using USB:

1. Select **Setup > All Connected Devices > IP Settings** from the menu bar.

**Note:** If you are connected to the device using Ethernet, the Configuration menu does not have the Setup IP command.

The IP Setting dialog displays. For IP Mode, two radio buttons are available: Static IP and DHCP. DHCP is the default (see Figure 1.34 on page 26.)



Figure 1.34: Static IP Setup Dialog

## **Static Configurations**

Within static configurations, SierraNet M408 must be manually programmed with an IP address, Subnet Mask and a default GATEWAY.

Once SierraNet M408 has been programmed with the static network configuration, it will broadcast a UDP message on its own subnet stating that is on line and available for connection.

**Note:** This broadcast is only on the subnet that includes the SierraNet M408 System.

When the application is started on the host machine, it will broadcast a UDP message on its own subnet asking all SierraNet M408s available to identify themselves.

**Note:** This broadcast is only on the host machine's subnet.

If the host machine and the SierraNet M408 System reside on the same subnet, they will see each other's broadcasts and the application will automatically populate the Select Device list.

2. To change to Static IP, click the **Static IP** radio button.

Enter the Static IP Address.

Enter the Subnet Mask.

Click Update.

The system displays a warning message.

Click Yes to get a success message.

Click **OK**. The message closes and the device resets.

3. To change back to DHCP, in the IP setup dialog, click the **DHCP** radio button, then click **Update**.



Figure 1.35: Dynamic IP Setup Success Message

After you see the Warning Message, click **Yes** After you see the Success Message, click **OK**.

Note: You can also click Reset.

## 1.5.5 Connecting Via USB

To set up the Analyzer using a USB for the first time:

- 1. Remove the Analyzer from its shipping container.
- 2. Insert the Installation CD.
- 3. Connect the Analyzer to a power outlet using the provided power cord.
- 4. Connect the USB port to a USB port on the PC using a USB cable.
- 5. Turn on the rear power switch and the front power switch.
- 6. Click **Next** after you see the Add New Hardware Wizard dialog.
- 7. Follow the Microsoft\* Windows\* on-screen Plug-and-Play instructions for the automatic installation of the Analyzer as a USB device on your host machine. (The required USB files are included on the Installation CD.)
- 8. Click **Finish** when you see the message that says "Windows has finished installing the software that your new hardware requires" and the file has been installed in your host machine.

**Note:** Do not change from USB to Ethernet, or back, without power cycling the Analyzer.

To connect the Analyzer to a host system via ethernet, refer to "Connecting via Ethernet" on page 21.

## 1.5.6 Update Device

The Update Device dialog allows you to update the Firmware and BusEngine components of a connected analyzer. During the update process, the analyzer may reset and/or need to be power-cycled. Be sure to follow the on-screen prompts to complete the update process successfully.

1. Click the **Update Device** button on the Device Management dialog.





Figure 1.36: Update Device Dialog with a Bad Device Status

An item whose version is correct has an OK status in a green box. An item whose version is mismatched has a BAD status in a red box.

**Note:** You can click the ellipses (...) at the end of a file path and name to display an Open dialog, in which you can browse for files.

Click the checkbox to the left of an item with BAD status, then click Update Selected to update that item to the correct version.



Launching Your Analyzer Teledyne LeCroy

Figure 1.37: Update Device Dialog Beginning to Update Status of a Device

After the update, the device should restart. If the software prompts you to power-cycle the device, do so at this time; then the update will be complete.

Otherwise, when the software prompts you that the update is complete, the update process is done and you may continue using the device.

The connection may freeze when the unit reboots after the firmware update. Perform the following steps to recover:

- 1. Click **OK** on the error message in the Info dialog.
- 2. Click **Close** to close the Device Setup dialog.
- 3. Click **Refresh Device List** in the Device Management dialog (see Figure 1.28 on page 21).
- 4. Click Disconnect.




Figure 1.38: Device Setup Dialog with OK Device Status

**Note:** Do not shut down or power cycle the analyzer during this process, unless specifically instructed to do so by the application.

Teledyne LeCroy Protocol Analyzer

# 1.6 Protocol Analyzer

To use the software for protocol analysis, first select **File > New Project** for a new project or **File > Open** to open an existing protocol analysis .gep file. (see "Protocol Analysis" on page 33.) You can also open a .get example file. Example files are in the Examples folder. You can also select **File > Recent Projects** to open a project you had recently saved.

**Note:** Select **File** from the main menu Analyzer Menu Bar or click on the **Hide Menubar** icon and select **File > Open.** Clicking the **Alt** key toggles showing/hiding the Analyzer Menu Bar.

**Note:** The application prevents the host machine from going into sleep mode to avoid loss of traces.

The software menus and toolbar options are explained in detail in "Software Menus and Toolbar" on page 36.

For more information on Analyzer Settings refer to "Analyzer Settings" on page 49.

# 1.6.1 Easy and Advanced Modes

The Easy Mode provides the quickest way to configure the analyzer to filter and trigger on events of interest. See "Trigger Filter Settings in Easy Mode" on page 64.

Use Advanced Mode only after you become familiar with the hardware and software and have special needs. To start working with the protocol analyzer and software. For more information on Advanced Mode refer to "Advanced Mode (User-Defined)" on page 104.

# 1.6.2 Viewing Captured Data

After data capture, the captured data is in the Viewer, see "Display Manipulation" on page 113. You can display the same data in:

- □ **Spreadsheet View**: Shows Protocol Fields and Frames by time.
- ☐ Frame Inspector View: Shows detail information about packet highlighted in Spreadsheet or Packet views.
- □ **Traffic Summary View:** The Traffic Summary View for each captured signal can be viewed. It displays errors for the whole trace or for a selected range. You can show grid lines, select rows and modify columns.
- Data View: The Data View displays information in Hexadecimal and ASCII format.

# 1.6.3 Preferences

For special work, you can use the Preferences menu to configure Software Settings, Port Alias, Address Alias and Display Settings. (See "Preferences" on page 149.)

InFusion Teledyne LeCroy

### 1.6.4 Port Status

You can see an overview of the analyzer's ports in the Analyzer Settings Pane (see "Port Status Pane" on page 58).

# 1.7 InFusion

The Teledyne LeCroy InFusion™ Error Injector and Traffic Modifier is an error injector and traffic modification tool that allows you to verify real-world fault handling for SierraFC systems (see "InFusion" on page 163).

# 1.8 CrossSync Control Panel

The CrossSync Control Panel allows you to select analyzers for synchronization and manage the recording process. It supports a wide combination of Teledyne LeCroy's flagship analyzers including PCI Express, USB, DDR, Serial ATA (SATA), Serial Attached SCSI (SAS), Fibre Channel (FC) and Ethernet.

CrossSync is Teledyne LeCroy's analyzer synchronization solution that enables timealigned display of protocol traffic from multiple daisy-chained analyzers showing packet traffic from multiple high-speed serial busses. A lightweight software control panel allows users to select analyzers for synchronization and manage the recording process. Captured traffic is displayed using the latest analyzer software (in separate windows) with all the protocol specific search and reporting features.

Captured packets are displayed in separate windows that share a common time scale. Navigating the traffic in either direction will scroll to the same timestamp in a synchronized window. When using the CrossSync option, users can access the full complement of analysis capabilities available within the individual Teledyne LeCroy software. Search, reporting, and decoding all operate normally.

This feature is available with the Teledyne LeCroy Net Protocol Suite software application.

# 1.8.1 Launching the CrossSync Control Panel

Click **Start > Programs > LeCroy > CrossSync > CrossSync Control Panel** to launch the application.

Teledyne LeCroy CrossSync Control Panel

# **Chapter 2**

# **Protocol Analysis**

The system performs Protocol Analysis by defining and running an analysis project for both Fibre Channel over Ethernet (FCoE) and Fibre Channel (FC) depending on the Analyzer that you are connected to. A captured trace is saved in a file with the **.get** extension. An analysis project definition defines what to capture, what the analyzer triggers on, and the memory settings. You can save defined projects as project \*.gep files for later use.

After you install the Analyzer software (see "Software Installation" on page 7) and set up the Analyzer (see "Hardware Setup" on page 7), launch the Analyzer software (see "Launching Your Analyzer" on page 14) to display the main window.




Figure 2.1: Teledyne LeCroy Ethernet Protocol Suite Main Window.

Teledyne LeCroy Starting a New Project

#### 2.1 Starting a New Project

To start a new project, click File > New Project from the Analyzer menu options, or click on the **Hide Menubar** icon and select **File > New Project** (see <u>Figure 2.2</u>) to display the Add Device to Project dialog (see Figure 1.16 on page 13). Select the desired analyzer and click OK.

**Note:** Click **Alt** to toggle between showing/hiding the top menu bar.




Figure 2.2: Starting a New Project from the Application Menu bar




Figure 2.3: Starting a New Project from the Menu button on the Application toolbar

The New Project main window opens with default settings to capture Everything on the bus and to Trigger On on Snapshot. (The analyzer captures everything immediately without triggering on anything in particular.)




Figure 2.4: Main Window.


# 2.2 Opening an Existing Project

To open an existing project, click **File > Open** from the Analyzer Menu Bar to open an existing .gep project, or click on the **Hide Menubar** icon and select **File > Open**.

# 2.3 Closing an Existing Project


Close Project allows you to close the current project without closing the Protocol Suite.

Teledyne LeCroy Software Menus and Toolbar



#### 2.4 **Software Menus and Toolbar**

The menu toolbar options are given in the following table.



Software Menus and Toolbar Teledyne LeCroy

	Export to Wireshark icon. Click to export trace to Wireshark and launch the Wireshark application. Wireshark must be installed on the PC. Wireshark is a free application available at www.wireshark.org. (see "Export and Open with Wireshark" on page 39).
	Displays the Trace information dialog. (see "Trace Information" on page 44).
H	Find icon. You can search for specific Triggers and specify the From, Domain, Direction and Logic. See "Find" on page 144.
EŞ.	Find Next icon. Searches for the next instance.
Ħ	Find Previous icon. Searches for the previous instance.
<u></u>	Go to icon. Click to locate cursors or specific packets: Timestamp, X Position, Y Position, Event, Begin, and End. See Figure 2.17 on page 47.
<b>*</b>	Go to Trigger icon. Click to go to the trigger point in the trace. See Figure 2.17 on page 47.
	Go to Marker icon. Click to go to a specific Marker. See "Markers" on page 127.
<b>①</b>	Zoom in icon. Searches for the previous instance.
	Zoom out icon. Searches for the previous instance.
<b>Y</b> .	Filter icon. Click to open the filter dialog. See "Filtering" on page 138.
Ch <b>T</b>	Ports icon. Click to select a port. See "Ports" on page 135.
	Idles icon. Click to show/hide idles in a trace.
Y	Device External Trig Setting icon. Click to open the Device Settings dialog. See "External Trigger" on page 58.
Y	Recording Setting icon. Click to open the Recording Setting dialog. See "Recording Settings Pane" on page 59.
Y	Trigger Filter Settings icon. Click to open the Trigger Filter Settings dialog. See "Patterns and Data Capture Setup" on page 71.

### 2.5 **Application Menu Options**

The following menu options display in the main window:

- □ File
- □ Setup
- Analysis
- Navigation
- □ View
- Window
- □ Help

#### 2.5.1 **File**

The File menu has the standard menu options as shown in the following screen capture.




Figure 2.5: File Menu Options.

New Project	Click to open a new project.
Open	Click to open an existing trace or trace files.
Save	Click to save an existing trace or trace files.
Save Project as	Click to save the current project with a different name or directory.
Save as	Click to save an existing trace or trace files with a different name or directory.
Batch	Click to run batch scenarios. (see "Batch Scenario" on page 217).  Available only after a project is open.
Close	Click to close a frame or window when multiple frames or windows are open.

Export	Export file to Excel, text or export and open with Wireshark (see "Export and Open with Wireshark" on page 39)
Print/Print Preview/Print Setup	Printing options for the file
Recent Trace Files	Lists recent trace files to open
Recent Projects	Lists recent projects to open
Exit	Click to exit the application.

# **Export and Open with Wireshark**

Selecting **File** > **Export and Open with Wireshark** or clicking the icon displays the Save As Dialog. Checking the Only Export Displayed Events box exports only the displayed events. If the box is unchecked, then all the contents of the trace file are exported. Only Ethernet content is exported; Fibre Channel content is not exported.




Figure 2.6: Wireshark Save As Dialog.

# 2.5.2 **Setup**

The Setup menu has the following options to setup and configure the device:

- Device Management
- Preferences

# **Device Management**

Click Device Management to display the Device Management dialog. Refer to "Device Management" on page 16 for more information.

### **Preferences**

The Preferences option allows you to set the software and display settings.

Click on **Setup > Preferences** or click icon to display the Preferences dialog (see Figure 2.7 on page 40) and configure these settings. Refer to "Preferences" on page 149 for more information.




Figure 2.7: Preferences Dialog.

The following can be configured in Preferences:

- Software Settings
- □ Port Alias
- Address Alias
- Display settings
- User Path
- Temp Path
- Browse Default Path
  - Software default
  - Windows default
- □ FC Backbone Version
  - BB-5
  - BB-6

Application Menu Options Teledyne LeCroy

# 2.5.3 Analysis

The Analysis menu has the following options to view trace files and specify SCSI decoding assignments:

- Decoding Assignments
- Spreadsheet View
- □ Frame Inspector View
- □ Traffic Summary View
- Data View
- □ Trace Information




Figure 2.8: Analysis Menu.

# **Decoding Assignments**

Click on **Analysis** and select **Decoding Assignments** to display the **Decoding Assignments** dialog.




Figure 2.9: Decoding Assignments Dialog.

# **Spreadsheet View**

Click on Analysis and select Spreadsheet View or click the Spreadsheet icon to display the Spreadsheet View.




Figure 2.10: Spreadsheet View.

Spreadsheet View displays Protocol Fields and Frames by time. Refer to "Spreadsheet View" on page 118 for more information.

# Frame Inspector View

Click on **Analysis** and select **Frame Inspector View** or click the Frame Inspector View.




Figure 2.11: Frame Inspector View.

Frame Inspector View displays detail information about a frame highlighted in Spreadsheet view. Refer to "Frame Inspector View" on page 128 for more information. Application Menu Options Teledyne LeCroy

# **Traffic Summary View**

Click on **Analysis** and select **Traffic Summary View** or click the icon to display the Traffic Summary View.




Figure 2.12: Traffic Summary View.

The Traffic Summary View for each captured signal can be viewed. This Summary View displays the statistics of commands, the type of command and the total count. For each command it displays the percent of the total count.

The software collects up to 10,000 unique pairs for the reports. Anything beyond that is grouped into the "Others" category as shown in <u>Figure 2.12</u>.

# **Data View**

Click on **Analysis** and select **Data View** or click the icon to display the Data View (see Figure 2.13 on page 44).




Figure 2.13: Data View.

The Data View displays information in Hexadecimal and ASCII format. Refer to "Data View" on page 134 for more information.

### **Trace Information**

Click on **Analysis** and select **Trace Information** or click the icon to display the trace Information dialog (see Figure 2.14 on page 45 and Figure 2.15 on page 46). You can click on the hyperlinks: File info, Hardware info, Project info or License info to navigate to that section. Click **Open Trace Project** to open the project in which the trace was captured.

Application Menu Options Teledyne LeCroy




Figure 2.14: Trace Information Dialog 1.




Figure 2.15: Trace Information Dialog 2.

#### 2.5.4 **Navigation**

The Navigation menu option enables the user to navigate the application (see Figure 2.16 on page 47). You can go to the trigger, marker or where the cursor is located. Markers can also be added and removed. Find menu options are available as shown in the screen capture below.

**Note:** The menu options listed in the Navigation menu can also be selected when you right-click anywhere on the screen, see "Markers" on page 127.

Application Menu Options Teledyne LeCroy



Figure 2.16: Navigation Menu Option.

The Navigation menu currently has the following options (see Figure 2.16 on page 47).

□ **Go To** menu options allows location of cursors or specific packets: Timestamp, X Position, Y Position, Event, Begin, and End. Refer to Figure 2.17.



Figure 2.17: Navigation Go to Menu Option.

- ☐ Go to Trigger- Allows you to go to the trigger point in the trace.
- ☐ Go to Marker- Allows you to go to specific Marker (see "Markers" on page 127).
- ☐ Find Allows you to examine any data capture file to quickly locate the packet or data pattern (see "Find" on page 144).
- ☐ Find Next Gives you the option to search for the next instance (see "Find" on page 144).
- ☐ Find Previous Gives you the option to search for the previous instance (see "Find" on page 144).
- ☐ Display Markers Displays the list of markers (see "Markers" on page 127).

# 2.5.5 View

The View menu has the following options:

- □ Zoom in- Allows you to zoom in the view.
- □ Zoom out- Allows you to zoom out the view.
- ☐ Hide/Show -Displays the Filter dialog box enabling you to configure filters applied to the trace view.
- ☐ Hide/Show non-Frames Shows/Hides the Idles in the trace view.
- □ Toolbars-Allows you to customize the toolbar display (see Figure 2.18 on page 48).
- ☐ Menu Bar-Selecting and deselecting this option toggles between showing and hiding the menu bar. Press the Alt + Windows keys to do the same.




Figure 2.18: View Menu Option.

# 2.5.6 Window

Window - Allows you to configure your display. It has the following options:

- ☐ Window Cascade (see "Switching Views" on page 117).
- ☐ Window Tile (see "Switching Views" on page 117).
- ☐ Close All Traces closes all open traces

# 2.5.7 Help

The Help menu (see Figure 2.19 on page 49) currently has the following options:

# **Tell Teledyne LeCroy**

Report a problem to Teledyne LeCroy Support via e-mail by selecting **Help>Tell Teledyne LeCroy** from the application toolbar. This requires that an e-mail client be installed and configured on the host machine.

# **Help Topics**

Displays the User Manual.

### **License Information**

Displays the License information with the licences that are purchased and their features (see "License Information" on page 160).

# **Check for Updates**

Checks to see if there are any updates available for download "Check for Updates" on page 161.

### **Shortcut List**

Displays a list of keyboard shortcuts (see "Shortcut List" on page 161).

### **About**

Displays the current Net Protocol Suite information, see "About" on page 162.




Figure 2.19: Help Menu Option.

# 2.6 Analyzer Settings

The Teledyne LeCroy Ethernet Protocol Suite Analyzer Settings panel in the application has six functional sections as shown below. The application is designed such that the user starts from the left pane and moves to the right pane to connect to a device and record a capture as listed below.



Figure 2.20: Analyzer Settings Panel.

- 1. Device Pane: Enables adding and assigning a device.
- 2. Port Status Pane: View the port status.
- 3. Session Control Pane: Starts and stops recording.
- Recording Settings Pane: Manage the recording settings such as Number of Segments and Segment Size.
- 5. <u>Trigger/Filter Settings Pane</u>: Enables Trigger Filter settings.

# 2.6.1 Device Pane

The Device pane allows you to add or remove a device in the chain of attached devices and assign each device to a different project (see Figure 2.21 on page 50). You must first add a device before activating it by clicking **Setup > Device Management** to select a device drag-and-drop it onto a device in the Project Device Pane. You can have multiple projects assigned to different devices. A single project will automatically connect to an active device. Right-click on a device and select **Activate** to start the device. Click The X icon to disconnect the device.

Teledyne LeCroy **Analyzer Settings** 





Figure 2.21: Device Pane Displaying Multiple Devices.

- Presents a physical representation of the analyzers.
- □ Presents a logical representation of the analyzers.

Perform the following steps to add a device.

1. Click Setup > Device Management. The **Device Management** dialog displays.



2. Click on the selected Device (Sierra Net M408 SN: 10884) and select the Connect button.

# **Device Settings**

The Device Settings dialog allows you to configure Probe Calibration and the External Trigger settings for each device. See "Probe Calibration" on page 51 and "External Trigger" on page 58 for more information.

# 2.6.2 Probe Calibration

In the Device Settings dialog, select the Probe Calibration Settings tab. Depending on the project's protocol configuration, the Device Settings tab appears slightly different. These settings are meant for advanced users to tune the performance of the Analyzer's receiver ports, the Jammer's receiver and transmitter ports, and the Analyzer's DUT link pass-through path. In most cases, the default settings will perform well and should be used asis.

# **40 GigE Configurations**




Figure 2.22: Device Settings dialog for 40 GigE device.

You can manually calibrate the probe settings. Set the parameters for the following:

- □ Cable Type: Select Optical, 1m Copper or 3m Copper.
- RX Eq DC gain: Select a value from the drop-down list.
- □ RX Eq Control: Select a value from the drop-down list.
- □ Advanced: Selecting **Advanced** displays the Advanced Probe Setting dialog. (See <u>Figure 2.23</u>.) Enter the desired values for each of the parameters.
- □ Splitter: Selecting **Splitter** displays the Splitter Settings dialog. (See Figure 2.24 on page 52.)
- □ Apply Selected Settings to All: Applies the settings selected in the currently selected port to all ports in the list.

Teledyne LeCroy **Analyzer Settings** 

- ☐ Import: Loads calibration settings from \*.csv file.
- ☐ Export: Creates a new \*.csv file.
- ☐ Set as Bootup: Loads these settings into memory; rebooting will automatically load these values.
- ☐ Restore Factory Settings: Restores factory settings.




Figure 2.23: Advanced Probe Setting dialog for 40 GigE device.




Figure 2.24: Splitter Settings dialog for 40 GigE device.

# 10 GigE Configurations




Figure 2.25: Device Settings dialog for 10 GigE device.

You can manually calibrate the probe settings.

Set the parameters for the following:

- □ Cable Type: Select Optical, 1m Copper or 3m Copper.
- RX Eq DC gain: Select a value from the drop-down list.
- RX Eq Control: Select a value from the drop-down list.
- □ Advanced: Selecting **Advanced** displays the Advanced Probe Setting dialog. (See Figure 2.26.) Enter the desired values for each of the parameters.
- □ Splitter: Selecting **Splitter** displays the Splitter Settings dialog. (See Figure 2.27 on page 54.)
- □ Apply Selected Settings to All: Applies the settings selected in the currently selected port to all ports in the list.
- ☐ Import: Loads calibration settings from \*.csv file.
- ☐ Export: Creates a new \*.csv file.
- □ Set as Bootup: Loads these settings into memory; rebooting will automatically load these values.
- ☐ Restore Factory Settings: Restores factory settings.

Teledyne LeCroy **Analyzer Settings** 




Figure 2.26: Advanced Probe Setting dialog for 10 GigE device.




Figure 2.27: Splitter Settings dialog for 10 GigE device.

# **FC Configurations**




Figure 2.28: Device Settings dialog for FC devices.

You can manually calibrate the probe settings. Set the parameters for the following:

- □ Cable Type
- RX Eq DC gain: Select value from the drop-down list.
- □ RX-8G Eq DC gain: Select value from the drop-down list.
- RX Eq Control: Select value from the drop-down list.
- □ RX-8G Eq Control: Select value from the drop-down list.
- □ Advanced: Selecting **Advanced** displays the Advanced Probe Setting dialog with the RX/TX tab selected. (See <u>Figure 2.29</u>.) Enter the desired values for each of the parameters. Select the RX/TX 8G tab (see <u>Figure 2.30</u> on page 56) and enter the desired values for each of the parameters.
- □ Splitter: Selecting **Splitter** displays the Splitter Settings dialog. (See Figure 2.31 on page 57.) Enter the desired values for each of the parameters. Select the 8G tab (see Figure 2.32 on page 57) and enter the desired values for each of the parameters.
- □ Apply Selected Settings to All: Applies the settings selected in the currently selected port to all ports in the list.
- ☐ Import: Loads calibration settings from \*.csv file.
- Export: Creates a new \*.csv file.
- □ Set as Bootup: Loads these settings into memory; rebooting will automatically load these values.
- ☐ Restore Factory Settings: Restores factory settings.

Teledyne LeCroy **Analyzer Settings** 




Figure 2.29: Advanced Probe Setting dialog for FC device - RX/TX tab.




Figure 2.30: Advanced Probe Setting dialog for FC device - RX/TX 8G tab.




Figure 2.31: Splitter Settings dialog for FC device.




Figure 2.32: Splitter Settings dialog for FC device - 8G tab.

Teledyne LeCroy **Analyzer Settings** 

# **External Trigger**

**Note:** This dialog applies to all configurations.

In the Device Settings dialog, selectelect the External Trig Settings tab which shows the External Trig Out Setting and External Trig In Setting as Active, Active Low, or Toggle.




Figure 2.33: External Trigger Settings dialog.

### **External Trig Out Setting**

The Analyzer can send a Low or High external signal any time a trigger occurs.

Select the External Trig Out Setting: High Active, Low Active, or Toggle from High to Low or Low to High once (3.3 V output).

Enter the External TrigOut pulse width.

# **External Trig In Setting**

An external Low or High input signal can cause triggering.

Select the External Trig In Setting: High Active, Low Active, or Toggle from High to Low or Low to High once (3.3 V output).

The nominal External Trigger voltage is 0.818 volts. Trigger In can work with 1 volt to 5 volts input voltage.

#### 2.6.3 **Port Status Pane**

The Port Status pane (see Figure 2.34 on page 59) displays the status of the link on each port (Trigger, Link, Frame and Error). Right-click the pane and select the Reset button to reset the status.



Figure 2.34: Port Status Pane.

## 2.6.4 Session Control Pane

Use the Session Control pane (see Figure 2.35 on page 59) to run and stop a capture. You can also set the idle.



Start/Stop Session Button after recording is started

Figure 2.35: Session Control Pane.

Disabling a port can be used to save recording buffer space. A disabled port can still trigger the analyzer.

Auto Speed is the default port speed selection. It will automatically detect and display the line speed. In rare cases (such as debugging speed negotiation), it might be desired to set the analyzers speed manually. Note, that when the speed is set manually, traffic at different speeds will not be captured correctly.

When "Trace is Not Saved" is displayed, this means that the trace is opened for viewing in Quick View mode, but it has not been saved to disk yet.

# 2.6.5 Recording Settings Pane

Use the Recording Settings (see Figure 2.36 on page 59) pane to select and set the number and size of segments and save a new trace file. (See "Buffer Size and Segments" on page 103.)




Figure 2.36: Recording Settings Pane.

Teledyne LeCroy **Analyzer Settings** 

### **Protocol Error Detection**

Click the Recording Settings icon 1 to display the Recording Settings dialog. It has three tabs. In the GE 10G PE Detection Tab you can select which Protocol Errors the analyzer will show and which will be ignored. Select one or more protocol errors or select the **Check** All box to select all. Enter the Number of Segments in the field.




Figure 2.37: GE 10G PE Detection Tab - Recording Settings Dialog.

In the FC 16G Setting Tab you can select the following:

- □ Speed select 1.0625, 2.125, 4.25. 8.5, 16.0 and Autospeed from the drop-down list. Autospeed is the default.
- □ Disable Descrambling select ports.
- ☐ Training Signal Pack Mode Unpacked and Packed.




Figure 2.38: FC 16G Setting Tab - Recording Settings Dialog.

Teledyne LeCroy **Analyzer Settings** 

> In the FC 16G PE Detection Tab, you can select which Protocol Errors the analyzer will show and which will be ignored. Select one or more protocol errors or select the Check All box to select all. Enter the Number of Segments in the field.




Figure 2.39: FC 16G PE Detection Tab - Recording Settings Dialog.

#### 2.6.6 **Trigger/Filter Settings Pane**

Use the Trigger/Filter Settings pane to select Snapshot or Event Trigger mode and choose the Trigger Filter settings. The default mode is Snapshot. See "Trigger Filter Settings in Easy Mode" on page 64 for more information.

You can configure the following settings from this dialog:

- □ Select **New** from the dropdown menu to create new trigger filter settings. The Trigger Filter Settings dialog displays a name adding a new sequential Trigger Filter Setting. You can change the default name by typing a new name.
- Select Manage from the dropdown menu to manage the trigger filter settings (Choosing the Event Trigger option enables Trigger Position to set it manually. You can set the trigger position in the captured buffer as a percentage of the segment size. Trigger point of 0% means the trigger point will be on the first

# packet in the buffer. (See "Trigger Position" on page 103.)




Figure 2.40: Trigger/Filter Settings Pane.

#### 2.7 Trigger Filter Settings in Easy Mode

Easy mode allows you to operate the analyzer with minimum setup. In this mode, you can perform only a Trigger and Data capture. Use Easy Mode to get a comprehensive overview of your analyzer's capabilities.

The Trigger and Filter settings dialog allows you to set the parameters for triggering on selected triggers and filtering in (including) or filtering out (excluding) selected patterns. The dialog box opens with default settings to capture everything on the bus. The analyzer captures everything immediately without triggering on anything in particular.

#### 2.7.1 **Trigger Tab**

You can drag and drop patterns from the Trigger Library pane into the Active Pane. You can select the pattern and use the Add and Remove arrows to move patterns between the Patterns Library and the Active pane (see Figure 2.41 on page 64). See "Trigger Setup" on page 101. You can copy a frame from the spreadsheet view and paste it in the Active Pane for triggering.




Figure 2.41: Trigger Settings Dialog.

#### **Choose a Parameter**

To choose a parameter for capture from any of these categories, highlight the category in the parameter window and click the +>> button to add the selection. You can also drag and drop a pattern. This opens selection dialogs for each of the categories displaying all of the parameters for that category. All patterns added appear in the Project Overview.

## 2.7.2 Filter Tab

You can drag and drop patterns from the Filter Library pane into the Active Pane. You can select the pattern and use the Add and Remove arrows to move patterns between the Patterns Library and the Active pane (see <u>Figure 2.42</u>). The following filtering options are available:

# **Capture Everything**

Checking this option captures everything on the bus and the Pattern Library is greyed out (see figure below).




Figure 2.42: Filter Dialog.

#### Filter in Selected Patterns

Checking this option includes the selected patterns in the trace capture (see Figure 2.42 on page 65).

#### **Filter Out Selected Patterns**

Checking this option excludes the selected patterns in the trace capture (see Figure 2.42 on page 65).

## **Always Filter Out**

Check one or more option to exclude Idles and or P1 through P8 in the trace capture (see Figure 2.42 on page 65).

**Note:** Capturing a full buffer requires you to capture the traffic with all ports. Using four ports allows you to capture only half the system memory. The size of the system memory is based on the license purchased.

## **Auto Negotiation**

Check this box to always filter out Auto Speed Negotiation traffic. (see Figure 2.42 on page 65).

# **Truncate Payload**

Check this option to truncate payload after x-number of Dword(s) (see Figure 2.42 on page 65).

**Note:** For iSCSI packets, payload truncation may not truncate at the specified value as some packets could come out of sequence.

#### **Run Hardware**

To get an immediate overview of the bus traffic to and from your Analyzer, click the Start Session button.



## **Recording Progress**

The analyzer begins filling the defined memory buffer with traffic on the bus. After the traffic fills the memory buffer, the traffic is uploaded to the viewer. As recording progresses, the Session Controller indicator changes to reflect the recording progress graphically:

A red vertical line illustrates the location of the Trigger Position you selected in Trigger and Filter Settings.

Pre-Trigger progress is indicated by Waiting for Trigger in the field to the left of the Trigger Position.



Figure 2.43: Pre-Trigger.

☐ After the trigger occurs **Recording** is displayed in the field to the left of the Trigger Position indicating the progress of the recording.



Figure 2.44: Post-Trigger.

☐ When recording is complete **Uploading** is displayed indicating the progress of the data upload to the host machine.



Figure 2.45: Uploading.

**Data direction arrows** 

The Recorded Data file appears in the main display window.

Save the file for later use by selecting **File > Save**.

When a captured trace is not saved and the USB cable is removed, the software displays an error message that unsaved traces will be closed. If the user ignores the message, and again plugs in and unplugs the USB cable, the software might get into an unstable state.

When the Ethernet cable is removed, the application detects the event after a delay of approximately 2.5 to 3 minutes. During this delay the device status remains ready and an attempt to capture a trace might result in error messages such as:" PCI configuration failed", or "HAL error". If this occurs, you need to power cycle the analyzer to allow detecting the device in the device list and continue capturing.

**Note:** Spreadsheet View is the default display. However, you can view results in any of the different views by selecting **View** on the menu bar and choosing the desired View. The software remembers the last view (or views combination) used, and will automatically use that next time it is launched.

X	ζ,Υ, <i>Ι</i>	T	Cursors	.						
				Spread Sheet View						
		No.	Start Time	ort	Destination Add	Source Addr.	EtherType	Frame	Frame	Sur
		1	2.322 (us)	<b>⇒</b> P5	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x01:Solic. Data		
		2	2.322 (us)	<b>⇔</b> P6	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x01:Solic. Data	
7		3	2.322 (us)	<b>⇒</b> P7	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x01:Solic. Data		
×D		4	2.322 (us)	<b>⇔</b> P8	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x01:Solic. Data	
		5	2.550 (us)	<b>⇒</b> P5				67 - Idle		Count=67
		6	2.550 (us)	<b>⇔</b> P6					67 - Idle	Count=67
		7	2.550 (us)	<b>⇒</b> P7				67 - Idle		Count=67
		8	2.550 (us)	<b>⇔</b> P8					67 - Idle	Count=67
YD		9	3.126 (us)	<b>⇒</b> P5	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x07:Cmd Status		0x00:Good
		10	3.126 (us)	<b>⇔</b> P6	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x07:Cmd Status	0x00:Good
		11	3.126 (us)	<b>⇒</b> P7	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x07:Cmd Status		0x00:Good
		12	3.126 (us)	<b>₽8</b>	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x07:Cmd Status	0x00:Good
		13	3.228 (us)	<b>⇒</b> P5				67 - Idle		Count=67
		14	3.228 (us)	<b>⇔</b> P6					67 - Idle	Count=67
		15	3.228 (us)	<b>⇒</b> P7				67 - Idle		Count=67
		16	3.228 (us)	<b>⇔</b> P8					67 - Idle	Count=67
		17	4.062 (us)	<b>⇒</b> P5	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC	0x22:ELS_Request		0x13:REC
		18	4.062 (us)	<b>⇔</b> P6	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC		0x22:ELS_Request	0x13:REC
		19	4.062 (us)	⇒P7	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC	0x22:ELS_Request		0x13:REC
		20	4.062 (us)	<b>⇔</b> P8	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC		0x22:ELS_Request	0x13:REC
		21	4.158 (us)	<b>⇒</b> P5				67 - Idle		Count=67
		22	4.158 (us)	<b>⇔</b> P6					67 - Idle	Count=67
4										

Figure 2.46: Typical Spreadsheet View Results Display.

The results display shows each transaction for every layer identified in a different color and the data direction identified with data direction arrows. Upstream traffic has a solid yellow arrow from right to left: ←. Downstream traffic has a solid grey arrow left to right:  $\Rightarrow$ .

You can configure the viewer display for test and viewing preferences (see "Preferences" on page 149 for details about configuring the viewer display).

The Analysis Project dialog offers you a comprehensive set of choices to create a trigger and capture project satisfying some specific need. You can set the Analyzer to:

- □ Capture specific patterns (see "Patterns and Data Capture Setup" on page 71).
- □ Capture different patterns pre- and post-trigger (see "Patterns and Data Capture Setup" on page 71).
- □ Exclude parameters from capture (see "Patterns and Data Capture Setup" on page 71).
- ☐ Trigger on a pattern or sequence of patterns (see "Trigger Setup" on page 101).
- □ Configure trace capture memory
- □ Select file to save trace capture in memory

## Saving a Trace Capture

You can save a Trace Capture for review at a later time using the **Save As** dialog.




Figure 2.47: Save As Dialog.

You can limit the range of the saved file. You can save:

□ All Packets

- □ A range between selected cursors
- ☐ A range between selected level of decoding. The levels allowed are dependent on the traffic in the trace. A trace with only Switch traffic might have the following levels available: ELS Cmd, Frame, GS Cmd, Sequence and SW Cmd, whereas a read-write trace might have Frame, SCSI Cmd and Sequence available.

**Only Save Displayed Events:** Click the checkbox to save only the Filtered in data in the trace.

# **Exporting a Trace Capture**

You can export a Trace Capture by using the **Export** menu Option. Click **File > Export** and select from the three options.

You can:

- Export to Excel
- Export to Text
- Export and Open with Wireshark




Figure 2.48: Export Dialog.

You can limit the range of the saved file. You can save:

- □ All Packets
- □ A range between selected cursors
- □ A range between selected level of decoding. The levels allowed are dependent on the traffic in the trace.

## **Project File Types**

Projects have the following file types:

- \*.gep Protocol Analyzer/Capture Project/Viewer file
- \*.get Trace file
- \*.xml Workspace file in Preferences

## **Example Projects**

The Analyzer includes example projects that you can use to perform an immediate analysis without any setup.

The Analyzer system software has a pre-defined folder (directory) structure for storing all files. All example files are in the Examples folder under the SierraNet M408 Analyzer folder.

It is strongly recommended that you open some example files to see types of projects that you can create.

## Run an Example Analysis Project

To run an example project:

- 1. Select File > Open.
  - For Windows XP use ROOT:\Program Files\LeCroy\Ethernet Protocol Suite For Windows Server 2003 (32 bit), Windows Server 2012 (64 bit), Windows 7 or Windows 8 - ROOT:\Users\Public\Public Documents\LeCroy\Ethernet Protocol Suite
- 2. Locate example analysis projects by looking in the Examples folder. Traces are available and Traces. Click **Data > Examples > Traces**.
- 3. In the Traces folder, choose an example \*.get file and click Open to display the example project dialog.




Figure 2.49: Open File Dialog.

4. Click the **Open** button to execute the pre-defined trace.

No. Start Time Port Destination Add Source Addr. FtherType
1 2.322 (us) ⇒P5 FCFCFC6A0300 FCFCFC6A0600 8906:FC... Summary 2.322 (us) 2.322 (us) 2.322 (us) FCFCFC6A0300 FCFCFC6A0600 0x8906:FC...
FCFCFC6A0300 FCFCFC6A0600 0x8906:FC... 2.550 (us) PS
2.550 (us) PS
2.550 (us) PP
2.550 (us) PP
2.550 (us) PP
3.126 (us) PP
3.126 (us) PP Count=67 Count=67 Count=67 67 - Idle 67 - Idle 67 - Idle 67 - Idle Count=67 0x00:Good FCFCFC6A0300 FCFCFC6A0600 0x8906:FC... 0x07:Cmd Stat 3.126 (us) →P6
→P7
→P8
→P5 FCFCFC6A0300 FCFCFC6A0600 FCFCFC6A0600 FCFCFC6A0600 3.126 (us) 3.228 (us) Count=67 13 3.228 (us) 14 3.228 (us) 15 3.228 (us) 16 3.228 (us) 17 4.062 (us) 18 4.062 (us) 19 4.062 (us) 67 - Idle <=P6 ⇒P7 67 - Idle Ox13:REC ⇒P8
⇒P5
⇒P6
⇒P7
⇒P8 0x22:ELS FCFCFC6A0600 FCFCFC6A0300 0x8906:FC... FCFCFC6A0600 FCFCFC6A0300 0x8906:FC FCFCFC6A0600 FCFCFC6A0300 0x8906:FC 0x13:REC Count=67 ngth: 1600 Destination Add ECECEC6A0300 FCFCFC6A0600 Source Add. EtherType/Len \_\_\_\_ All Reports

5. After the project runs, you see an analyzer trace capture display (see Figure 2.50 on page 71).

Figure 2.50: Analyzer Trace Capture Display.

For details about the results display, see "Display Manipulation" on page 113 and see "Preferences" on page 149.

## 2.7.3 Patterns and Data Capture Setup

You can refine data capture by choosing **Pattern** and then selecting specific patterns for capture. Additionally, you can define a different set of patterns to capture after trigger.

The Trigger and Filter settings dialog allows you to set the parameters for triggering on selected triggers and filtering in (including) or filtering out (excluding) selected patterns. Refer to "Trigger Filter Settings in Easy Mode" on page 64.

## 2.7.4 Pre- and Post Trigger Data Capture

Move the **Trigger Position** slider button (see Figure 2.40 on page 63) to define one set of patterns for capture prior to the occurrence of a trigger (left of the slider) and another set of patterns for capture after the occurrence of a trigger (right of the slider). The selection and setup procedure is the same for both Pre-Trigger capture and Post-Trigger capture. (see "Trigger Setup" on page 101).

## 2.7.5 Triggering/Filtering Patterns (Easy Mode)

The application provides User Patterns and a library of Preset patterns.

## **User Patterns**

Recently used patterns are stored under the Most Recent user pattern.

Create a New User Group by right-clicking and selecting New Group as shown below. Key in the name of the new group.




Figure 2.51: Creating a New User Group.

#### 2.7.6 Timers/External

#### **Timer**

You can set a timer independently of any other trigger selection, to cause an unconditional trigger after a set time.

Double-click **Timer** in the Pattern window to open the Add Timer Pattern dialog.

Check a Time Unit, enter the Timer Value, and click OK.




Figure 2.52: Timer Pattern Dialog.

**Note:** The timer resolution is limited to one DWORD. The minimum value is 12-13 DWORD.

# **External Trigger**

Use this event to wait for a signal on the analyzers external trigger input. Refer to "External Trigger" on page 58 for details on configuring the external trigger input.

# 2.7.7 Pattern Editing Conventions

When entering values in patterns the following conventions apply:

In Binary, 'X' means one bit which is "don't care" and the value can be either 1 or 0. Below are some examples in binary and their meanings:

"X10": The value length is 3 bits and from right to left, the first and second bits have specific values and the third one is "don't care".

"XXXXXXX1": The value length is 8 bits and from right to left, the first bit has a specific value and the rest are "don't care".

In Hexadecimal 'X' means 4 bits in which all four are "don't care". In hexadecimal '?' means either one of the bits 1, 2, 3 or 4 bits is "don't care" and it is not clear which bit is

"don't care" and which ones have specific value. Some examples are given in the table below.

Hexadecimal Value	Length in bits	Equivalent Value in Binary
"X1"	8 bits	"XXXX0001"
"X?"	8 bits	"XXXXXX10"
"?X"	8 bits	"110XXXXX"
"?"	2 bits	"XX"
"?"	3 bits	"11X"
"7"	3 bits	"111"
"7?"	8 bits	"01110XX1"

If VI READ RQST is selected, the value for the "Device HDR" field will be "10" in binary format as this field is a two-bits field. This field is the last field in the "DF CTL" field which is an 8 bits field. For this specific frame, the value of "DF CTL" will be "XXXXXX10" in binary format and "X?" in hexadecimal format according to the conventions above.

#### 2.7.8 **Ethernet Patterns**

#### **Basic**

## Loss of Sync

Double-click Loss of Sync to open the Loss of Sync Pattern dialog.




Figure 2.53: Loss of Sync Pattern Dialog

This event detects loss of sync on the Ethernet physical layer receiver. Enter the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

## **Symbol**

Double-click **Symbol** to open the Symbol Pattern dialog.




Figure 2.54: Symbol Pattern Dialog

Enter the values for the Sync Header, Order Set and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

Two different order sets can exist in one 64 bits payload of a 66 bits block. The six examples of a remote and local fault given below demonstrate how to manually enter ordered set triggers.

0x010000001000055 -> local fault-local fault

0x00000000100004b -> local fault-idle

0x010000000000002D -> idle-local fault

0x0200000002000055 -> remote fault-remote fault

0x000000000200004b -> remote fault-idle

0x020000000000002D -> idle-remote fault

## **Auto Negotiation**

Double-click **Auto Negotiation** to open the Auto Negotiation Pattern dialog.




Figure 2.55: Auto Negotiation Pattern Dialog

Enter the values for the Data, Code Word, Manchester and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

## **IPG**

Double-click IPG to open the IPG dialog.




Figure 2.56: IPG Pattern Dialog

Enter the IPG Length from the drop-down list and Bytes values and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

## **FCoE Patterns**

#### **Basic**

#### **Basic Link Service**

For any Ethernet pattern, double-click the pattern name, for example, double-click **Basic Link Service** to open the Basic Link Service Pattern dialog.

**Note:** Some screen captures for the Ethernet patterns are similar to the screen capture shown below.




Figure 2.57: Basic Link Service Pattern Dialog

Enter the values for the Ethernet header, FCoE header, Frame header and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

Check the Trigger on given pattern with variable header length box to automatically adjust the offset, if optional headers like VLAN tag, VNTag, etc. are present. Uncheck it, to trigger for a pattern at a specific offset from the start of the frame.

**Note:** Some patterns have additional options to select from drop-drown lists as shown in the figure above.

## **Link Control Frame**

For any FCoE pattern, double-click the pattern name, for example, double-click Basic Link **Service** to open the Basic Link Service Pattern dialog.

**Note:** Some screen captures for the FCoE patterns are similar to the screen capture shown below.




Figure 2.58: Link Control Frame Pattern Dialog

Enter the values for the Ethernet header, FCoE header, Frame header and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

Check the **Trigger on given pattern with variable header length** box to automatically adjust the offset, if optional headers like VLAN tag, VNTag, etc. are present. Uncheck it, to trigger for a pattern at a specific offset from the start of the frame.

The following additional Ethernet patterns are available:

#### **FCP Patterns**

#### Frame Information Unit

#### SCSI

## **Any SCSI Command**

- 6-Byte Any SCSI Cmd
- 10-Byte Any SCSI Cmd
- 12-Byte Any SCSI Cmd
- 16-Byte Any SCSI Cmd
- Long LBA 16-Byte Any SCSI Cmd
- Variable Length Any SCSI Cmd
- Variable Length for Long LBA 32-Byte Any SCSI Cmd
- □ SPC4
- □ SBC3
- MMC6
- □ SMC2
- □ SSC2
- □ OSD2

□ ADC3

**FCP Task Management** 

**ELS Patterns** 

**ELS Request** 

**ELS Reply** 

**GS Patterns** 

**Generic Link Service-Request** 

# **GS Reply**

- ☐ GS RJT
- GS Accept
  - FC-SW-5
  - Event Service
  - Key Distribution Service
  - Alias Service
  - Management Service
    - **Fabric Configuration Service**
    - Unzoned Name Server
    - Fabric Zone Server
    - Reserved for Performance Server
    - Security Policy Server
    - Security Information Server
    - Fabric Device Management Server
  - Time Service
  - Directory Service -
    - Name Server
    - Directory Service FC-4 Specific Servers

## **SW Patterns**

**SW Request** 

**SW Reply** 

**FICON Patterns** 

**FCAE Patterns** 

**FCAE ASM** 

**FCAE-1553** 

**FCVI Patterns** 

**FCAV Patterns** 

**VSAN Patterns** 

(all FC patterns listed above are available under VSAN as well)

#### **FIP Patterns**

For any FIP pattern, double-click the pattern name, for example, double-click **Discovery Solicitation from ENode** to open the dialog.

**Note:** All the screen captures for the FIP patterns are similar to the screen capture shown below.




Figure 2.59: FIP Discovery Solicitation from ENode Pattern Dialog

Enter the values for the Ether header, FIP Header and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

The following FIP patterns are available:

- Discovery Solicitation from ENode
- Discovery Solicitation from FCF
- Discovery Advertisement
- □ FIP FLOGI Request
- ☐ FIP FLOGI LS ACC
- □ FIP FLOGI LS RJT
- □ FIP NPIV FDISC Request
- □ FIP NPIV FDISC LS ACC
- □ FIP NPIV FDISC LS RJT
- □ FIP Fabric LOGO
- □ FIP Fabric LOGO LS ACC
- ☐ FIP Fabric LOGO LS RJT
- ☐ FIP ELP Request
- □ FIP ELP SW ACC
- ☐ FIP ELP SW RJT
- □ FIP Keep Alive

- ☐ FIP Clear Virtual Links-5DWORD Descriptor
- ☐ FIP VLAN Request-2DWORD Descriptor
- □ FIP VLAN Notification

#### **MPCP Pattern**

Double-click Multi control Protocol Frame to open the dialog.




Figure 2.60: Multi control Protocol Frame Pattern Dialog

Enter the values for the Ether header and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

## **Address Resolution Protocol Pattern**

Double-click **Address Resolution Protocol** to open the dialog.




Figure 2.61: ARP Frame Dialog

Enter the values for the Ether header, ARP Packet and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

## Link Layer Discovery Protocol Pattern

Double-click **LLDP Frame** to open the dialog.




Figure 2.62: LLDP Frame Dialog

Enter the values for the Ether header, LLDPDU TLV and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

#### **Internet Protocol Pattern**

Double-click Any IP Frame to open the dialog.




Figure 2.63: IP Frame Dialog

Enter the values for the Ether header, IP Header and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

Other Internet Protocol patterns available are:

- □ IP Frame (ICMP)
- □ IP Frame (IGMP)
- □ IP Frame (IPV6)
- □ IP Frame (OSPF)
- □ IP Frame (AH)
- IP Frame (ESP)
- □ IP Frame (PIM)
- □ IP Frame (UDP)
- □ IP Frame (TCP)

#### iSCSI Pattern

## **Initiator PDU**

Double-click iSCSI Data-Out to open the dialog.




Figure 2.64: iSCSI Data-Out Dialog

Enter the values for the Ether header, IP Header and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

Other ISCSI patterns available are:

- □ iSCSI Login Request
- □ iSCSI Logout Request
- □ iSCSI NOP-Out
- □ iSCSI SNACK Request
- □ iSCSI Task Mgmt Request
- □ iSCSI Text Request

## **Target PDU**

The dialogs are similar to the Initiator PDU above. The patterns available are:

- □ iSCSI Asynchronous Message
- □ iSCSI Response
- □ iSCSI Data-In
- □ iSCSI Login Response
- □ iSCSI Logout Response
- □ iSCSI Nop-In
- □ iSCSI Ready to Transfer
- □ iSCSI Reject
- □ iSCSI Task Mgmt Request
- □ iSCSI Text Request

#### **ISCSI Cmd**

#### **Any SCSI Command**

Double-click 6-Byte Any SCSI Cmd to open the dialog.




Figure 2.65: 6-Byte Any SCSI Cmd Dialog

Enter the values for the Ether header, IP Header and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

Other ISCSI patterns available are:

- 10-Byte Any SCSI Cmd
- 12-Byte Any SCSI Cmd
- 16-Byte Any SCSI Cmd
- Long LBA16-Byte Any SCSI Cmd
- Variable Length Any SCSI Cmd
- Variable Length For Long LBA 32-Byte Any SCSI Cmd
- □ SPC4
- □ SBC3
- MMC6
- □ SMC2
- □ SSC2
- □ OSD2
- □ ADC3

#### **iWARP Patterns**

You may set patterns for the following iWARP RDMA operations:

Write

**Read Request** 

**Read Response** 

Send

Send with Invalidate

Send with SE

Send with SE and Invalidate

**Terminate** 

#### **VLAN Patterns**

All Ethernet Patterns are available as VLAN Patterns as well. The only difference is that the Ethernet Type of the Ethernet header will be preset to "VLAN", and you should specify the VLAN id value in the VLAN Tag header.

#### **VXLAN Patterns**

All Ethernet Patterns are available as VXLAN Patterns as well. The only difference is that the frame will be preset as an IP/UDP frame with the UDP destination port set to "VXLAN", and you should specify the VXLAN Network Id in the VXLAN header.

#### ISL Patterns

#### **FCoE**

All the ISL FCoE patterns are similar to Ethernet patterns. Refer to "FCoE Patterns" on page 77.

#### **FIP**

All the ISL FIP patterns are similar to FIP patterns. Refer to "FIP Patterns" on page 81.

#### **MPCP**

All the ISL MPCP patterns are similar to MPCP patterns. Refer to "MPCP Pattern" on page 82.

#### **Address Resolution Protocol**

The ISL Address Resolution Protocol pattern is similar to Address Resolution Protocol pattern. Refer to "Address Resolution Protocol Pattern" on page 82.

## **Link Layer Discovery Protocol**

The ISL Link Layer Discovery Protocol pattern is similar to Link Layer Discovery Protocol pattern. Refer to "Link Layer Discovery Protocol Pattern" on page 83.

## **ISL Internet Protocol**

All the ISL Internet Protocol patterns are similar to Internet Protocol patterns. Refer to "Internet Protocol Pattern" on page 84.

#### iSCSI Pattern

All the ISL ISCSI patterns are similar to ISCSI patterns. Refer to "iSCSI Pattern" on page 84.

## **Initiator PDU**

See "Initiator PDU" on page 84.

## **Target PDU**

See "Target PDU" on page 85.

## iSCSI Cmd

See "ISCSI Cmd" on page 86.

**Note:** For all ISL patterns enter a value for the ISL Header.

## InfiniBand Over Ethernet (IBXoE)

See "InfiniBand Over Ethernet (IBXoE)" on page 89.

## **CN Tag Patterns**

All the CN Tag patterns are similar to Ethernet patterns. Refer to "FCoE Patterns" on page 77.

**Note:** For all CN Tag patterns enter a value for CN Tag.

# **VN Tag Patterns**

All the VN Tag patterns are similar to Ethernet patterns. Refer to "FCoE Patterns" on page 77.

**Note:** For all VN Tag patterns enter a value for VN Tag.

#### LLC

#### LLC-IEEE802.1D Frame

Double-click **LLC-IEEE802.1D** Frame to open the dialog.




Figure 2.66: LLC-IEEE802.1D Dialog

Enter the values for the Ethernet, LLC Header, Spanning Tree Header, GARP Header and select an option from the DSAP and SSAP pull -down menus. Enter the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

Other LLC-IEEE802.1D patterns available are:

- Bridge Protocol Data Unit (BPDU)
- Configuration BPDUs
- Multiple Spanning Tree BPDUs (MSTP)
- Rapid Spanning Tree BPDUs (RSTP)
- Topology Change Notification BPDU (TCNP)
- ☐ GARP Multicast Registration Protocol (GMRP)
- ☐ GARP VLAN Registration Protocol (GVRP)
- ☐ Generic Attribute Registration Protocol (GARP)

## InfiniBand Over Ethernet (IBXoE)

Double-click InfiniBand Over Ethernet (IBXoE) to open the IBXoE Frame dialog.




Figure 2.67: IBXoE Frame Dialog

Enter the values for the Ethernet header, Global Routing Header (GRH), Base transport header (BTH) and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

## **Trill Frame**

Double-click **Trill Frame** to open the dialog.




Figure 2.68: Trill Frame Dialog

Enter the values for the Ethernet header, Trill and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

## **Protocol Errors**

Double-click **Protocol Errors** to open the dialog.




Figure 2.69: Protocol Errors Dialog

Select the desired protocol errors or click on the **Check All** box to select all the errors. Enter the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

# **Any Ethernet Frame**

Double-click **Any Ethernet Frame** to open the dialog.




Figure 2.70: Any Ethernet Frame Dialog

Enter the values for the Ether header and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

#### FC Patterns (Easy Mode) 2.7.9

## **Basic Patterns**

## Connect/Disconnect

Double-click Connect/Disconnect to open the Connect/Disconnect dialog.




Figure 2.71: Connect/Disconnect Dialog

Select Connect/Disconnect and the count of the expected number of occurrences. Check the Check All box to select ports P1 through P8 or individually select ports.

## **Ordered Set**

Double-click Ordered Set to open the Order Set dialog.




Figure 2.72: Order Set Pattern Dialog

Select the values for the Ordered Set from the drop-down list. Select Frame Delimiters, Primitive Signals and Primitive Sequences as applicable. Check the **Check All** box to select ports P1 through P8 or individually select ports.

# Symbol 8 Bits

Double-click Symbol 8 bits to open the Symbol 8G Pattern dialog.




Figure 2.73: Symbol 8G Pattern Dialog

Check K Symbol or D Symbol as applicable. Select the value for K Symbol from the dropdown list or enter the value for D Symbol. Check the Check All box to select ports P1 through P8 or individually select ports.

## Symbol 66 Bits

Double-click **Symbol 66 bits** to open the Symbol 66 Bits Pattern dialog.




Figure 2.74: Symbol 66 Bits Pattern Dialog

Enter the values for the Sync Header, Symbol and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

Two different order sets can exist in one 64 bits payload of a 66 bits block. The six examples of a remote and local fault given below demonstrate how to manually enter ordered set triggers.

0x010000001000055 -> local fault-local fault

0x00000000100004b -> local fault-idle

0x010000000000002D -> idle-local fault

0x0200000002000055 -> remote fault-remote fault

0x000000000200004b -> remote fault-idle

0x020000000000002D -> idle-remote fault

# **Training Sequence**

Double-click **Training Sequence** to open the Training Sequence dialog.




Figure 2.75: Training Sequence Dialog

Enter the values for Control and Status Fields and the count of the expected number of occurrences.

Check the Check All box to select ports P1 through P8 or individually select ports.

#### **Basic Link Service**

Double-click Basic Link Service to open the Basic Link Service Pattern dialog.

For any FC pattern, double-click the pattern name, for example, double-click **Basic Link Service** to open the Basic Link Service Pattern dialog.

**Note:** Some screen captures for the FC patterns are similar to the screen capture shown below.




Figure 2.76: Basic Link Service Pattern Dialog

Enter the values for the Frame Header, CS\_CTL, F\_CTL and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports. You can specify the type of SOF to match on for the frame by selecting it from the SOF drop-down list.

**Note:** Some patterns have additional options to select from drop-drown lists as shown in the figure above.

#### **Link Control Frame**

Double-click **Link Control Frame** in the Pattern window to open the Add Link Control Frame Pattern dialog.




Figure 2.77: Link Control Frame Pattern Dialog

Enter the values for the Frame Header, CS\_CTL, F\_CTL and the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P4 or individually select ports. You can specify the type of SOF to match on for the frame by selecting it from the SOF drop-down list.

The following additional FC patterns are available:

#### Other FC Patterns

The same pattern types listed for FCoE are also available for native FC as well. Refer to "FCoE Patterns" on page 77 above.

## **FC Protocol Errors**

Double-click **Protocol Errors** to open the dialog.




Figure 2.78: Protocol Errors Dialog

Select the desired protocol errors or click on the **Check All** box to select all the errors. Enter the count of the expected number of occurrences. Check the **Check All** box to select ports P1 through P8 or individually select ports.

### 2.7.10 Trigger Setup

You can specify when the analyzer triggers. Two trigger modes are available: The default mode is **Snapshot** or you can select **Event Trigger**.

When data capture starts with **Don't care (Snapshot)** selected, the analyzer triggers on the first data pattern on the bus.

Starting a data capture with **Pattern** selected triggers when specific pattern(s) are detected in the captured data stream. The following three ways can trigger the analyzer with **Pattern** selected:

- ☐ Trigger on any pattern (Any Trigger Mode)
- □ External Trigger
- ☐ Trigger on a sequence of patterns (Sequential Trigger Mode)

### **Snapshot Mode**

To trigger immediately on any pattern, check the **Snapshot** button.



Figure 2.79: Default Trigger Snapshot Mode Selected

### **Manual Trigger**

In the **Manual Trigger** mode, the analyzer captures bus traffic continually from when you use the Manual Trigger until you click the **Stop Hardware** button (on the analyzer toolbar), which triggers the analyzer.

### **Timer**

See "Timer" on page 72 for more information.

### **Defining Patterns**

The definition of patterns for the sequential trigger mode is identical to the Pattern mode, with the following exception:

In sequential triggering mode, all the pattern dialogs display the option for setting to count the expected number of occurrences on each link. This allows you to specify the number of times that the pattern must occur before triggering or proceeding in the trigger sequence.




Figure 2.80: Number of Occurrences

**Note:** The Events on each link are counted independently, causing a trigger whenever the number of occurrences on any link equals the specified value.

### **Pre-Trigger**

You can set the amount of data to capture before and after the trigger, as a percentage of pre-trigger, between 0% and 100%. Position the pre-trigger slider to a percentage. This feature allows the evaluation of bus activity leading up to and after the triggering Event. Figure 2.81: illustrates the operation of pre-trigger in data memory.

Pre-trigger data is capture of the specified percentage of data prior to the triggering Event. It cannot be guaranteed and may be 0. This can occur when the triggering Event occurs before storing the required amount of pre-trigger Event data. In such a case, the data display shows fewer than the specified data points prior to the triggering Event.

# PRE TRIGGER - ALL % PRE TRIGGER DATA TRIGGERING EVENT - ALL SPECIFIED POST TRIGGER DATA ALL SPECIFIED POST TRIGGER DATA

Figure 2.81: Pre-Trigger Example, 20% Pre-Trigger

### **Buffer Size and Segments**

The Analyzer Settings panel has the Recording Buffer pane where you can set Number of Segments and the Segment Size. The defaults are one segment of 25MB. The total size used is automatically displayed for you. Setting multiple segments will allow to trigger on the first occurrence of the trigger condition, fill up the first segment, then automatically re-arm the trigger and repeat the remaining number of segments specified. You can use the slider button or click the up or down arrow to change memory usage for recording trace data. (Minimum size of memory is 1MB. Maximum size of memory is dependent on the hardware.) (See Figure 2.36 on page 59.) Enter an integer **Num. of Segment**, from 1 to 32, then enter an integer **Segment Size** in kilobytes, up to the memory size in megabytes divided by the number of segments. The default 1.

The New Project dialog opens with default settings to capture Everything on the bus and to Trigger On on Snapshot. (The analyzer captures everything immediately without triggering on anything in particular.)

Each time a trigger condition occurs, the system records a new segment. You can use a Snapshot or Pattern trigger, but not Manual Trigger. As the same trigger automatically repeats, the system makes the number of segments that you entered.

**Note:** If the size of a data packet exceeds the buffer memory allocation, the project runs, but no data capture occurs. You must increase buffer memory size to a value greater than the packet size.

### **Trigger Position**

You can set the trigger position in the captured buffer as a percentage of the segment size. Trigger point of 0% means the trigger point will be on the first packet in the buffer.

To upload segments automatically for display as the system creates them, do not select the checkbox. This defaults to 1, which defines the amount of data to capture before and after the triggering Event. You can change this percentage by dragging the slider.

In certain cases, when one port is recording traffic and filling up the memory much faster than another port, you might see traffic appearing only on one port for a while, and the

other port's traffic will only appear later. This occurs as a function of the trigger position, and is normal, expected behavior of the analyzer.

To upload segments manually in the Segment Manager, select the **Use upload manager** (no automatic upload) checkbox. To upload segments automatically for display as the system creates them, do not select the checkbox.

### 2.8 Advanced Mode (User-Defined)

Advanced Mode expands Analysis capability by allowing you to program complex triggering and data capture projects.

The Advanced Mode is a state machine. You can program each state individually to:

- ☐ Trigger on a different Event or trigger unconditionally.
- □ Capture Everything, Nothing, or a user-defined pattern.
- □ Include up to three ELSE IF statements, allowing a jump to any other state based on a user definition.
- □ Use up to three timers, which you can set to a maximum value of 4294900 ms or over one hour. If you enter a value larger than 42494900ms a warning pop-up displays: Invalid value! Please enter a value between 0 and 4294900. You can set a timer in the state or continue the timer set in the previous state.
- □ Output an external trigger High or Low.

**Note:** In Advanced Mode, Events on each link are counted independently. A condition is met if the number of Events on a link equals the defined occurrence.

### 2.8.1 Working in Advanced Mode

To start working in the Advanced Mode, click the **Switch to Advanced** mode button in the Trigger Filter Settings as shown in <u>Figure 2.82</u>.



You can:

- Display the state definition
- □ Set Output Trigger level
- Select up to three timers
- □ Define the If condition and up to three Else If conditions
- ☐ Set number of occurrences before trigger
- Set captured data
- Set excluded data
- □ Go to next state
- Add state
- Choose link for Sequencer setup




Figure 2.82: State Programming Dialog

### **Add State**

Click on the Add State button to add a State to the Sequencer. A State will be added below the last State.

### **Insert State**

Select a State and click on the Insert State button to insert a State. A State will be inserted after a selected State.

### **Delete State**

Select a State and click on the Delete State Delete State button to delete a State.

### **Copy/Cut and Paste States**

You can copy and paste states within a Sequence.

- 1. Right-click in the blue title area of the State you want to copy and select Copy State (or Cut State if applicable).
- 2. Right-click in the white workspace of the desired target Sequence and select Paste State.

### Copy/Cut and Paste Conditions

You can copy and paste Conditions within and between States.

- 1. Right-click in the empty yellow space of the Condition you want to copy and select Copy Condition (or Cut Condition if applicable).
- 2. Right-click in the gray placeholder area (i.e. in the area that says "Drag an event here....") of the desired target State and select Paste.

### **Copy/Cut and Paste Events**

You can copy and paste Events within and between States.

- 1. Right-click on the Event you want to copy and select Copy (or Cut if applicable).
- 2. Right-click in the empty yellow space of the desired target Condition or in the gray placeholder area (i.e. in the area that says "Drag an event here....") of the desired target State and select Paste.

### Adding Patterns to a State

- Drag a pattern from the list of patterns displayed in the left panel and drop it in the State to add it. The application displays Drag an event or Drag an event here to add another condition, to indicate the location to drop events in a State. Drag/Drop events between states will copy/paste the event.
- 2. Define each selected pattern in the same way as in Easy Mode, as described in "Triggering/Filtering Patterns (Easy Mode)" on page 71. To use a timer, define it first.

**Note:** You can copy a frame from the spreadsheet view and paste it for triggering.

**Note:** You can set a timer for any If or Else If condition.

3. Enter a value for the number of occurrences before trigger in the **Count** field, up to a maximum of 65535 occurrences.

### **Setting Triggers**

The trigger icon toggles between a blue outline and no outline, activating and deactivating it. Click the Trigger icon to activate the trigger. Once the trigger is activated the no outline trigger icon turns to blue outline.

### **External Output Trigger**

The external output trigger icon toggles between a blue outline and no outline, activating and deactivating it. The External Output Trigger icon (no outline) indicates there is no change. Click to activate the trigger. Once the trigger is activated the icon has a blue outline indicating it is active.




Figure 2.83: Setting Triggers

### **Setting State Transitions**

Click on the State Transition icon to change the state to transition to. Left-click for menu options to display as shown in the following screen capture and select the state to transition to. To remove the state transition select **No Jump.** 




Figure 2.84: State Transition

### **Settings Capture Filters**

□ Choose a capture option by clicking on the Capture Everything ☑ icon shown in the figure below. The Filter Settings dialog displays (see Figure 2.86 on page 110.)




Figure 2.85: Capture Everything




Figure 2.86: Filter Settings Dialog

- ☐ If you choose Capture Everything, you can select Idles for exclusion.
- □ Select Filter In Selected Patterns or Filter Out Selected Patterns to select patterns for inclusion or exclusion (see <u>Figure 2.86</u>). See "Triggering/Filtering Patterns (Easy Mode)" on page 71.
- □ Choose pattern(s) and click the > button to add them for capture or exclusion. You define each pattern the same way as in Easy mode ("Triggering/Filtering Patterns (Easy Mode)" on page 71).
- □ Click Capture Nothing to run the trace without capturing anything.
- ☐ Click on the checkboxes to Always Filter Out Idles, RRDY or ports 1 through 8.
- □ Select ARBFF, NOS, VC\_RDY, Before ports are up, or Training Pattern. ARBff, NOS and VC\_RDY are ordered sets that show up frequently and are of little use in most cases, and selecting allows you to specifically filter them out. Before ports are up will filter everything before the ports are up, to save buffer space and allow to concentrate on the parts important to the user. Training Pattern will similarly filter out all Training Patterns
- □ Check the Truncate Payload option to truncate payload after x-number of Dword(s) 0 bytes. (see Figure 2.86).

### **Multi-Link Triggering**

You can set different triggering for each link. To set different trigger conditions for a link, check the **Multi Sequencer** checkbox and select the link for setup from the Port tabs. When you select this option, you can define a sequencer per link (pair port). These sequencers are independent from each other and will be run separately on each link.




Figure 2.87: Multi-Link Triggering Setup

### **Set Timers**

You can set and use up to three timers for triggering. You can set each timer for each state or continue from a timer set in the previous state. The timer defined for a particular state starts when entering that state. To set timers, click the Timer icon in each state and define each of the timers in the Timer Setting dialog.




Figure 2.88: Timer Settings Dialog

Three timers are available. You have to set and start each timer in order to continue the next timer. For example, you have to start Timer 1, continue it, then set Timer 2 in order to continue it. It will not allow you to continue Timer 2 until you first set it.

# **Chapter 3**

## **Display Manipulation**

### 3.1 Viewer Display

After data is captured (Recorded), the Viewer displays the captured data and saves it as a trace file with a .get file extension.

Note that statistics are available only after the whole trace has uploaded. The data is available for analysis in various views which are explained in this section.

Click on **Analysis** in the Analyzer main menu options to enable and disable different trace views.

You can set decoding assignments by selecting **Analysis > Decoding Assignments...** The following Decoding Assignments dialog displays. For additional information see "Decoding Assignments" on page 117.




Figure 3.1: Decoding Assignments.

Teledyne LeCroy Viewer Display

The following views are available for analysis (refer to the following screen captures):

- Spreadsheet View
- □ Frame Inspector
- □ Traffic Summary
- Data View

No.	Start Time	Port	Destination Addr.	Source Addr.	EtherType	Frame	Frame	
1	2.322 (us)	⇒P5	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x01:Solic. Data		
2	2.322 (us)	⇔P6	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x01:Solic. Data	
3	2.322 (us)	<b>⇒</b> P7	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x01:Solic. Data		
4	2.322 (us)	⇔P8	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x01:Solic. Data	
5	2.550 (us)	⇒P5				67 - Idle		Count=67
6	2.550 (us)	<b>⇔</b> P6					67 - Idle	Count=67
7	2.550 (us)	⇒P7				67 - Idle		Count=67
8	2.550 (us)	<b>⇔</b> P8					67 - Idle	Count=67
9	3.126 (us)	⇒P5	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x07:Cmd Status		0x00:Good
10	3.126 (us)	<b>⇔</b> P6	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x07:Cmd Status	0x00:Good
11	3.126 (us)	⇒P7	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC	0x07:Cmd Status		0x00:Good
12	3.126 (us)	⇔P8	FCFCFC6A0300	FCFCFC6A0600	0x8906:FC		0x07:Cmd Status	0x00:Good
13	3.228 (us)	⇒P5				67 - Idle		Count=67
14	3.228 (us)	<b>⇔</b> P6					67 - Idle	Count=67
15	3.228 (us)	⇒P7				67 - Idle		Count=67
16	3.228 (us)	<b>⇔</b> P8					67 - Idle	Count=67
17	4.062 (us)	⇒P5	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC	0x22:ELS_Request		0x13:REC
18	4.062 (us)	<b>⇔</b> P6	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC		0x22:ELS_Request	0x13:REC
19	4.062 (us)	⇒P7	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC	0x22:ELS_Request		0x13:REC
20	4.062 (us)	ФP8	FCFCFC6A0600	FCFCFC6A0300	0x8906:FC		0x22:ELS_Request	0x13:REC
21	4.158 (us)	⇒P5				67 - Idle		Count=67

Figure 3.2: Spreadsheet View.




Figure 3.3: Frame Inspector View.

Viewer Display Teledyne LeCroy




Figure 3.4: Traffic Summary View.




Figure 3.5: Data View.

**Note:** You can change the colors of captured patterns of by selecting options in the **Preferences** > **Software Settings** > **Types** dialog.

Teledyne LeCroy Quick View

### 3.2 Quick View

By default, the Software Settings enable **Quick View**. Quick View allows full access to the whole trace more quickly, especially when using a Gigabit Ethernet connection. However, the trace is NOT written to the host machine hard drive. To save the trace, you must manually select Save or Save As.

- ☐ If you select **Save**, the application saves the entire trace to a default file name. The trace remains open and its name is updated to reflect the saved location.
- ☐ If you select **Save As**, the application saves the trace to the specified location, and opens that trace from the new location. The original Quick View mode trace remains open as well.

If you de-select Quick View in the Software Settings to disable Quick View, then the trace loads more slowly, but is automatically saved to the host machine hard drive. When Quick View is enabled, the Viewer displays successive parts of trace data as they upload. As soon as a trace part uploads, it is available in all trace views.




Figure 3.6: Enable Quick View

If you only need quick successive traces, and do not need to save them, keep the default setting to enable Quick View.

If you need to save all captured traces, de-selecting the Quick View setting loads the traces faster, especially for larger traces and slower connections.

To refresh the viewer display with more uploaded data, scroll to the end of the trace, using scroll bars, page down, arrow down, or CTRL-End. Newly uploaded data then appears there.

**Note:** High-level decoding and statistics are available only after the whole trace has uploaded.

After the trace finishes uploading, the software automatically switches to full trace view.

To go to the beginning of an uploaded trace, press CTRL Home, or CTRL End to go to the end of an uploaded trace.

### 3.3 Switching Views

To enable and disable views, use the Analysis menu item or the Analysis toolbar.




Figure 3.7: Analysis Toolbar.

After you select a view, it appears in a separate window. To increase the new window display size, use Zoom in and Zoom out from the View menu item or the buttons from the View Toolbar.

To rearrange the tiling, select the **Window** menu and choose **Window Cascade** or **Window Tile.** 

### 3.3.1 Decoding Assignments

Click **Analysis> Decoding Assignments** to display the Decoding Assignments dialog. Click Assign to display the SCSI Assignment dialog (see Figure 3.9). Select an address and click **Close**.

The Script column identifies the script that will be used to decode the protocol.

**<Built-in>** means that a built-in decoder will be used.

If you double-click in the cell, you can specify the path to a user-defined script (.udd).

See the Net Protocol Suite User-Defined Decoding manual for details on how to write a decoding script.




Figure 3.8: Decoding Assignments Dialog.




Figure 3.9: SCSI Assignment Dialog.

### 3.3.2 Spreadsheet View

The Spreadsheet View displays captured packets sequentially, one per line. The packets are decoded and packet fields are displayed column by column.

To display the Spreadsheet View of the current capture, click

Analysis > Spreadsheet View or click the Spreadsheet button on the View toolbar.




Figure 3.10: Spreadsheet View.

### **Data Payload**

Click the iii icon to display the Data Payload dialog (see Figure 3.11 on page 120).

Click the **Export** button to export the data payload to a text file.

Enter a value and click the **Next** or **Previous** button to search the data payload in Hexadecimal or ASCII format. The application looks for byte boundaries while searching. Hence, searching for '1A' will not result in a match because it spans two bytes, whereas searching for '01AC' will result in a match (see Figure 3.12 on page 120).

Click the **Columns in Row** and **Bytes in Column** drop-down menu lists in the View pane to configure the display.

Click **Hex** or **ASCII** to specify the search criteria.




Figure 3.11: Data Payload Dialog.

Click the **Columns in Row** and **Bytes in Column** drop-down menu lists in the View pane to configure the display.




Figure 3.12: Data Payload Search Result.

### **Protocol Errors**

Click the licon to display the Protocol Errors dialog (see Figure 3.13 on page 121). It displays the Code and Name.




Figure 3.13: Protocol Error Dialog.

### **Viewing Ethernet and Fibre Channel Traces**

The application captures and displays both Ethernet and Fibre Channel data.




Figure 3.14: Merged FC and Ethernet Traces in Spreadsheet View.

### Save As and Export

Select **File > Save As** to open the Save As dialog. Refer to "Saving a Trace Capture" on page 68 and "Exporting a Trace Capture" on page 69.

### Spreadsheet View Menu Options

Right-click on any of the columns in the Spreadsheet view to display a list of menu options (see Figure ).




Figure 3.15: Right-click Menu Options in Spreadsheet View.

Add Marker	Opens the Marker List dialog. You can add and delete markers (see "Markers" on page 127.)		
Byte Order	This option is context sensitive. This option allows a you left/right align the data display in each cell.		
Go to:	The Go to option jumps to a related frame in the viewer. It displays the following sub-menu options to go to Trigger, X or Y Position, Packet No., Time Stamp, Marker, Begin and End.		
Change Background Color:	Displays colors to change the background.		
Change Text Color:	Displays colors to change the text.		
Set Time Stamp Origin:	There are four options to set time stamp origin.		
•Absolute:	Sets the time stamp to zero when the recording starts. The first frame in the trace might have the time stamp larger than zero due to filtering, hiding or other reasons such as recording started in the middle of a frame.		
•Trigger:	Sets time to when the trace was triggered.		
•Current Position:	Sets time to the current position.		
•Based on System Time:	Sets time based on the system time.		
Preferences	Displays the Preferences dialog.		
Сору	Copies the frame to allow you to paste it in the Trigger settings.		

### **Column Display Options**

You can customize the columns display by showing/hiding, adding, editing or deleting columns. Right-click on the column header and select an option as shown in Figure 3.16 on page 123.




Figure 3.16: Right-click Menu Options in Spreadsheet View.

Show	Displays a hidden column.
Hide	Hides a column.
Add Column	Allows you to add a column (see Figure 3.17 on page 125). Select Field, Column Name, Source Direction, foreground and back ground Colors, choose And/OR, display Data Payload Protocol Error icons, apply Frame and Port color, enable Time Format, display Field name, set column Alignment and Width and Add to Pre-defined Columns. Columns can also be added to the Pre-defined columns list. This list is a flat list where you can keep columns you might want to toggle on/off.
Edit Column	Allows you to edit column properties. It has the same functionality as Add Column above (see Figure 3.18 on page 126).
Delete Column	Allows you to delete the selected column.
Auto Fit All Columns	Adjusts the column widths to fit the text.
Restore All Columns Widths	Restores the column widths to the previous size.
Go to:	Displays options to go to Trigger, X or Y Position, Packet No., Time Stamp, Marker, Begin and End.
Change Time Stamp Format:	Displays options to select the time stamp format.
Preferences	Displays the Preferences dialog.

### Selecting **Add Column** displays the following dialog.




Figure 3.17: Add a New Column Dialog.

You can select any combination of fields to fill the content of the column. Use the Filter text box above the Fields tree list to more easily find the fields you're interested in. In case you select multiple fields, the up/down buttons enable you to specify in which order they should be displayed in the column. Desired columns can also be added to the pre-defined columns. Pre-defined columns are ones that contain metadata (such as timestamp, port number, etc.) or custom ones that have been added by checking the "Add to Predefined Column" checkbox.

Selecting **Edit Column** displays the following dialog.




Figure 3.18: Edit Column Properties Dialog.

### **Markers**

Markers are a convenient way to mark a point in the spreadsheet by name, so that you can rapidly return to that point. You can create markers for your data by right-clicking any where in the data in Spreadsheet view (see figure below) and select **Add Marker** (see Figure 3.19 on page 127). Enter a Name and description click **Add**. You can also delete, edit or go to a specific marker.




Figure 3.19: Marker List Dialog

Once markers are created they display in the left column of the rows as shown below. Right-click on the marked row and select **Edit Marker** to edit it. Click the **Delete** button to delete the marker.




Figure 3.20: Markers in Spreadsheet View

### Finding a Marker

To find a marker in the right-click the mouse in the trace viewer and select **Go to > Marker**.

Highlight the bookmark to which to go, then click the **Go To** button, or double-click the selection.

### **Marker Description**

To get a quick description of a displayed bookmark, position the tool tip over a bookmark. The name and description of the bookmark display.

### 3.3.3 Frame Inspector View

Frame Inspector View has lots of information that is available in Packet View, but not Spreadsheet View, so it is most useful in conjunction with the Spreadsheet View.

To open a Frame Inspector View of the current capture, select **Analysis > Frame** 

**Inspector View** or click the **b** button on the View Type toolbar.

This Frame Inspector View has the following three tabs:

### **Spec View**

This view shows the Frame as it would appear in the spec, with the field names and values spelled out clearly. Fields that are too short to clearly contain the description can be viewed as tooltips by hovering the mouse over them. Some fields might have a a lowercase 'e' button at the top right corner. Pressing this button displays an 'expanded' view of the sub-fields in this field.





Figure 3.21: Frame Inspector-Spec View

### **Field View**

This view shows, when applicable, a hierarchical display of the selected Packet, with the relevant fields in each level.



Data Payload Button

Figure 3.22: Frame Inspector-Field View

Click the Data Payload button to display the Data Payload dialog (see Figure 3.23 on page 130).




Figure 3.23: Data Payload Dialog

Any ASCII non-printable characters are depicted as black dots as shown above.

### Raw Data View - Frame Inspector View for 64b/66b Decoding

Raw Data View in the Frame Inspector View window shows the exact bit stream in 66b format (see Figure on page 131). This view shows Hex, 10-bit and Running Disparity views of each dword in the selected packet. In this view, a 66 bits block is reconstructed similar to the received data (see the screen capture below). The following columns are displayed in the Raw Data View:

- □ **Index**: This column demonstrates the index of the 66-bits symbol in current blocks.
- □ **Sync Header**: This column shows the Sync Header bits of a symbol.
- □ **Payload**: This column shows the 8 payload bytes in each symbol before scrambling.
- □ **Scrambled**: This column shows the 8 payload bytes in each symbol after scrambling.




Figure 3.24: Raw Data View without FEC

### 3.3.4 Traffic Summary View

The Analysis menu option allows you to run a traffic summary of the captured trace. The Traffic Summary View for each captured pattern can be viewed. This Summary View displays the port number, statistics and the percentage of the total count.




Figure 3.25: Traffic Summary View

### Viewing Ethernet and Fibre Channel Traces in Traffic Summary View

The application captures and displays both Ethernet and Fibre Channel data.





Figure 3.26: Merged FC and Ethernet Traces in Traffic Summary View

### 3.3.5 Reassembly of Frames


Frames transmitted over the Ethernet break up into PDUs (Protocol Data Units). These PDUs may be received in a different order than they were originally transmitted. The application reassembles and displays them in the original order.

The screen captures below show the details of the reassembled frame in both the Spreadsheet View and the Frame Inspector View. The details of PDU1 in the Spreadsheet View are shown in the Frame Inspector View





Reassembled frame in Spreadsheet View



Reassembled frame in Frame Inspector View

Figure 3.27: Reassembled Frame.

### 3.3.6 Source and Destination Columns in Traffic Summary View

**Traffic Summary** displays the Source and Destination addresses for the first 10,000 pairs; the rest are grouped in the **Others** row.




Figure 3.28: Source and Destination Columns in Traffic Summary View.

### 3.3.7 Data View

The Data View displays data in Hexadecimal and ASCII format (see Figure 3.29 on page 135). You can search for data by entering criteria in the Search field. Select an option from Columns and Bytes drop-down list to display the data. The formats available are:

Columns: 1,2, 4, 8 and 16Bytes: 1,2, 4, 8 and 16

Click the **Export** button to display the Save Data Payload dialog to save the data.




Figure 3.29: Data View

### 3.3.8 Customize Display

### **Ports**

All active ports are highlighted on the Show/Hide Ports toolbar. Click the Ports button on the top toolbar to display the ports. Click a port button to hide the captured frames for that port. Frames can be displayed or hidden based on which port they were captured.



Figure 3.30: Show/Hide Ports Toolbar

### Filter: Show/Hide Field

You can simplify the Viewer display by hiding packets. Click the Filter button on the top toolbar to Show/Hide packets and specify And/Or conditions as shown in Figure 3.30 on page 135 (see "Filtering" on page 138).




Figure 3.31: Show/Hide Field

**Note:** Only the fields previously hidden appear in the restore list.

### Show/Hide Idles

You can show or hide Idles by clicking on the Hide/Show Idles icon.

### 3.3.9 Toolbars

### **Enabling Tool Bars**

To customize the Viewer Display workspace, you can enable and reposition the available toolbars. To display or hide toolbars, select **View > Toolbars**, then check or uncheck toolbars.




Figure 3.32: Customizing the Toolbar

### Toolbars are:

- Main
- Analysis
- Setup
- Navigation
- □ View

Once enabled, the toolbars can dock at the Viewer Display window or float on the windows desktop.

### **Main Toolbar**

The Main or standard toolbar has the Hide Menubar, File Open and File Save. See "Software Menus and Toolbar" on page 36 for mor information.



### **Analysis Toolbar**

The Analysis toolbar displays various views. See "Switching Views" on page 117 for more information.

Switching Views Teledyne LeCroy



## **Navigation Toolbar**

The Navigation toolbar allows searching, filtering, collapsing/expanding, and data reporting.





The **Find** button opens the **Find** dialog (see "Find" on page 144).



The **Find Next** button searches for the next matched packet or data previously set in the **Find** dialog (see "Find" on page 144).



The **Find Previous** button searches for the previous match packet or data previously set in the **Find** dialog (see "Find" on page 144).



The down arrow on the **Go To** button allows location of cursors or specific packets: Trigger Position, X Position, Y Position, Timestamp, Event, Begin, and End.



The **Go to Trigger** goes to a trigger point.



The **Go to Marker** button opens the **Marker List** dialog (see "Markers" on page 127) and allows you to specify the marker to go to. The down arrow lists all the markers and you can select one to go to.

## **View Toolbar**

The View toolbar allows wrapping, zooming, and configuration.





The **Zoom In** button on the View Toolbar magnifies the data display area on the screen. Clicking this button in Column or Text View increases column width only.

Teledyne LeCroy Filtering



The **Zoom Out** button on the View Toolbar scales the data display area to display more data lines on the screen. Clicking this button in Column or Text View decreases column width only.



The **Filter** button on the View Toolbar opens the Filter dialog (see "Filtering" on page 138.)



The **Port Filters** button provides a popup that enables you to quickly filter traffic by port in the Spreadsheet View. See "Port Status Pane" on page 58.



The **Show/Hide Idles** button toggles between hiding and showing idles.

## Setup Toolbar

The Setup toolbar is used to set preferences.



The **Preferences** button displays the Preferences dialog (see "Preferences" on page 40.)

#### 3.3.10 Status Bar

The Status bar is located at the bottom of the main display window. Depending on the current activity, the bar can be divided into as many as four segments.

## 3.3.11 Search Status

The right most segment displays the current search direction: **Fwd** (forward) or **Bwd** (backward). Change the search direction from the Search Menu or double-click the Search Status segment.

# 3.4 Filtering

The Filtering menu and options allow you to modify data in the trace viewer display to exclude packets with a set of user-defined patterns and show the results in all views.

To set up filtering, you must have a viewer display open.

## 3.4.1 Filter Setup

To display the Quick Filter dialog (see Figure 3.33 on page 139), click the drop-down

arrow of the **Filter** button on the toolbar or select **View > Hide/Show**. When Filter criteria are set, click the funnel icon on the Filter button to toggle the filters on and off.

Filtering Teledyne LeCroy



Figure 3.33: Quick Filter Dialog

You can Quick Search and Filter on a Frame by right-clicking on it in the trace and selecting **Quick Search**. Select a field to filter/search for. Click in between the two lines in the center to display logical operators to select from the drop-down list.




Figure 3.34: Search/Quick Filter for Frame Dialog

Click the **Advanced** button (see Figure 3.33) on the Quick Filter dialog to display the Advanced Filter dialog (see Figure 3.35).

Teledyne LeCroy Filtering



Figure 3.35: Advanced Filter Dialog

You can select or deselect each of the items shown in the left pane for filtering. Items not in the current trace are greyed out.

**NOTE 1:** If you select a group, that also selects all child items.

NOTE 2: Only packets captured at run time are available for selection for filtering.

## **Filter Type**

You can choose to show or hide the Filter Type items by checking the Show or Hide option button.

## **Filter Logic**

After you have set up Filter options, you can set filter logic to **And** to apply "AND" logic on related selected options or **OR** to apply "OR" logic on all selected options.

## **Save Filter**

After you have set up a Filter configuration, you can save it as a Filter file by clicking Save.

## Load

You can use a previously saved filter by clicking **Load** in the Filter dialog.

## Apply

You can apply the current filter by clicking **Apply** in the Filter dialog.

Filtering Teledyne LeCroy

## Filtering LUNs and LBAs

Perform the following steps to filter for LUNs and LBAs:

1. Click the drop-down arrow of the **Filter** button to display the Quick Filter dialog.

- 2. Click **Advanced** to display the Hide/Show dialog.
- 3. Select FCP\_CMD in the left pane and drag it in to the right pane or click the right arrow.




Figure 3.36: Filtering for LUNs and LBAs

- 4. Select the command, double-click or right-click, and select **Match Fields**. The following filter dialog displays (see Figure 3.35 on page 140).
- 5. Enter the values in the field.
- 6. Click OK twice.

Teledyne LeCroy Using Cursors




Figure 3.37: LUN and LBA Filter

# 3.5 Using Cursors

## 3.5.1 Cursors

The spreadsheet view display incorporates three cursors labeled **X**, **Y**, and **T**. All cursors are initially overlaid and positioned at location 0, which is the trigger position of the display. The Trigger, or **T**, cursor is the measurement reference and is always at location 0 in the display.

# Positioning the X Cursor

To position the X-Cursor within the viewer data display, click the left mouse button in the gray bar on the left side of the trace viewer next to the line in which to place the cursor.

## **Positioning the Y Cursor**

To position the Y-cursor within the viewer data display, click the right mouse button in the gray bar on the left side of the trace viewer next to the line in which to place the cursor.

#### **Locate Cursors**

To quickly locate any cursor within the data viewer display, right-click and select the **Go To X** or **Go To Y** option and choose the cursor to locate (see Figure 3.38 on page 143). You can also locate a cursor by selecting **Go To** from the Navigation menu and choosing the cursor to locate.

Using Cursors Teledyne LeCroy




Figure 3.38: Locate Cursor

## Go to Trigger

Moves the view to the Trigger.

## Go to Packet/Event

To locate a packet, select **Go To Event** or right-click and choose **Packet**.

Enter a Link or Sequence value and number in the Go To dialog and click **OK**.




Figure 3.39: Go to Dialog

## Go to Begin

To go to the beginning of a trace, click the **Go To** button or right-click and choose **Begin**.

#### Go to End

To go to the end of a trace, click the **Go To** button or right-click and choose **End**.

# **Set Time Stamp Origin**

Right-click and choose **Set Time Stamp Origin** (see Figure 3.40 on page 144). For details see "Spreadsheet View Menu Options" on page 122.

Teledyne LeCroy Find




Figure 3.40: Set Time Stamp Dialog

## 3.6 Find

The Find menu and toolbar options permit you to examine any data capture file to

quickly locate the packet or data pattern. Select **Navigation> Find** or click the button to open the **Quick Find** dialog (see Figure 3.41 on page 144). You can also right-click in the trace and select **Quick Search**.

**Note:** Only items captured in the trace file are enabled for search.




Figure 3.41: Quick Find Dialog

Click the **Advanced** button on the Quick Find dialog to display the Advanced Find dialog (see Figure 3.42 on page 145).

Find Teledyne LeCroy




Figure 3.42: Advanced Find Dialog

#### Save

After you have set up a Filter configuration, you can save it as a Filter file by clicking **Save**.

#### Load

You can use a previously saved filter by clicking **Load** in the Filter dialog.

## **Find**

You can find specific packets by selecting one and clicking **find** in the Filter dialog.

You can continue to search the output file using **Find Next (F3)** or **Find Previous (F4)** for the same pattern, until you redefine the data capture search parameters. You can also

click the **Find Next** icon or the **Find Previous** icon. Alternatively, select **Navigation > Find Next** or **Navigation > Find Previous**.

# 3.6.1 Save Find Setup

After you have set up a Find configuration, you can save it as a Search configuration file by clicking **Save**. You can then use it on a different capture by clicking **Load** in the Find dialog.

Teledyne LeCroy Find

## 3.6.2 Search From

Choose a starting point to begin or continue a search: Start of the trace file, Trigger Pointer, X Pointer, Y Pointer, or Last Found.

## 3.6.3 Find Direction

Choose either **Forward** or **Backward** direction in which to perform the find.

# 3.6.4 Find Logic

The default setting is **Or**. With this setting, clicking **Find Next** locates all selected items in turn. If you choose **And**, you can set a logical AND combination of items to find. Both options allow setting Advanced find features.

# 3.6.5 Finding LUNs and LBAs

Perform the following steps to find LUNs and LBAs:

- 1. Click the **Find** icon **t** to display the Quick Find dialog.
- 2. Click **Advanced** to display the Find dialog.
- 3. Select FCP\_CMD in the left pane and drag it in to the right pane or click the right arrow.




Figure 3.43: Find LUNs and LBAs 1

Find Teledyne LeCroy

4. Select the command, double-click or right-click, and select **Match Fields**. The following dialog displays (see Figure 3.44).

- 5. Enter the values in the fields.
- 6. Click OK twice.




Figure 3.44: Find LUNs and LBAs 2

## 3.6.6 Data Pattern Search

From the Advanced Find/Filter dialog, there is a Data Pattern item available (see Figure 3.45 on page 148).

Teledyne LeCroy Find



Figure 3.45: Data Pattern Search Menu

You may use this feature to set criteria based on Data Patterns in the frame payloads.




Figure 3.46: Data Pattern Search Filter

Preferences Teledyne LeCroy

1. From the tree list on the left, select the types of payloads you want to search/filter against.

- 2. Check the boxes next to 'Data Pattern' and 'Data Length' to set whether you check based on those criteria or not.
- 3. If you check both the 'Data Pattern' and 'Data Length' boxes, also select the And/Or radio button to set whether you want to combine the criteria with AND or OR logic.
- 4. If 'Data Pattern' is checked, enter the pattern you wish to match against. You may specify any size of pattern in this field. Click the red format button to toggle between different input format modes:
  - a. Hex
  - b. Binary
  - c. ASCII
  - d. Decimal
- 5. If 'Data Length' is checked, enter the length in bytes you wish to match against, and set the desired comparison operator:
  - a. == (equal)
  - b. != (not equal)
  - c. > (greater than)
  - d. < (less than)
  - e. >= (greater than or equal)
  - f. <= (less than or equal)

## 3.7 Preferences

The Analyzer ships with a default configuration for software settings, port alias, address alias, display and sequencer settings. You can define your own settings for a particular

testing scenario. To set these preferences select **Setup > Preferences** or click the icon on the main toolbar to display the Preferences dialog (see Figure 3.47 on page 150).

Teledyne LeCroy Preferences




Figure 3.47: Preferences Dialog

# 3.7.1 Software Settings

Software Settings allow you to define template files for new Analyzer projects, to specify how trace files appear when opened, and to set Spec Assignment.

In General you can select the User Path and Temp path by clicking the \_\_\_\_\_ icon or browse to one of the default paths which are Software default and Windows default. See the figure below.

Select BB-5 or BB-6 for the FC BACKBONE Version.

Select Cable Type from the drop-down list.

Preferences Teledyne LeCroy




Figure 3.48: Software Settings General Options

Teledyne LeCroy Preferences

## **Decoding Assignments**




Figure 3.49: Decoding Assignments

These settings enable you to customize which protocol decoders are applied to the data in captured traces. Settings made here will apply to subsequent traces that are created. To apply new settings to an existing trace, first set the settings as desired, then open the trace, select File -> Save As and save the trace to a new file. The new file will have the new decoding assignment settings applied.

- □ SCSI Spec Assignment: Select which SCSI command set to apply for decoding of SCSI commands.
- □ SCSI TCP Ports: Set which TCP ports are assigned for the iSCSI protocol.
- □ VXLAN UDP Ports: Set which UDP ports are assigned for the VXLAN protocol.
- ☐ MPA TCP Ports: Set which TCP ports are assigned for the MPA protocol.
- Script Path: Set the base script directory used for looking up user-defined decoding scripts. Refer to "Decoding Assignments" on page 117 for details on assigning script decoders.
- □ For the Ports settings, you may specify a list of ports by separating port numbers with commas (e.g., "400, 403, 407"). You may specify a range of ports by using a hyphen between the lower and upper port numbers of the range (e.g., "1200-1207").

Preferences Teledyne LeCroy

The Decoding Assignments allow the user to configure SCSI command set assignments (see "SCSI Spec Assignments" on page 153), well-known port numbers assignments, and decoding script assignments.



Figure 3.50: SCSI Spec Assignments

## 3.7.2 Port Alias

Port Alias allows you to assign a meaningful name to each port to assist in interpreting the results displayed in the trace view. You can set the alias name for each port. Double click an Alias Name and enter a name. See the figure below.

Teledyne LeCroy Preferences




Figure 3.51: Port Alias Dialog

## 3.7.3 Address Alias

Address Alias allows you to assign a meaningful name to each address to assist in interpreting the results displayed in the trace view You can set the alias name for each address. Double click an Alias Name and enter a name. See the figure below.

Preferences Teledyne LeCroy




Figure 3.52: Address Alias Dialog

# 3.7.4 Display Settings

In General you can select the Time options and the Data Payload options from the drop-down lists. See the figure below.

Teledyne LeCroy Preferences




Figure 3.53: Display Settings General Dialog

Preferences Teledyne LeCroy

In Spreadsheet you can click **Property** and select the Color Setting option for row and column from the drop-down list. See the figure below.




Figure 3.54: Display Settings Spreadsheet Dialog

Teledyne LeCroy Preferences

In Field Attributes you can click a **Trigger Pattern** and select the, Field Setting, Color Setting and Field Header Setting options from the drop-down lists. See the figure below.




Figure 3.55: Display Settings Field Attributes Dialog

Preferences Teledyne LeCroy

In Frame types you can select the foreground and background Color Setting by clicking on the relevant button. See the figure below.




Figure 3.56: Display Settings Frame Types Dialog

Teledyne LeCroy Help Menu

In Ports you can select the foreground and background Color Setting by clicking on he relevant button. See Figure 3.56 on page 159.




Figure 3.57: Display Settings Ports Dialog

# 3.8 Help Menu

# 3.8.1 Tell Teledyne LeCroy

Report a problem to Teledyne LeCroy Support via e-mail by selecting **Help>Tell Teledyne LeCroy** from the application toolbar. This requires that an e-mail client be installed and configured on the host machine.

## 3.8.2 Help Topics

Displays online help. You can also select F1.

## 3.8.3 License Information

Open the license information dialog (see Figure 3.58 on page 161) to display a list of named features supported by the current software version. Named features that are not enabled on your system are indicated by No in the Purchased column. Whether or not named features are enabled depends on the license key stored in your analyzer. If you try

Help Menu Teledyne LeCroy

to use a feature for which you do not yet have a license, the program displays the License Protection Message. To use the feature, you must purchase a license.




Figure 3.58: License Information Dialog

A current license agreement with Teledyne LeCroy entitles the Analyzer owner to continued technical support and access to software updates as they are published on the Teledyne LeCroy website. When you obtain a license key, from the Help menu in the License Information dialog, select **Install License File** to display the Open License dialog. Enter the path and filename for the license key, or browse to the directory that contains the license key and select the \*.lic file. Click Open.

# 3.8.4 Check for Updates

Check whether a new software version is available. If so, you can download from the Teledyne LeCroy web site.

You can select to Check for updates at application startup.

## 3.8.5 Shortcut List

Displays a list of keyboard shortcuts.

Teledyne LeCroy Help Menu




Figure 3.59: Shortcuts List

## 3.8.6 About

Displays Teledyne LeCroy SierraNet Protocol Suite software version information.

# **Chapter 4**

# **InFusion**

## 4.1 InFusion Overview

The Teledyne LeCroy InFusion™ Error Injector and Traffic Modifier is an error injector and traffic modification tool that allows you to verify real-world fault handling for Fibre Channel systems. InFusion can sit unobtrusively in the data path on a live system to programmatically alter or corrupt traffic. InFusion is the ideal tool for stress-testing

systems using actual workloads. Click the New Scenario icon to display the Infusion Scenario Manager dialog.




Figure 4.1: InFusion Windows

Teledyne LeCroy Key Features

InFusion supports Ethernet and Fibre Channel links up to 16 Gbps. InFusion monitors traffic from both directions in real-time and relies on predefined rules to replace any bit, ordered-set, or parameter with one you specify. InFusion can change traffic when it detects a specific sequence or reaches a designated time interval, yet it requires no complicated scripts, programming, or simulation tools. It supports "Jumbo" packets up to 16K.

InFusion can monitor traffic in both directions and act on Events occurring in either direction of the communications link. InFusion can modify traffic in only one direction within a given test Scenario, but that direction can be either from the Originator or from the Responder.

InFusion is specifically designed to verify recovery characteristics within a subsystem. An easy, user friendly menu interface with icons and hyperlinks allows you to create specific test Scenarios in just minutes.

Once an InFusion session starts, the system automatically handles protocol handshaking between devices. InFusion transmits a faithful copy of the original data stream down to the CRC value which, if needed, it recalculates. InFusion allows test engineers to systematically verify error recovery in ways not possible with other test platforms.

# 4.2 Key Features

The key features of InFusion are:

- Error Injection: Injects CRC, disparity, 8b/10b encoding, framing, and coding errors.
   Break Link Recovery: Programmatically breaks the connection to test link recov
  - ery.
- □ Value Replacement: Monitors the link for specific values, patterns, or orderedsets (as low as bit level) and replace with user-defined values. You can replace values on every occurrence, after a specified number of occurrences, or after a specified time interval.
- □ **Packet Drop**: Removes individual ordered-sets or frames from the stream to verify retry behavior.
- □ **Ordered-set Manipulation**: Replaces handshaking and flow control ordered-sets to help validate robustness of a design.
- ☐ **Traffic Monitoring:** Operates as a traffic monitor, collecting statistical data on user-specified parameters. In this mode, data passes unchanged in both directions.
- ☐ **Menu-Driven Interface:** Allows easy set-up of test Scenarios.

With respect to traffic modification, in the Link Layer you can modify ordered-sets, CRC, scrambled data, and connection Events. You cannot modify clock skew management and signal integrity.

InFusion consists of a hardware device that connects to the line under test and a Windows-based software application used to create and download test scripts to the device. You also can use the software application to configure and control the device across an Ethernet or USB link.

Infusion Control Interface Teledyne LeCroy

InFusion test scripts are called Scenarios. Scenarios determine how the hardware device monitors and modifies line traffic. In order to create and download Scenarios the Teledyne LeCroy Net Protocol Suite application must be used.

For the InFusion connections, the device is connected between the PHYs of the originator and responder.

## 4.3 Infusion Control Interface



Figure 4.2: InFusion Control Interface Menu

The InFusion Control interface has the following controls:

**Start/Stop Session button:** This is a toggle button that starts or stops the session on the specified ports. Each port-pair has its own button and is controlled independently. The text on the bottom half of the button indicates the port-pair controlled by the button.

Scenario drop-down list: This is a drop-down list that lets you assign a scenario from the Project's library to the specified ports. Each port-pair has its own drop-down list and is assigned independently. The text on the left side of the drop-down list indicates the port-pair to which the scenario is assigned. The highlighted port label indicates the direction of jamming, which can be changed from the Scenario Manager interface (see section "Traffic Direction" on page 199).

# 4.4 InFusion Scenario Manager Interface




Figure 4.3: InFusion Scenario Manager Menu

The InFusion Scenario Editor interface has the following panels:

**Global Libraries Panel:** The Main Library window (on the left), which displays the available Scenarios. You can create a New Scenario, Open Containing Folder, Copy Container Folder Path, Add New Library, Rename Library or Remove Library. The scenarios saved on a specific platform in the Global Library are available in all projects for the same platform.

**Project Library Panel:** The Project Library window (on the left), which displays the project libraries. The scenarios saved in the Project Library are only available for the current project.

**Scenarios Workspace Panel:** This is the middle section, where you will construct and manipulate the logic of the scenario by defining Events and Actions.

**Event Panel:** Lists all the available events to be used in the Scenarios Workspace.

**Action Panel:** Lists all the available actions to be used in the Scenarios Workspace.

# 4.5 Port Configuration for InFusion

Select **File> New Project** to display the Add Device to Project dialog (see (Figure 4.4 on page 167).

InFusion Scenarios Teledyne LeCroy

To record traffic both before and after the InFusion modifies (jams) it, select AJA (Analyzer/Jammer/Analyzer) in the Link Assignment column (or any other desired configuration) and click **OK**.



Figure 4.4: Add Device to Project Dialog

**Note:** You can select only one Jammer port at a time when using the AJA configuration.

To record traffic from other ports after the InFusion modifies (jams) them, select a combination of ports that have **Jammer/Analyzer** specified under them. The different configurations accommodate different possible user setups and requirements.

# Important Information for Jammer and Analyzer

Jammer intercepts and delays traffic on both directions simultaneously, so Originator sends to Jammer, Jammer delays and sends to Responder, Responder sends to Jammer, Jammer delays and sends to Originator. However, Jammer modifies traffic in one direction only: from Originator to Responder, or from Responder to Originator.

When AJAJ is selected, use a jumper between P2 and P3. For Bi directional jams, use P1/2 Jammer for "A" channel ("before" should be on 1 and "after" should be on 3) and use P3/4 Jammer for "B" channel ("before" should be on 4 and "after" should be on 2).

#### 4.6 InFusion Scenarios

You can create and execute InFusion Scenarios. A Scenario is a test script that defines how InFusion monitors and modifies line traffic.

# 4.6.1 Scenario Overview

You create Scenarios on a host machine running the Net Protocol Suite application. You then specify the Scenarios for execution on an InFusion device.

Teledyne LeCroy InFusion Scenarios

The Net protocol Suite application provides a user friendly interface for building Scenarios. The interface prompts you for simple decisions and choices from drop-down menus and icons and has a drag and drop interface. As you make your selections, the script takes shape automatically in the Scenario window.

You can open an existing Library or create a new Library from the drop-down list on the

top of the screen or click the New Scenario icon to display the Infusion Scenario Manager dialog.




Figure 4.5: New Scenario in InFusion Scenario Manager.

You can drag and drop events in the Global Rules panel and assign actions to them.

InFusion Scenarios Teledyne LeCroy

Click the **Add State** button to drag and drop events in the Sequence 1 and Sequence 2 panels and assign actions to them. If Actions are not assigned a yellow Caution message displays. If invalid actions are assigned then a red Warning icon displays.




Figure 4.6: Add State InFusion Scenario Manager

**Note:** The **Insert State** command inserts a new state after the current state. Plan carefully while creating scenarios or you might have to insert a state after state 0, copy and paste from state 0 to the new state, and clear out state 0, in order to accomplish what "Insert State" does.

Teledyne LeCroy InFusion Scenarios

The Global Rules and States are part of the new Scenario. Once the scenario is created, right-click on the New Scenario tab and select **Rename** to name it in the Project Library panel. Click the **Close** icon to save it in the Library for later use. All the Scenarios that are created are displayed in the Library panel.




Figure 4.7: Global Rules and States InFusion Scenario Manager

## 4.6.2 Jam Details

- ☐ Jam Event: Set a Jam Event by dragging an Event to the Global Rules or Sequence panel. The Events and their descriptions are listed in Table 4.1 on page 171.
- ☐ Jam Action: Set a Jam Action by dragging an Action to the Global Rules or Sequence panel.
- □ After the first Jam Action has been specified you can set a consequent Jam Action by dragging more Actions to the **Drag an Event here to add another condition** area. The Jam Actions and their descriptions are listed in Table 4.1 on page 171.

#### 4.6.3 Scenario Events

Table Table 4.1 on page 171 describes the Presets that can be used as FCoE Events. See "Available Resources" on page 191 for details.

**Note:** You can have multiple Events and Actions in Global Rules and in each State.

InFusion Scenarios TeledyneLeCroy

**TABLE 4.1: Events and their Descriptions (Ethernet)** 

_		
Event	Description	
User Patterns		
Most Recent	Lists the most recent Events.	
New User Group	Lists the new user groups.	
Presets		
Timers/External		
Timer	The Event occurs when the timer expires.	
Other Trigs	Analyzer: the Event occurs when the Analyzer triggers.	
	External: the Event occurs when the external Trigger In is asserted.	
Basic	-	
Basic Link Service	Refer to section "Basic" on page 77.	
Link Control Frame	Refer to section "Link Control Frame" on page 78.	
Link Speed	The Event occurs when the link is at the specified speed.	
Both Linkup	The Event occurs when both ports are out of electric idle.	
Dword Reuse	Refer to section "Using Captured Data Dwords" on	
	page 193.	
Dword Matcher	Refer to section "Dword Matcher" on page 195.	
Training Sequence	Inject Error on Control: Generates Manchester Coding	
	violation on Control field bits corresponding to the defined	
	mask: One means violation, and zero means no error.	
	Inject Error on Status: Generates Manchester Coding	
	violation on Status field bits corresponding to the defined mask: One means violation, and zero means no error.	
	Frame Marker Error: Generates training sequence with an	
	invalid frame marker.	
	Recode Manchester Coding: Forces jammer to recalculate	
	Manchester Coding for each bit of training frame.	
FCP		
FCP SCSI Command	Refer to section "Basic" on page 77.	
FCP Frame Information	Refer to section "FCP Patterns" on page 79.	
Unit		
SCSI Command Status	Refer to section "SCSI" on page 79.	
FCP Task Management	Refer to section "FCP Task Management" on page 80.	
ELS		
Extended Link Service- Request	Refer to section "ELS Patterns" on page 80.	
Extended Link Service-	Refer to section "ELS Patterns" on page 80.	
Request, Reply		
Extended Link Service-	Refer to section"ELS Patterns" on page 80.	
Reply		

Teledyne LeCroy InFusion Scenarios

<b>5</b> 1	D
Event	Description
GS	12 f
Generic Link Service- Request	Refer to section "GS Patterns" on page 80.
Generic Link Service- Request, Reply	Refer to section "GS Patterns" on page 80.
Generic Link Service-	Refer to section "GS Patterns" on page 80.
Reply	
SW	
Switch Internal Link - Request	Refer to section "SW Patterns" on page 80.
Switch Internal Link - Request, Reply	Refer to section "SW Patterns" on page 80.
Switch Internal Link -	Refer to section "SW Patterns" on page 80.
Reply	There to section 500 rateering on page 50.
FICON	
FICON (Any Data	Refer to section "FICON Patterns" on page 80.
Information Block Type)	
FICON (Data)	Refer to section Refer to section "FICON Patterns" on
	page 80.
FICON (Command)	Refer to section Refer to section "FICON Patterns" on page 80
FICON (Status)	Refer to section Refer to section "FICON Patterns" on
	page 80.
FICON (Control)	Refer to section Refer to section "FICON Patterns" on
	page 80.
FICON (Command-Data)	Refer to section "FICON Patterns" on page 80.
FICON (Link-Control)	Refer to section "FICON Patterns" on page 80.
FCAE 1553	
FCAE - ASM	Refer to section "FCAE_ASM" on page 80.
FCAE 1553 (Any)	Refer to section "FCAE-1553" on page 80.
FCAE 1553 (Data)	Refer to section "FCAE-1553" on page 80.
FCAE 1553 (Command)	Refer to section "FCAE-1553" on page 80.
FCAE 1553 (Status)	Refer to section "FCAE-1553" on page 80.
FCVI	
FCVI(Any)	Refer to section "FCVI Patterns" on page 80.
FCVI(SEND_RQST)	Refer to section "FCVI Patterns" on page 80.
FCVI(WRITE_RQST)	Refer to section "FCVI Patterns" on page 80.
FCVI(READ_RQST)	Refer to section "FCVI Patterns" on page 80.
FCVI(SEND_RESP)	Refer to section "FCVI Patterns" on page 80.
FCVI(WRITE_RESP)	Refer to section "FCVI Patterns" on page 80.
FCVI(READ_RESP)	Refer to section "FCVI Patterns" on page 80.
FCVI(CONNECT_RQST)	Refer to section "FCVI Patterns" on page 80.

Event	Description		
FCVI(DISCONNECT_RQST)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RESP1)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RESP2)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RESP3)	Refer to section "FCVI Patterns" on page 80.		
FCVI	Refer to section "FCVI Patterns" on page 80.		
(DISCONNECT_RESP)			
FCAV			
FCAV(Simple)	Refer to section "FCAV Patterns" on page 80.		
FCAV(Extended)	Refer to section "FCAV Patterns" on page 80.		
VSAN			
Basic			
VSAN-Basic Link Service	Refer to section "VSAN Patterns" on page 80.		
VSAN-Link Control Frame	Refer to section "VSAN Patterns" on page 80.		
FCP			
VSAN-FCP SCSI	Refer to section "VSAN Patterns" on page 80.		
Command			
VSAN-FCP Frame	Refer to section "VSAN Patterns" on page 80.		
Information Unit			
VSAN-SCSI Command	Refer to section "VSAN Patterns" on page 80.		
Status			
VSAN-FCP Task	Refer to section "VSAN Patterns" on page 80.		
Management			
ARB			
VSAN-ARB Loop Initialization	Refer to section "VSAN Patterns" on page 80.		
ELS			
VSAN-Extended Link	Refer to section "VSAN Patterns" on page 80.		
Service-Request	Refer to section VSAN Patterns on page 80.		
VSAN-Extended Link	Refer to section "VSAN Patterns" on page 80.		
Service-Reply	There to section VSAN latterns on page 80.		
GS			
VSAN-Generic Link	Refer to section "VSAN Patterns" on page 80.		
Service-Request			
VSAN-Generic Link	Refer to section "VSAN Patterns" on page 80.		
Service-Reply	. 0		
SW			
VSAN-Switch Internal	Refer to section "VSAN Patterns" on page 80.		
Link-Request			
VSAN-Switch Internal	Refer to section "VSAN Patterns" on page 80.		
Link-Reply			
FICON			

Event	Description		
VSAN-FICON (Any Data	Refer to section "VSAN Patterns" on page 80.		
Information Block Type)			
VSAN-FICON (Data)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Command)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Status)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Control)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Command-	Refer to section "VSAN Patterns" on page 80.		
Data)			
VSAN-FICON (Link-	Refer to section "VSAN Patterns" on page 80.		
Control)			
VSAN-FCAE-ASM	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCAE 1553			
VSAN-FCAE 1553 (Any)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCAE 1553 (Data)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCAE 1553	Refer to section "VSAN Patterns" on page 80.		
(Command)			
	Refer to section "VSAN Patterns" on page 80.		
FCVI			
VSAN-FCVI(Any)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCVI(SEND_RQST)	Refer to section "VSAN Patterns" on page 80.		
VSAN-	Refer to section "VSAN Patterns" on page 80.		
FCVI(WRITE_RQST)			
VSAN-FCVI(READ_RQST)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCVI(SEND_RESP)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCVI(WRITE_RESP)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCVI(READ_RESP)	Refer to section "VSAN Patterns" on page 80.		
VSAN-	Refer to section "VSAN Patterns" on page 80.		
FCVI(CONNECT_RQST)			
VSAN-	Refer to section "VSAN Patterns" on page 80.		
FCVI(DISCONNECT_RQST)			
VSAN-	Refer to section "VSAN Patterns" on page 80.		
FCVI(CONNECT_RESP1)	Defendance (NICANI Dellance)		
VSAN- FCVI(CONNECT RESP2)	Refer to section "VSAN Patterns" on page 80.		
VSAN-	Perfor to section "VCAN Patterns" on page 90		
FCVI(CONNECT RESP3)	Refer to section "VSAN Patterns" on page 80.		
VSAN-	Refer to section "VSAN Patterns" on page 80.		
FCVI(DISCONNECT RESP)	neier to section VSAN ratterns on page ou.		
FCAV			
VSAN-FCAV(Simple)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FCAV(Extended)	Refer to section "VSAN Patterns" on page 80.		
VOAN I CAV(LATERIACA)	l section voniviations on page ou.		

Event	Description		
FIP	Refer to section "FIP Patterns" on page 81.		
MPCP	Refer to section "MPCP Pattern" on page 82.		
Address Resolution	Refer to section "Address Resolution Protocol Pattern" on		
Protocol	page 82.		
Link Layer Discovery	Refer to section "Link Layer Discovery Protocol Pattern" on		
Protocol	page 83.		
Internet Protocol	Refer to section "Internet Protocol Pattern" on page 84.		
iSCSI	Refer to section "iSCSI Pattern" on page 84.		
VLAN	Refer to section "VLAN Patterns" on page 87.		
ISL	Refer to section "ISL Patterns" on page 87.		
CN-Tag	Refer to section "CN Tag Patterns" on page 88.		
VN-Tag	Refer to section "VN Tag Patterns" on page 88.		
Trill Frame	Refer to section "LLC" on page 88.		
Protocol Errors	Refer to section "Protocol Errors" on page 92.		
Jammer Internal	Refer to section "Synch Jammer Scenarios with Jammer		
Triggers	Internal Triggers" on page 206.		

The following table describes the Presets that can be used as FC Events.

TABLE 4.2: Events and their Descriptions (FC)

Event	Description			
User Patterns				
Most Recent	Lists the most recent Events.			
New User Group	Lists the new user groups.			
Presets				
Timers/External				
Timer	The Event occurs when the timer expires.			
Other Trigs	Analyzer: the Event occurs when the Analyzer triggers.			
	External: the Event occurs when the external Trigger In is			
	asserted.			
Basic				
Ordered Set	Refer to section "Ordered Set" on page 95.			
Basic Link Service	Refer to section "Basic Link Service" on page 99.			
Link Control Frame	Refer to section "Link Control Frame" on page 100.			
Link Speed	The Event occurs when the link is at the specified speed.			
Both Linkup	The Event occurs when both ports are out of electric idle.			
Training Sequence	Inject Error on Control: Generates Manchester Coding			
	violation on Control field bits corresponding to the defined			
	mask: One means violation, and zero means no error.			
	Inject Error on Status: Generates Manchester Coding			
	violation on Status field bits corresponding to the defined			
	mask: One means violation, and zero means no error.			
	<b>Frame Marker Error</b> : Generates training sequence with an invalid frame marker.			
	<b>Recode Manchester Coding</b> : Forces jammer to recalculate			
	Manchester Coding for each bit of training frame. Refer to			
	section "Training Sequence" on page 98.			
FCP				
FCP SCSI Command	Refer to section "SCSI" on page 79.			
FCP Frame Information	Refer to section "Frame Information Unit" on page 79.			
Unit				
SCSI Command Status	Refer to section "SCSI" on page 79.			
FCP Task Management	Refer to section "FCP Task Management" on page 80.			
ELS				
Extended Link Service-	Refer to section "ELS Patterns" on page 80.			
Request	D. (			
Extended Link Service-	Refer to section "ELS Patterns" on page 80.			
Request, Reply  Extended Link Service-	Pefer to castion "ELC Patterns" on page 90			
Reply	Refer to section"ELS Patterns" on page 80.			
GS Reply				
<del>55</del>				

Event	Description		
Generic Link Service-	Refer to section "Generic Link Service-Request" on		
Request	page 80.		
Generic Link Service-	Refer to section "GS Reply" on page 80.		
Request, Reply			
Generic Link Service-	Refer to section "GS Reply" on page 80.		
Reply			
SW			
Switch Internal Link -	Refer to section "SW Request" on page 80.		
Request			
Switch Internal Link -	Refer to section "SW Reply" on page 80.		
Request, Reply			
Switch Internal Link -	Refer to section "SW Reply" on page 80.		
Reply			
FICON	<b>,</b>		
FICON (Any Data	Refer to section "FICON Patterns" on page 80.		
Information Block Type)			
FICON (Data)	Refer to section Refer to section "FICON Patterns" on		
	page 80.		
FICON (Command)	Refer to section Refer to section "FICON Patterns" on		
	page 80.		
FICON (Status)	Refer to section Refer to section "FICON Patterns" on		
FICONI (Cartari)	page 80.		
FICON (Control)	Refer to section Refer to section "FICON Patterns" on		
FICON (Commond Data)	page 80.		
FICON (Command-Data)			
FICON (Link-Control)	Refer to section "FICON Patterns" on page 80.		
FCAE 1553	ID (		
FCAE - ASM	Refer to section "FCAE_ASM" on page 80.		
FCAE 1553 (Any)	Refer to section "FCAE-1553" on page 80.		
FCAE 1553 (Data)	Refer to section "FCAE-1553" on page 80.		
FCAE 1553 (Command)	Refer to section "FCAE-1553" on page 80.		
FCAE 1553 (Status)	Refer to section "FCAE-1553" on page 80.		
FCVI			
FCVI(Any)	Refer to section "FCVI Patterns" on page 80.		
FCVI(SEND_RQST)	Refer to section "FCVI Patterns" on page 80.		
FCVI(WRITE_RQST)	Refer to section "FCVI Patterns" on page 80.		
FCVI(READ_RQST)	Refer to section "FCVI Patterns" on page 80.		
FCVI(SEND_RESP)	Refer to section "FCVI Patterns" on page 80.		
FCVI(WRITE_RESP)	Refer to section "FCVI Patterns" on page 80.		
FCVI(READ_RESP)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RQST)	Refer to section "FCVI Patterns" on page 80.		
FCVI(DISCONNECT_RQST)			
. 51. 15.5551111261_1(451)   Italian to section   Forthatterns on page oo.			

Event	Description		
FCVI(CONNECT_RESP1)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RESP2)	Refer to section "FCVI Patterns" on page 80.		
FCVI(CONNECT_RESP3)	Refer to section "FCVI Patterns" on page 80.		
FCVI	Refer to section "FCVI Patterns" on page 80.		
(DISCONNECT_RESP)			
FCAV			
FCAV(Simple)	Refer to section "FCAV Patterns" on page 80.		
FCAV(Extended)	Refer to section "FCAV Patterns" on page 80.		
VSAN			
FCP			
VSAN-FCP SCSI	Refer to section "VSAN Patterns" on page 80.		
Command			
VSAN-FCP Frame	Refer to section "VSAN Patterns" on page 80.		
Information Unit			
VSAN-SCSI Command	Refer to section "VSAN Patterns" on page 80.		
Status			
VSAN-FCP Task	Refer to section "VSAN Patterns" on page 80.		
Management			
ARB			
VSAN-ARB Loop	Refer to section "VSAN Patterns" on page 80.		
Initialization			
ELS			
VSAN-Extended Link	Refer to section "VSAN Patterns" on page 80.		
Service-Request			
VSAN-Extended Link	Refer to section "VSAN Patterns" on page 80.		
Service-Reply			
GS			
VSAN-Generic Link	Refer to section "VSAN Patterns" on page 80.		
Service-Request			
VSAN-Generic Link	Refer to section "VSAN Patterns" on page 80.		
Service-Reply			
SW			
VSAN-Switch Internal	Refer to section "VSAN Patterns" on page 80.		
Link-Request			
VSAN-Switch Internal	Refer to section "VSAN Patterns" on page 80.		
Link-Reply			
FICON			
VSAN-FICON (Any Data	Refer to section "VSAN Patterns" on page 80.		
Information Block Type)			
VSAN-FICON (Data)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Command)	Refer to section "VSAN Patterns" on page 80.		
VSAN-FICON (Status)	Refer to section "VSAN Patterns" on page 80.		

Event	Description	
VSAN-FICON (Control)	Refer to section "VSAN Patterns" on page 80.	
· · · · · · · · · · · · · · · · · · ·	Refer to section "VSAN Patterns" on page 80.	
Data)	Refer to section VSAN Patterns on page 80.	
VSAN-FICON (Link-	Refer to section "VSAN Patterns" on page 80.	
Control)	Neier to section VSAN Fatterns on page 80.	
VSAN-FCAE-ASM	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCAE 1553		
VSAN-FCAE 1553 (Any)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCAE 1553 (Data)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCAE 1553	Refer to section "VSAN Patterns" on page 80.	
(Command)	μ.	
VSAN-FCAE 1553 (Status)	Refer to section "VSAN Patterns" on page 80.	
FCVI	<u> </u>	
VSAN-FCVI(Any)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCVI(SEND_RQST)	Refer to section "VSAN Patterns" on page 80.	
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(WRITE_RQST)		
VSAN-FCVI(READ_RQST)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCVI(SEND_RESP)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCVI(WRITE_RESP)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCVI(READ_RESP)	Refer to section "VSAN Patterns" on page 80.	
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(CONNECT_RQST)		
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(DISCONNECT_RQST)		
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(CONNECT_RESP1)		
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(CONNECT_RESP2) VSAN-	Defends costing "NCAN Dettorns" on page 90	
FCVI(CONNECT RESP3)	Refer to section "VSAN Patterns" on page 80.	
VSAN-	Refer to section "VSAN Patterns" on page 80.	
FCVI(DISCONNECT RESP)	Neier to section VSAN Fatterns on page 80.	
FCAV		
VSAN-FCAV(Simple)	Refer to section "VSAN Patterns" on page 80.	
VSAN-FCAV(Extended)	Refer to section "VSAN Patterns" on page 80.	
FIP	Refer to section "FIP Patterns" on page 81.	
MPCP	Refer to section "MPCP Pattern" on page 82.	
Address Resolution	Refer to section "Address Resolution Protocol Pattern" on	
Protocol	page 82.	

Event	Description	
Link Layer Discovery	Refer to section "Link Layer Discovery Protocol Pattern" on	
Protocol	page 83.	
Internet Protocol	Refer to section "Internet Protocol Pattern" on page 84.	
iSCSI	Refer to section "iSCSI Pattern" on page 84 and "ISCSI Cmd" on page 86.	
VLAN	Refer to section "VLAN Patterns" on page 87.	
ISL	Refer to section "ISL Patterns" on page 87.	
CN-Tag	Refer to section "CN Tag Patterns" on page 88.	
VN-Tag	Refer to section "VN Tag Patterns" on page 88.	
Trill Frame	Refer to section "Trill Frame" on page 90.	
Protocol Errors	Refer to section "Protocol Errors" on page 92.	
Jammer Internal	Refer to section "Synch Jammer Scenarios with Jammer	
Triggers	Internal Triggers" on page 206.	

**Note:** You can specify additional Sequences and States. The application automatically checks for the maximum number of terms (sequences/states). When you exceed the limit, an error is flagged, prompting you to jump to the place that caused the error.

**Note:** You can specify additional Sequences and States. The application automatically checks for the maximum number of terms (sequences/states). When you exceed the limit, an error is flagged, prompting you to jump to the place that caused the error.

Creating InFusion Scenarios is easy, but it requires an understanding of the following terms defined in Table 4.3.

**TABLE 4.3: Key Scenario Terms** 

Term	Definition	
Action	InFusion response to an Event. See "Scenario Actions" on page 181.	
Event	Condition that is detectable by InFusion. See "Scenario Events" on page 170.	
Combined Event	Logical OR association of Events (for example, Event A OR Event B).	
Global Rules	Portion of a Scenario that can define a single InFusion test state. You can think of the Global Rules and each Sequence as a separate test routine or program operating within the Scenario. Each operates independently and in parallel with the others. The purpose of each is to detect Events and then respond with the appropriate Action or set of Actions. In essence, you can operate up to three test states simultaneously within InFusion - one is the Global Rules, and the other two are the 2 active states, one in each Sequence. See "Global Rules" on page 197.	
Sequence	Portion of a Scenario that can define multiple InFusion test states. More flexible than the Global Rules, a Sequence allows more powerful Scenarios that include branching and looping between test states (Global Rules can define only a single test state, so there is no branching). See "Sequences" on page 198.	
State	"Behavior" of the Global Rules or a Sequence at any point in time. In terms of InFusion testing, behavior is "waiting" for a set of Events and responding with a set of Actions.	

## 4.6.4 Scenario Actions

After you enter the set of Events for a test state, the menu-driven interface prompts you for the corresponding Action or set of Actions. If you define multiple Actions, the Actions occur simultaneously.

**Note:** The Actions displayed are dependent on the Events selected.

The following figure displays the options for a set of Actions in the Simple Mode (Ethernet).




Figure 4.8: Ethernet Action Properties Dialog

The following table lists the supported Actions. Note that some of these Actions only apply to creating sequences.

TABLE 4.4: Test State Actions in Simple Mode

Action		Description
Basic	Веер	Emits audible sound of duration selectable via a drop-down list.
	Monitor Count	Opens a window to count the number of Events that occur during a session. A session is a time interval during which a Scenario runs.
	Auto Negotiation Jam	Opens a window to set Code Values, Code Settings and General parameters (Ethernet only).
	Link Control	Reconnect - starts traffic pass-through immediately. This Action restarts traffic after a previous disconnect command.  Once traffic is passing through, the originator and responder resume link bring up.  Disconnect - puts InFusion ports at electrical idle immediately. This action is only in effect while the scenario is running, and the Jammer will reconnect the line when the scenario is stopped.
		Reconnect/Disconnect can be applied in either direction separately: From P1/P3/P5/P7 direction: Reconnect/ Disconnect only the originator link. From P2/P4/P6/P8 direction: Reconnect/ Disconnect only the responder link. (See Figure 4.11 on page 188.)
Symbol Jam	Replace with Another Symbol	Replaces the Symbol with the selected Symbol.
	Remove [Replace with Idle]	Removes the Symbol.
DWORD Jam	Replace DWORD	Replace DWORD (FC 16 only).

Action		Description
Frame Jam	Insert Bytes Inside Frame	Allows to insert up to 60 Bytes inside the frame, at the specified offset or at the "current" dword, meaning the dword that caused the Event.
	Modify [Keep Length]	Allows to manipulate each dword in the header, with the selected Action (click on Pass though to get a drop-down list).
	Replace	Replaces the whole frame with the selected frame.
	Remove [Replace with IDLE]	Removes the whole frame.
	Truncate	Removes some of the payload, as specified in the Frame Length.
Inject General Error	Invalid 10-bit-Error Code	Injects invalid 10b code into the line (FC8 only).
	Running Disparity Error	Injects a Running Disparity (RD) error into traffic(FC8 only).
	FEC Parity Error	Injects a FEC error into traffic.
	Sync Header Error	Injects a Sync Header error into traffic.
	Block Error	Injects a Block error into traffic.
	Order Set Error	Injects a Order Set error into traffic, (Not available with 40GigE).
Insert	Insert New Frame	Allows to insert a whole frame as specified from the list of available frames.
	Symbol (66 Bit)	Allows to insert a Symbol 66 bits.
	Pre-captured Frame	Allows to insert a Pre-captured Frame (Ethernet only).
	Insert Bytes	Allows to insert Bytes (FC 16 only).
Ordered Set Jam	Delete	Delete an Ordered Set Jam.
	Remove [Replace with IDLE]	Remove an Ordered Set Jam or Replace with another Ordered Set.
	Replace with Another Ordered Set	Only replace with another Ordered Set.
Scenario Execution	Stop Scenario	Stops the current Scenario. This Action should be the only Action in a State as it has higher priority over other Actions.
	Restart All Sequence	Restart all sequences in the Scenario. <sup>1</sup>
	Restart Current Sequence	Restart the sequence that contains this Action definition. <sup>1</sup>
Branch To	Destination State	Go to a state in this Sequence. <sup>1</sup>

Action		Description
Trigger Output		Sends a signal out the trigger port to the device downstream.
	Analyzer Trigger	<ol> <li>The Action is to send a trigger to the Analyzer.</li> </ol>
		<ol><li>The trigger point in the Analyzer that caused the analyzer trigger action will not be the selected event, it will be the selected event with some offset.</li></ol>
	External Trigger Output	The Action is to cause an external trigger output.
	Marker Trigger	Add a marker to captured data.
Capture	DWORD	Capture DWORD.
		Reuse of Captured DWORDs. (See "Reusing "Captured DWORDS" in Events" on page 195.)
	Frame	Capture Frame (Ethernet only).

 $<sup>^{\</sup>mathbf{1}}$  Only shown in Action Properties dialog box when creating a sequence.

Changes made in the grey area in the screen below when modifying packets do not take effect and will not be jammed.




Figure 4.9: Frame Jam - Modify Dialog

The following figure displays the options for a set of Actions in the Simple Mode (FC).




Figure 4.10: FC Action Properties Dialog




Figure 4.11: Reconnect Menu for Selecting Direction

The following table lists the supported Actions. Note that some of these Actions only apply to creating sequences.

TABLE 4.5: Test State Actions in Simple Mode

Action		Description
Basic	Веер	Emits audible sound of duration selectable via a drop-down list.
	Monitor Count	Opens a window to count the number of Events that occur during a session. A session is a time interval during which a Scenario runs.
	Link Control	Reconnect - starts traffic pass-through immediately. This Action restarts traffic after a previous disconnect command. Once traffic is passing through, the originator and responder resume link bring up.
		Disconnect - puts InFusion ports at electrical idle immediately. This action is only in effect while the scenario is running, and the Jammer will reconnect the line when the scenario is stopped.
		Reconnect/Disconnect can be applied in either direction separately: From P1/P3/P5/P7 direction: Reconnect/
		Disconnect only the originator link.  From P2/P4/P6/P8 direction: Reconnect/ Disconnect only the responder link.
		(See Figure 4.11 on page 188.)
DWORD Jam	Replace DWORD	Replace DWORD.
Symbol Jam	Replace with Another Symbol	Replaces the Symbol with the selected Symbol.
	Delete	Deletes the Symbol Jam.
Frame Jam	Insert Bytes Inside Frame	Allows to insert up to 60 Bytes inside the frame, at the specified offset or at the "current" dword, meaning the dword that caused the Event.
	Modify [Keep Length]	Allows to manipulate each dword in the header, with the selected Action (click on Pass though to get a drop-down list).
	Replace	Replaces the whole frame with the selected frame.
	Remove [Replace with IDLE]	Removes the whole frame.
	Truncate	Removes some of the payload, as specified in the Frame Length.

Action		Description	
Inject General Error	FEC Parity Error	Injects a FEC error into traffic.	
	Sync Header Error	Injects a Sync Header error into traffic.	
	Invalid 10-bit-Error Code	Injects invalid 10b code into the line (FC8 only).	
	Running Disparity Error	Injects a Running Disparity (RD) error into traffic(FC8 only).	
Insert	Insert New Frame	Allows to insert a whole frame as specified from the list of available frames.	
	Symbol (66 Bit)	Allows to insert a Symbol 66 bits.	
	Insert Bytes	Allows to insert Bytes (FC 16 only).	
Ordered Set Jam	Delete	Delete an Ordered Set Jam.	
	Remove [Replace with IDLE]	Remove an Ordered Set Jam or Replace with another Ordered Set.	
	Replace with Another Ordered Set	Only replace with another Ordered Set.	
Scenario Execution	Stop Scenario	Stops the current Scenario. This Action should be the only Action in a State as it has higher priority over other Actions.	
	Restart All Sequence	Restart all sequences in the Scenario. 1	
	Restart Current	Restart the sequence that contains this	
	Sequence	Action definition. <sup>1</sup>	
Training Sequence Jam	Modify	Modify the Training Sequence Action Jam.	
Branch To	Destination State	Go to a state in this Sequence. <sup>1</sup>	
Trigger Output		Sends a signal out the trigger port to the device downstream.	
	Analyzer Trigger	1. The Action is to send a trigger to the Analyzer.	
		2. The trigger point in the Analyzer that caused the analyzer trigger action will not be the selected event, it will be the selected event with some offset.	
	External Trigger Output	The Action is to cause an external trigger output.	
	Internal Trigger Output	The Action is to cause an internal trigger output.	
	Marker Trigger	Add a marker to captured data.	
Capture	DWORD	Capture DWORD.	
		Reuse of Captured DWORDs. (See "Reusing "Captured DWORDS" in Events" on page 195.)	

Action	Description
Jammer Internal Triggers	Refer to section "Synch Jammer Scenarios with Jammer Internal Triggers" on page 206.

<sup>&</sup>lt;sup>1</sup> Only shown in Action Properties dialog box when creating a sequence.

### 4.6.5 Available Resources

You can specify Events, Combined Events and Actions and additional Events. The application automatically checks for the maximum number of terms (Events/Actions). When you exceed the limit, an error is flagged, prompting you to jump to the place that caused the error.

The list of available resources for Ethernet is given below:

- ☐ Symbol Detector(each has its own Embedded counter) X 4
- Auto-Neg Detector X 4
- □ Counter X 12
- □ Frame Detector X 8
- □ Timer X 8
- □ Frame Jammer X 8
- □ Symbol Substitute X 16
- Aut-Neg Jammer X 4
- □ Capture DWORD slot X 8
- ☐ Insert/Save frame slot (up to 16K bytes) X 7
- ☐ Insert BYTEs/Symbols inside frame (up to 128 bytes) X 8
- ☐ Global Action Register X 8
- ☐ State per sequencer X 256
- □ Action Register per state X 8

Usage of Action Register:

- ☐ Each Counter in Global Rules = 1
- □ Each Counter in State = 1
- ☐ Each Timer in Global Rules = 2
- □ Each Timer in State = 3
- □ Other Actions = 1

The list of available resources for Fibre Channel is given below:

- Symbol Detector (each has its own Embedded counter) X 4
- □ Ordered-set Detector (each has its own Embedded counter) X 8
- □ Pattern (32bit) Detector (each has its own Embedded counter) X 12
- ☐ Training Sequence Detector X 4
- □ Counter X 12
- □ Frame Detector X 8
- □ Timer X 8
- ☐ Frame Jammer X 8
- Symbol Substitute X 4

	Pattern/Orderded-set Substitute X 12 (shared with Pattern detectors)
	1 Training Sequence Jammer X 4
	Capture DWORD slot X 8
	Insert frame slot (up to 4K bytes) X 1
	Insert DWORD inside frame (up to 64 bytes) X 8
	I Global Action Register X 8
	State per sequencer X 256
	Action Register per state X 8
Usage	of Action Register:
	Each Counter in Global Rules = 2
	Each Counter in State = 3
	Each Timer in Global Rules = 2
	Each Timer in State = 3
Г	Other Actions - 1

# 4.6.6 Using Counters in Events and Actions

Many of the Events and Actions supported by InFusion also support counters that can control functions.

Within Events, counters determine how many times the Event must occur before the associated Actions are triggered. Event counters typically have two properties:

- Count Randomly: Can be set to "Yes" or "No" (default value is "No"). If the Count Randomly checkbox is selected, the Event repeats a random number of times (between 1 and the value set in the property Max Random Count, which replaces the property Counter Value when "Yes" is selected), before the Action is triggered.
- □ **Counter Value**: Number of repeats required when the **Count Randomly** checkbox is not selected. The default value is 1.

Within Actions, counters determine how many times the Event happens before it executes the Action. Note that an Event can be defined for a number of occurrences, so in total, the Event will have to occur for Event counter multiplied by the Action counter times before the Action gets executed. For example, if the Event is defined with a counter of 5, and Action with a counter of 10 such Events, the Event looked at will have to occur 50 times before the Action is taken.

Action counters typically have two properties:

- Action Random: Can be set to "Yes" or "No" (default value is "No"). If the Action Random checkbox is selected, the Action triggers a number of occurrences before the Action takes place. That number ranges randomly between 1 and the value set in the property Every Nth occurrence, which replaces the property Every Nth occurrence when the Action Random checkbox is selected.
- **Every Nth occurrence**: Number of times the system calls the Action before it acts.

Note that there is some overlap in the way these counters can be used. For example, in the simple case of a single Event leading to a single Action, it makes no difference whether you specify the Event to require five repeats before triggering the Action, or the Action to require five occurrences before it acts.

However, in the case of combined Events and/or Actions, the separate counters provide flexibility in designing test cases. For example, consider the case where Event\_1 OR Event\_2 leads to Action. If Event\_1 has a counter of 5, then the Action triggers either when Event\_1 has repeated five times or when Event\_2 happens the first time, whichever occurs first.

But if the Event counters are set to 1 and the Action counter is set to 5, then the Action happens after five occurrences of EITHER Event 1 or Event 2.

# 4.6.7 Capturing a Data Dword

InFusion provides the ability to capture individual data dwords and provides different registers to store captured dwords. When your detector is DWord Matcher you can use Dword #0, #1, #2 and #3 and when your detector is Pattern Detector you can use Dword #4, #5, #6 and #7. When trying to use the captured dword, for example in Replace Dword Action, you can actually select from 8 captured dwords, numbered 0 through 7.

To capture a data dword, select **Capture Dword** from the Action Properties screen (see Figure 4.12 on page 193). Select the location you would like the captured Dword to be stored in, so it can be used in a later replacement or insertion.




Figure 4.12: Capture Data Dword Action

## 4.6.8 Using Captured Data Dwords

Captured data dwords can be used in creating Events for data that match the captured dword(s), or in creating Actions to substitute or insert the captured dword(s) into the data stream.

To create an Event using the captured dword, in the Add Event dialog (see Figure 4.13 on page 194), select Dword Matcher and change the Type to the desired Captured Dword

number. Note that choice of a mask and an offset are still available. Select the code mask from the drop-down menu.



Figure 4.13: Using Captured Dword as an Event

Captured data dwords may also be used in the **Substitute Data Dword** Action. From the Action Properties screen, click on the **DWORD Jam** icon and click on Replace DWORD, choose **Substitute For Custom Dword** and then select the **Substitute for** property. A drop-down menu is provided (see below) that allows the choice of a custom dword or any of the four captured dword registers.




Figure 4.14: Using a Captured Data Dword in Substitute Dword Test Action

### 4.6.9 Dword Matcher

Dword Matcher is a dword pattern matcher that presents match and mask fields and a K-Code Mask field. K-Codes are control characters that are always used in the first byte of a four-byte ordered-set. Of the K-Code masks listed in the menu, D-D-D is used for data bytes, and K-D-D-D is used for all ordered-sets.

When you create a dword match, keep the following in mind:

The pattern can be inside or outside of frames (it does not matter if the pattern
is inside a frame or not).
Because the pattern can be inside or outside of frames, there is no offset.
You can make user-defined ordered-sets. (This is the reason this feature was cre-
ated.)
You can use any K/D pattern.

# 4.6.10 Reusing "Captured DWORDS" in Events

This feature will enable the user to reuse previously captured data inside a Frame event; therefore some parts of the frame event can be changed during the jammer running period in real time.

To use a captured DWord in a Frame Event, the user can right click on Data pane of the Frame Event Properties dialog and choose "Replace with Captured DWord". Then another dialog will pop up and the user can specify which captured DWord (Capture DWord#0 to Capture DWord#3) to use to replace the selected DWord at run time. A user can mask any of the bytes of the captured DWord by using the Mask buttons provided in the "Replace With Captured Data" dialog.



Figure 4.15: Replace with Captured DWORD Menu




Figure 4.16: Replace with Captured Data Dialog

To remove or edit the existing captured DWord in an event, the user can right-click on the desired DWORD and choose "Remove" or "Edit"



Figure 4.17: Remove or Edit Captured DWORD

### 4.6.11 Global Rules

Global Rules are a portion of the Scenario that can define only one test state. To create the Global Rules, you use the menu-driven interface to enter an Event or Combined Event and the corresponding Action or set of Actions (the response of InFusion hardware to the Event).

In the case of a Combined Event, the Action is taken upon occurrence of any of the Events stated for the Event combination. It is a logical OR association, meaning any of the Events can trigger the Action.

After you enter the Event or Combined Event, the interface prompts you for Actions. An Action might be, for example, injecting a particular ordered-set or error into the traffic stream. You can enter multiple Actions, which take place simultaneously. If one of the Actions is Stop Scenario, the other Actions will NOT be carried out. To stop the Scenario after the requested Actions have been carried out, you should branch to a new state which stops the Scenario.

After defining the Event and Actions within the Global Rules panel, you can save the Scenario and run it.

## 4.6.12 Sequences

The Global Rules are all you need for simple test Scenarios. However, a Scenario also can contain one or two sequences, which can define multiple states and allow branching between states. With a sequence, you also can do looping, which allows you to repeat a test state or to execute a test for a specified period of time.

As with Global Rules, the menu-driven interface guides you in building a sequence. Some of the prompts are different, however, because you now are encapsulating groups of Events and Actions as distinct states. Recall that a state is a combination of Events and Actions at a specific point in time. If the Event or Combined Event defined by a state occurs, the corresponding Action or set of Actions follows. You can enter multiple Actions, which take place simultaneously. If one of the Actions is Stop Scenario, the other Actions are carried out. To stop the Scenario after the requested Actions have been carried out, you should branch to a new state which stops the Scenario.

InFusion hardware provides the capacity to have up to two sequences co-existing in a Scenario in addition to the Global Rules. Recall that both the Global Rules and any sequences are active at all times. Each is a separate "state machine," having the behavior of a particular test state at any point in time. Because the Global Rules has the capacity for only one state, you can view it as a "degenerative state machine."

### 4.6.13 Scenario Libraries

Libraries are repositories that hold Scenarios. This section describes the ways that you can manipulate Scenarios within Libraries.

### Scenario Library Item Multi-Selection

The Scenario Library lists support conventional multi-selection via mouse-clicks and keyboard modifiers. The Copy Scenario item from the right-click context menu will operate on all selected items:

- ☐ Hold down the Ctrl key on the keyboard and click on items to toggle their selection state.
- □ Select a first item, then hold down the Shift key and select a second item; all items from the first item to the second item will be selected.

## **Global and Project Libraries**

The scenarios saved in the Global Library are available to reuse for all projects. The scenarios saved in the Project Library are only available for the current project. You may transfer Scenarios between these libraries by drag-n-drop or copy/paste.

Adding Scenarios from Global to Project can only work if the protocol is similar, else it will be greyed out and unselectable.

## Import/Export of Scenarios

Users can export a scenario (or multiple scenarios) to a file. Export is available via right click pop up menu. Scenarios can then be archived on your host machine's hard drive.

There are two ways to import a library, if the user wants to import file into a existing library, they have to right click on the existing library and select import library. If the user wants to make a new library, there is an icon to import a library in library pane toolbar.

## 4.6.14 Traffic Direction

The direction for traffic modification is defined on a global basis for the entire Scenario. In other words, any Scenario Action that modifies line traffic only affects the traffic flowing in the direction established at the top of the Scenario, in the Scenario Properties. Scenario Events can be monitored in either direction, and therefore the parameters for Events provide the ability to specify the intended direction for monitoring traffic for that Event.

You identify direction of traffic change, or modification, in terms of traffic origin. The application uses the following conventions:

- □ **From P1/P3**: Change is made to traffic coming from Port 1 or Port 3 (for example, CRC error is injected into traffic stream sent from P1/P3 to P2/P4).
- □ From P2/P4: Modification is made to traffic coming from the Port 2 or Port 4 (for example, CRC error is injected into traffic stream sent from P2/P4 to P1/P3).




Figure 4.18: Traffic Direction

To copy an Event or Action, right-click on the Event or Action and select **Copy**. Right-click and select **Paste**.

You can also remove, cut and copy a selected Event or Action.

You can double-click the State name and edit it.

# 4.6.15 Copy and Paste Scenarios

You can copy and paste scenarios from one project to another project. Perform the following steps to do so:

 Select the scenario you want to copy in either the scenario name tab and select Copy or in the Library pane, right-click and select Copy Scenario (see Figure 4.19 on page 200.




Figure 4.19: Copy Scenario

Place the cursor in the area below <New Scenario> in the Library pane, in the project you want to paste in, right- click and select Paste Scenario.




Figure 4.20: Paste Scenario

# 4.6.16 Copy and Paste Library

You can copy and paste libraries from one project to another project. Perform the following steps to do so:

1. Select the library you want to copy, right-click and select **Copy Library**.




Figure 4.21: Copy Library

2. Place the cursor on the Jammer libraries icon in the Global Libraries panel, right-click and select **Paste**.




Figure 4.22: Paste Library

## 4.6.17 Copy/Cut and Paste States

You can copy and paste states from Global Rules to Sequences. You can also copy/cut and paste states between Sequences. You cannot cut a state from nor paste a state into Global Rules.

- 1. Right-click in the blue title area of the State you want to copy and select Copy State (or Cut State if applicable).
- 2. Right-click in the white workspace of the desired target Sequence and select Paste State.

# 4.6.18 Copy/Cut and Paste Conditions

You can copy and paste Conditions within and between States.

- 1. Right-click in the empty yellow space of the Condition you want to copy and select Copy Condition (or Cut Condition if applicable).
- 2. Right-click in the gray placeholder area (i.e. in the area that says "Drag an event here....") of the desired target State and select Paste.

# 4.6.19 Copy/Cut and Paste Events

You can copy and paste Events within and between States.

- 1. Right-click on the Event you want to copy and select Copy (or Cut if applicable).
- Right-click in the empty yellow space of the desired target Condition or in the gray placeholder area (i.e. in the area that says "Drag an event here....") of the desired target State and select Paste.

## 4.6.20 Marker Trigger

### **Purpose**

The main purpose of this feature is enabling the user to mark specific parts of the captured traffic for better tracking.

### Solution

The Marker Trigger action will be added to Jammer under Trigger Output category. Also, for differentiating various markers, the action will has an Index parameter that will be shown in the captured traffic as well. Therefore 8 Marker actions will be as bellow:

- 1. Jammer Marker 1
- 2. Jammer Marker 2
- Jammer Marker 3
- 4. Jammer Marker 4
- 5. Jammer Marker 5
- 6. Jammer Marker 6
- 7. Jammer Marker 7

### 8. Jammer Marker 8

Adding above markers can be used as an action in the Jammer. When the Jammer runs this action, the result is adding a marker (bookmark) in captured trace in analyzer. The added markers will be shown as a normal marker (bookmark) in trace and you can see list of marker in book mark dialog.

**Note:** The limitation for adding markers is 10,000, it means you can add up to 10,000 marker to a trace.

### GUI

Marker trigger added under "Trigger output" node in action tree as below:




Figure 4.23: Marker Trigger Added to Action Tree

There is a dropdown list in Marker Trigger dialog to choose which marker user wants to insert to analyzer trace. (Marker 1 to Marker 8).




Figure 4.24: Marker Trigger Menu

# 4.6.21 Synch Jammer Scenarios with Jammer Internal Triggers

By design, each Jammer port pair runs its own independent scenario, and each one can be controlled independently. However, there may be advanced cases where you would need to synchronize the Jammer operation of 2 or more port pairs. For example, you might want to create a setup in which you jam both directions of a single link; you can achieve this by looping the link through P1/P2 and P3/P4 with external cabling, running separate scenarios on each of P1/P2 and P3/P4, and synchronizing those scenarios with the Jammer Internal Triggers.

Jammer Internal Triggers are pairs of events and actions that enable cross-port signaling; these events and actions are manipulated like any other event and action. The Internal Trigger Action allows one port pair to signal an Internal Trigger Event on a different port pair. Note that the Internal Trigger Action will NOT signal an Internal Trigger Event on the same port pair. There are four independent Jammer Internal Trigger event/action pairs available

For supporting this feature, a specific signal between different paths should be added, such that one scenario will be able to notify the scenarios of other paths.

Thus, firstly, it is needed to add a new Action for notifying other paths and secondly, adding a new event for waiting on any notify signal that is raised on other paths. This will be implemented as bellow:

- 1. Adding 'Internal Trigger' action to notify all other paths:
  - a. Internal Trigger Action 1
  - b. Internal Trigger Action 2
  - c. Internal Trigger Action 3
  - d. Internal Trigger Action 4
- 2. Adding 'Internal Trigger' event to wait for others' notifications
  - a. Internal Trigger Event 1 which is corresponded to Internal Trigger Action 1
  - b. Internal Trigger Event 2 which is corresponded to Internal Trigger Action 2
  - c. Internal Trigger Event 3 which is corresponded to Internal Trigger Action 3
  - d. Internal Trigger Event 4 which is corresponded to Internal Trigger Action 4

### **Example**

For example, the user would like to insert a new frame on P1/P2 path (ACTION1) when there is a specific symbol on P3/P4 path (EVENT1), this scenario will be implemented in 2 different scenarios as below:

- 1. In the first scenario for P1/P2, in the global state define a condition that waits for EVENT1 and then raise 'Internal Trigger' action.
- 2. In the second scenario for P3/P4, in the global state define a condition that waits for the same 'Internal Trigger' event and the does ACTION1.

### Scenario 1



Figure 4.25: Scenario 1 using Jammer Internal Trigger




Figure 4.26: Internal Trigger action in the Actions pane




Figure 4.27: Internal Trigger Action Properties

### Scenario 2



Figure 4.28: Scenario 2 using Jammer Internal Trigger Event




Figure 4.29: Internal Trigger Event in the Events Pane




Figure 4.30: Internal Trigger Event Properties

Scenario Example Teledyne LeCroy

#### 4.7 Scenario Example

#### 4.7.1 Example: Insert DWORD Matcher

In this example, the Global Rules panel of the Scenario waits for a Custom Frame then inserts a Dword inside the frame. In Sequence 0 and State 0 it waits for an FCP SCSI Command, SBC3; inserts a Dword inside the frame, beeps for a duration of 50 ms and stops the Scenario.

#### **Creating Global Rules**

This section describes using the Global Rules panel of the Scenario for this example. Recall that the Global Rules panel defines a single test state. The Global Rules do not have the capacity for multiple states, so that area of a Scenario cannot change state.

In terms of InFusion testing, a state defines test "behavior." In this context, behavior is "waiting" for an Event and responding with an Action or set of Actions that happen simultaneously.

Keep in mind that a test state you implement with the Global Rules operates in parallel with the active test state of each sequence in the Scenario.

In effect, InFusion lets you do up to three line tests at the same time. You can do one test with the Global Rules and a separate test with each sequence you create. You can have up to two sequences in a Scenario.

- Select Traffic Direction from the drop-down list to trigger on the defined event or trigger from InFusion Jammer (the default is From P1/P3, which is selected for this example).
- 2. In the Global Rules panel (see Figure 4.31 on page 210).
- 3. Select **DWORD Matcher** in the Event panel and place it in the Global Rules panel (see Figure 4.32 on page 210).

Teledyne LeCroy Scenario Example




Figure 4.31: Global Rules Panel




Figure 4.32: Adding an Event

4. The Event is added to the Global Rules panel (see Figure 4.33 on page 211).

Scenario Example Teledyne LeCroy

5. Select **Replace DWORD** in the Action panel and place it in the Global Rules panel (see Figure 4.33 on page 211).

6. Right-click the New Scenario tab and select **Rename Scenario** and enter the name in the Library panel as shown in Figure 4.33 on page 211




Figure 4.33: Global Rules - Naming a Scenario

#### Adding a Sequence

To add a Sequence click **Add State in the Sequence 1** panel.

You create a sequence one state at a time. The application numbers states consecutively from 0 up (1, 2, 3, and so on).

By default, the name of the first sequence in a Scenario is Sequence 1. The name of the first state is State 0. To change the name of a sequence or state, or to associate a description with it, click the name of the sequence or state..

1. Drag **6-Byte Any SCSI Command** under **FCP** as the Event to display the dialog.

Teledyne LeCroy Scenario Example



Figure 4.34: Adding an Event for Sequence 1

- 2. Click **OK** to close the 6-Byte Any SCSI Command dialog box.
- 3. After adding an Event, to add an Action in the Sequence 1 panel, drag and drop Monitor/Count.

The Monitor/Count dialog box displays.




Figure 4.35: Adding Action Monitor/Count for Sequence 1

- 4. Click the **OK** button to close the Monitor/Count dialog box.
- Repeat step 4 to add another Action (if desired).
   The completed Scenario is shown below.

Scenario Example Teledyne LeCroy




Figure 4.36: Complete Scenario of Insert DWORD Matcher

#### 4.7.2 Sequence Creation

A sequence can have multiple states, but only one state is active at any time. In other words, at any point in time, a sequence "waits" for one Event (or Combined Event) and responds with the corresponding Action or set of Actions when the Event occurs.

A sequence is more powerful than Global Rules, because you can create branching or looping test logic with a sequence. You can include up to two sequences in a Scenario, but each is completely independent of the other. There is no branching or other interaction between the two, except through the Restart All Sequences Action.

You must follow some simple rules when creating sequences:

Teledyne LeCroy Running Scenarios

#### **TABLE 4.6: Sequence Rules**

You can use only two branch Actions per state.

When you specify Actions for a state, you can only use two instances of **Branch to an Existing State** or **Branch to a New State**. If you try to use more than two, a red error message appears in the status area of the application that says "Too Many Actions."

#### You can use only one restart sequence Action per state.

When you specify Actions for a state, you can only use one instance of **Restart Current Sequence** or **Restart All Sequences**. If you try to use more than one, a red error message appears in the status area of the application that says "Too Many Actions."

#### You can use a maximum of 255 states per sequence.

If you try to use more than 255 states, a red error message appears in the status area of the application.

#### 4.7.3 Summary of Scenario Creation

The suggested process of creating and executing a Scenario is as follows:

- Create a Scenario in the library.
- 2. Drag and drop to create Global Rules Events and Actions and/or to create Sequence and State Events and Actions.
- 3. Complete the Scenario and Save it.
- 4. Select the Scenario in the Library that you want to run on the device.
- 5. To run the Scenario, click the **Start Session** button. The device starts to monitor/modify traffic.

#### 4.8 Running Scenarios

If you use a library as a Scenario archive, then the process of executing a Scenario is as follows:

Click on **File > Open** to open an existing File Library. The File Library displays all saved Scenarios in that library and you can select a Scenario.



OR

Select a saved Scenario from the drop-down list and click the **Start Session** button.

Running Scenarios Teledyne LeCroy



Figure 4.37: Running a Scenario

Once the Scenario is complete or stopped the Output panel displays the Port, Time, Event, Action duration and value.



Figure 4.38: Output Panel Displaying Session Started and Stopped

Teledyne LeCroy Running Scenarios

# **Chapter 5**

### **Batch Scenario**

#### 5.1 Using the Batch Scenario Feature

You can run a sequence of executable scenarios to control both the Analyzer and the Jammer automatically. A Scenario Batch file is a a list of commands to run in sequence when you execute the file. A batch scenario can manage Jammer scenarios and Analyzer recordings and their assigned ports and hardware in sequence. The system checks for accuracy of inputs and commands.

Once a new Project is defined (see "Starting a New Project" on page 34) you can use the Batch Scenario feature by selecting **File>Batch** to display the Batch Scenario Manager dialog (see Figure 5.1 on page 218). Batch Scenarios are part of a Project, and are saved as such. Each Project file can have a unique set of different Batch Scenarios.

A batch scenario can be repeated up to 10,000 times. Branching to previous states is not permitted, in order to prevent infinite loops.




Figure 5.1: Batch Scenario Manager Dialog.

#### 5.1.1 Interface

The following buttons and panels are available to use the Batch Scenario functions:

- □ Show/Hide Batch Scenario Button: Toggles between showing/hiding the Batch Scenario pane.
- □ **Show/Hide Command/Event Button:** Toggles between showing/hiding the Command/ Event pane.
- □ **Show/Hide Batch Log Button:** Toggles between showing/hiding the Batch Log pane.
- □ Add State Button: Click to add a new state.
- ☐ Insert State Button: Click to insert a state after the selected state.
- □ **Delete State Button:** Click to delete the selected state.
- □ **Start Button:** Click to start the scenario.
- **Batch Scenario Panel:** Lists all the available Batch Scenarios. Double-click on <**New Batch Scenario**> to create a new scenario. The following operations are available through a right-click context menu:
  - Remove Scenario
  - Rename Scenario
  - Copy Scenario
  - Paste Scenario
- □ **Command/Event Panel:** Lists all the available Commands and Events.
- **Batch Log Panel:** Displays the scenario name, date and time run and description of the scenario.

**Note:** The log viewer reads up to 1000 entries, but when you save a batch log, it will contain the last 500,000 internal entries.

**Note:** In order to save the jammer log from batch mode, enable "Automatic log" in the Jammer log settings.

#### 5.2 Batch Scenario Overview

You create Batch Scenarios on a host machine running the Net Protocol Suite application. You then specify the Batch Scenarios for execution on a SierraNet platform.

The Net protocol Suite application provides a user friendly interface for building Batch Scenarios. The interface prompts you for simple decisions and choices using buttons and has a drag and drop interface. As you make your selections, the script takes shape automatically in the Batch Scenario window.

Click the **Add State** button, then drag and drop Commands and Events in the new State panels that get created. If invalid actions are assigned, then a red Invalid Session message displays in the Batch Log panel.



Figure 5.2: Add State Batch Scenario Manager.

#### **5.2.1 Adding Commands**

Four types of commands are available:

#### **Start Analyzer**

Drag and drop the Start Analyzer command to display the Command Property dialog.




Figure 5.3: Start Analyzer Command Property Dialog.

Chain: Select a Chain from the drop-down list.

**Project Chain Settings**: Click this button to select Project Chain Settings.

**Advanced Settings**: Click this button to select Project Chain Settings to activate the settings below:

**Trace Path**: Click the ellipsis button to display the Select Trace File Name dialog to save the trace file.

Overwrite Trace File: Select the checkbox to overwrite the trace file.

Buffer Settings: Set the number of segments and the buffer size.

**Trigger Settings**: Select Snapshot or Trigger Event. Select the Trigger Filter Settings from the dropdown list and move the slider to the desired percentage.

If a delay is needed after the command is executed, check the Delay checkbox and set the time in seconds.

#### **Start Jammer**

Drag and drop the Start Jammer command to display the Start Jammer Properties dialog.




Figure 5.4: Start Jammer Properties Dialog.

Select the Jammer checkbox to select all four port pairs or select individual port pairs. If a delay is needed after the command is executed, check the Delay checkbox and set the time in seconds.

#### **Stop Analyzer**

Drag and drop the Stop Analyzer command to display the Stop Analyzer Properties dialog.




Figure 5.5: Stop Analyzer Properties Dialog.

Select the Analyzer checkbox. If a delay is needed after the command is executed, check the Delay checkbox and set the time in seconds.

#### **Stop Jammer**

Drag and drop the Stop Jammer command to display the Stop Jammer Properties dialog.




Figure 5.6: Stop Jammer Properties Dialog.

Select the Jammer checkbox to select all four port pairs or select individual port pairs. If a delay is needed after the command is executed, check the Delay checkbox and set the time in seconds.

#### 5.2.2 Adding Events

Three types of events are available:

#### **Wait For Trigger**

Drag and drop the Wait For Trigger event to display the Wait For Trigger Properties dialog.




Figure 5.7: Wait For Trigger Properties Dialog.

Select an option from the drop-down list. In order to prevent an infinite Wait, you can select the Timeout checkbox and set the time in seconds.

#### Wait For Stop Analyzer

Drag and drop the Wait For Stop Analyzer event to display the Wait For Stop Analyzer Properties dialog.




Figure 5.8: Wait For Stop Analyzer Properties Dialog.

Select an option from the drop-down list. In order to prevent an infinite Wait, you can select the Timeout checkbox and set the time in seconds.

#### **Wait For Stop Jammer**

Drag and drop the Wait For Stop Jammer event to display the Wait For Stop Jammer Properties dialog.




Figure 5.9: Wait For Stop Jammer Properties Dialog.

Select the Jammer checkbox to select all four port pairs or select individual port pairs. In order to prevent an infinite Wait, you can select the Timeout checkbox and set the time in seconds.

#### 5.2.3 State Transition

Click on the State Transition icon to change the state to transition to. Left-click for menu options to display as shown in the following screen capture and select the state to transition to. To remove the state transition select **No Jump.** 




Figure 5.10: State Transition.

#### 5.2.4 Global Variables

Each batch scenario contains a list of global variables which allows you to set data for specific fields of frame events, or trigger setting patterns without editing them one by one. Global variables are automatically applied to all the trigger setting patterns that are selected in the "Start Analyzer" command immediately before you run the command. If you select "Use Project Chain Settings" with the "Start Analyzer" command, global variables will be applied to the current trigger settings.

This also works for the Jammer. Global variables are applied automatically to all frame events of a Jammer scenario that are selected in the "Start Jammer" command, immediately before you run the command.

Global variables have no effect on any trigger settings or Jammer scenarios that are not used in the batch scenario.

Global variables provide dynamically changing event fields in runtime. You can add as many fields as you need to the global variable list and specify your desired value for them. When running batch mode, the software replaces your value in the specified field for any event in which that field is used. The software looks in all events for that field and replaces the value.

#### **Global Variables Dialog**

- 1. To change the definition of selected global variables, go to Batch Scenario Manager and click on the "Global Variables" button.
  - ☐ The Global Variables dialog window opens.




Figure 5.11: Batch Scenario Manager window.




Figure 5.12: Global Variables dialog window.

This window consists of two panes: on the left, a tree of all available fields. On the right is a table of fields that can be selected.

You can add a global variable to the table simply by dragging a field from the tree on the left and dropping it into the table on the right. This adds the field to the table with an empty value. To edit the value, simply double-click on the value cell.

A red "H" appears at the left of the value cell. (See Figure 5.13.) This shows, by default, that the value is to be in hexadecimal format. You can switch between binary and hexadecimal by simply clicking on the red H; it changes to a red "B" for binary. (See Figure 5.14.)



Figure 5.13: Hexadecimal button.




Figure 5.14: Binary button.

There is no length limit for the value, but it may trimmed according to field length when it is applied to a frame pattern or event.

To remove a global variable, simply select it on the table and select the Delete button. The variable is removed from the right pane of the dialog.

The Up and Down arrows (Figure 5.15) let you rearrange the order of variable values that you wish to change, before Net Protocol Suite runs a scenario. For most fields, the order does not matter, but for the fields that do change the format of events, this order becomes important. For example, suppose you want to change the value of the field **Opcode** in a SCSI command, and then change one of the other fields in that SCSI command. You will have to move the Opcode field to the top of the list, because when you set Opcode fields, the event fields will be changed automatically. Then you can change the value of another field. On the other hand, if you want to set the value of a field such as **Originator S\_ID**, changing its value has no effect on the format of other fields in an event, so you don't need to specify the order in which these fields are accessed.



Figure 5.15: Location of Delete button and Up and Down arrows.

**Note:** Replacing any value in a frame pattern or event may cause other fields values to reset. To avoid this, make sure you select the correct order of global variables.

For example, assume there is a batch scenario with one "Start Jammer" command and global variables as shown in Figure 5.16 and Figure 5.17.



Figure 5.16: Example of a Batch Scenario.



Figure 5.17: Destination Address field selected.

A batch scenario such as this can run a jammer scenario with a frame event. An example is shown in Figure 5.18.




Figure 5.18: Destination Address before changes.

As you see, the "Destination Address" field is 0xXXXXXXXX XXXX. After starting the batch scenario, the expected behavior is the "Destination Address" field is replaced with the value 0x1122334455 from the defined global variable.

If you check the same jammer frame event after running the batch, the result will be as seen in Figure 5.19, which is the expected behavior.




Figure 5.19: Destination Address after changes.

**Note:** This function makes changes in the actual frame pattern/event which will result in changes in your project.

# Appendix A

## **China Restriction of Hazardous Substances Table**

The following tables are supplied in compliance with China's Restriction of Hazardous Substances (China RoHS) requirements:

			有:	毒有害物质和元	法	
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
部件名称	(Pb)	(Hg)	(Cd)	(Cr <sup>6+</sup> )	(PBB)	(PBDE)
PCBAs	X	0	X	X	X	X
机械硬件	0	0	X	0	0	0
金属片	0	0	X	0	0	0
塑料部件	0	0	0	0	X	X
电源	X	X	X	0	X	X
电源线	X	0	X	0	X	X
保护外壳(如有)	0	0	0	0	X	X
电缆组件(如有)	X	0	X	0	X	X
风扇(如有)	X	0	X	0	X	X
交流滤波器和熔丝组件(如有)	X	0	X	0	0	0
外部电源(如有)	X	X	X	0	X	X
探头(如有)	X	0	X	0	X	X

X:表明该有毒有害物质至少在该部件的某一均质材料中的含量超过 SJ/T11363-2006 标准规定的限量要求。

EFUP (对环境友好的使用时间) 使用条件:

温度: 5摄氏度到40摄氏度

湿度: 5% - 95%最大相对湿度 (无冷凝)

高度: 最高2000米

	Toxic or Hazardous Substances and Elements					
				Hexavalent	Polybrominated	Polybrominated
	Lead	Mercury	Cadmium	Chromium	Biphenyls	Diphenyl Ethers
Part Name	(Pb)	(Hg)	(Cd)	(Cr <sup>6+</sup> )	(PBB)	(PBDE)
PCBAs	X	0	X	X	X	X
Mechanical Hardware	O	О	X	О	O	0
Sheet Metal	O	0	X	O	0	0
Plastic Parts	О	0	0	О	X	X
Power Supply	X	X	X	О	X	X
Power Cord	X	0	X	0	X	X
Protective Case (if present)	О	0	0	0	X	X
Cable Assemblies (if present)	X	0	X	О	X	X
Fans (if present)	X	0	X	0	X	X
AC Filter/Fuse Assy (if present)	X	О	X	О	0	0
Ext Power Supply (if present)	X	X	X	О	X	X
Probes (if present)	X	0	X	0	X	X

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement specified in SJ/T11363-2006.

EFUP (Environmental Friendly Use Period) Use Conditions:

Temperature 5C to 40C

Humidity 5% to 95% max RH (non-condensing)

Up to 2000 meters Altitude

X: Indicates that this toxic or hazardous substance contained in at least one of the homogenous materials used for this part is above the limit requirement specified in SJ/T11363-2006.

# **Appendix B**

## **How to Contact Teledyne LeCroy**

Type of Service		Contact
Call for technical support	US and Canada:	1 (800) 909-7112
	Worldwide:	1 (408) 653-1260
Fax your questions	Worldwide:	1 (408) 727-6622
Write a letter		Teledyne LeCroy
	Pr	rotocol Solutions Group
		<b>Customer Support</b>
		3385 Scott Blvd.
	Sant	a Clara, CA 95054-3115
		USA
Send e-mail	psgsuppo	rt@teledynelecroy.com
Visit Teledyne LeCroy's web		teledynelecroy.com/
site		
Tell Teledyne LeCroy	Report a problem to Teledyne LeCroy	/ Support via e-mail by
	selecting Help>Tell Teledyne LeCroy	from the application
	toolbar. This requires that an e-mail of	client be installed and
	configured on the host machine.	

# Index

Symbols	Choose Port Speed 104
.fcc files 33	Close Project 35
	Combined Event 181
A	components 2
About 48, 162	configuration 149
Action 181	Connect Disconnect Pattern dialog 74, 94, 95, 96, 97, 98
action	Connecting to a Network 21
counter 192	contact 235
scenario 181	Count Randomly 192
Action Properties dialog 185, 191	Counter Value 192
Adapters 19	counters 192
Add Basic Link Service Pattern dialog 77, 78, 81, 82, 83,	CrossSync Control Panel 31
84, 86, 88, 89, 90, 92, 93, 99, 100	cursors
Add Device 18	locating 142
Add Link Control Frame Pattern dialog. 100	positioning 142
Adding Commands 220	
Adding Events 224	D
address 235	daisy-chain 12
Address Alias 17	data 30
Advanced Mode 14, 104	Data View icon 36
Analysis Project dialog 68	defining patterns 102
analyzer	DHCP 25
connecting 7	DHCP server 21
application overview 14	Disconnect 18
Auto Run 7	display configuration 149
n	Don't care (Snapshot) 101
<b>B</b>	Dword Matcher 195
batch scenario 217	
Batch Scenario Overview 219	E
Break Link Recovery 164	Easy Mode 14, 64
	e-mail 235
С	Email CATC Support 235
cables	Error Injection 164
usage 8	error message
capture	startup 7
parameter 65 pre and post trigger 71	Ethernet
captured data 30	connecting with 21
CATC Technical Support 235	Ethernet port 2
Check for Updates 161	Event 181
alamanasa	event

Teledyne LeCroy Index

counter 192	InFusion scenarios 167
example files 70	Install component selection 7
expandability 12	Installation CD ROM 2
Export to Wireshark icon 37	installing the analyzer 7
External Trig In Setting 58	IP Settings 18
External Trig Out Setting 58	IP Setup 22
External Trig Setting dialog 58	IP Setup dialog 26
external trigger 2	
External Trigger Setting icon 37	K
_	K-Codes 195
F	
fax number 235	L
features 2	launching 14
File menu 38	LCD display 5
file type	LCD Display and Button Functions 5
definition 69	LCD Display and Button Functions for Configuring
filter 138	the Analyzer 5
type 140 Filter icon 37	LEDs 3
filtering 138	description 3
Find 18	link layer
Find icon 37	command interpretation 67
Find Next icon 37	
Find Previous icon 37	M
Force Add/Connect Attempt 18	Main Toolbar 136
Frame Inspector View icon 36	Main Window 64
From Initiator 199	manual trigger 102
From Target 199	menu
full screen	help 48
results display 138	navigation 46 view 47
results display 150	Multi Sequencer check box 111
G	•
Global Rules 197	N
examples 209	Navigation menu 46
Global Variables 228	network 21
Global Variables Dialog 228	New Batch Script command 219
Go To button 137	
Go to icon 37	0
Go To Timestamp dialog 143	Open icon 36
Go to trigger icon 37	operating system 7
Goto Response 123	Others 43
Н	P
hardware	Packet Drop 164
run 66	packing list 2
Help (F1) 48	pattern
Help menu 48	definition 102
Help Topics 160	Pattern command 71
	pattern definition
1	in sequential trigger mode 102
Idles icon 37	Pattern triggers 101
InFusion 31, 163	port
Infusion 31	show/hide 135

Index Teledyne LeCroy

port alias 153, 154	Setup IP 25
Port Filters button 138	Setup IP command 25
Port Status 31	Setup menu 39,41
Ports icon 37	Setup Preferences 40
Preferences icon 36	Show/Hide Field 135
pre-trigger 102	Show/Hide Idles 138
Primitive Manipulation 164	Show/Hide Port 135
Program Manager Window 14	SierraNet M408 Protocol Analyzer 1
project	Snapshot mode 101
examples 70	software installation 7
file type definition 69	software overview 14
Protocol Analysis 33	spreadsheet view 118
Protocol Analyzer 30	Spreadsheet View icon 36
	Start Analyzer 220
Q	Start Jammer 221
Quick View 116	State 181
	State Transition 227
R	Static IP 25
recording	Status bar 138
progress 66	Stop Analyzer 222
Recording Setting icon 37	Stop Batch Script 219
Refresh Device List 20	Stop Batch Script 219 Stop Hardware button 102
Remote Connection Settings dialog 15	Stop Hardware Button 102 Stop Jammer 223
Remove Device 18	Subnets 19
Reset Device 20	support 235
Run Batch Script command 219	Support 233
run hardware 66	Т
5	Technical Support 235
S	telephone number 235
save	time
partial trace capture 68, 69 trace capture 68	relative display 67
Save As Text dialog 122	timer
Save icon 36	setup advanced mode 111
scenario 167	Timer Pattern dialog 72
action 181	tool bar 136
creation 214	Toolbar command 136
overview 167	Trace Capture 68,69
Scenario Batch file 217	Trace is Not Saved 59
SCSI commands	Traffic Monitoring 164
address display 67 search	Traffic Summary icon 36
for data pattern 145	Traffic Summary View 30, 43
save setup 145	trigger
status 138	manually 102
search direction 145	multi link 111 on timer 72
search from 146	position in memory 103
selecting components for installation 7	snapshot 101
sequence 198	Trigger Filter Settings icon 37
session 183, 189	
set IP Configuration 5	U
set IP Mode Dynamic 6	unpacking 2
Set IP Mode Static 6	Update Device 28
Setup command 7	USB port 2

Teledyne LeCroy Index

Using the Batch Scenario Feature 217 using the cursors 142 Using the Software 14

#### V

Value Replacement 164 View menu 47 View Type Toolbar 113, 114, 115, 117 Viewer 30, 113 Viewer Setting toolbar 137 Viewing Captured Data 30 views 30

#### W

Wait For Stop Analyzer 225 Wait For Stop Jammer 226 Wait For Trigger 224 web site 235 Website, CATC 235 Windows 48

#### Ζ

Zoom In results display 138 Zoom in icon 37 Zoom Out results display 138 Zoom out icon 37